## Thank you for choosing Redmi 2

This user guide will take you through the basic steps to set up your Redmi 2.
For more information, see:

- Xiaomi's official website: www.mi.com.

Front Camera
Volume Button
Power Button
Task Button
Back Button
Home Button
LED Indicator
USB Port

### Power Button
Long press this button to turn the device on or off.

### Volume Button
Adjust the sound volume. Press this button when there is an incoming call to switch to silent mode.

### USB Port
Supports USB On-The-Go function.

Redmi 2 User Guide

## Insert the Micro SIM or UIM Card

Make sure the Micro SIM or UIM card's metal contacts are facing down and its cut-off corner is facing the left.

Warning: Redmi 2 Micro SIM or UIM card is positioned above the battery.

You need to remove the battery before inserting or removing the SIM/UIM card.

## Insert or Remove the Battery

Align the battery's exposed copper contacts with the battery compartment, and insert the battery by pressing down gently;
Remove the battery by pulling outward gently from the notch at the base of the battery compartment.

## Insert or Remove a Memory Card

Warning: Please safely uninstall or switch off the device before inserting or removing the memory card. Otherwise system problems may occur.

1. Insert a memory card, contact area facing downwards, into the card slot;
2. You will hear a clicking sound when the memory card is locked in place. The installation is complete.

## Removing the Back Cover

To remove your phone's back cover, press down on the middle of the back cover while pulling up gently at the notch as indicated.

A-P-XXXX