Ford Ecosport 76124H01B9 / 76124H02B9

Vehicle Entertainment & Navigation system

User Manual

Before using the navigation system, please read this user manual carefully and keep it properly for future reference.

V1. 0



Declaration

- This user manual mainly introduce the function of the vehicle AV system, purpose, operation method, etc.;
- This manual is only used as operation instruction, not as a basis for maintenance services;
 Due to the continuous improvement of products, design and specifications, if there is any
- changes, no prior notice is delivered;
 The information provided in this manual can be modified without any statement, our company reserves the final interpretation for this modification;
- The pictures used in this manual are only for reference, and we do not assume any responsibility for the misunderstanding;
 Pictures are only for information, take real products as standard. If you need any details
- information, please kindly turn to the dealers;;

 Product name and brand name belong to the company's trademarks or registered trademarks.

Catalogue

Before the system using	
Important safety information · · · · · · · · · · · · · · · · · · ·	1
Security statement · · · · · · · · · · · · · · · · · · ·	
To ensure the safe driving ······	
Other safety information · · · · · · · · · · · · · · · · · · ·	2
Preparation before using the system	_
■ The method of Power on and off	3
Disc insert and remove	
■ The method of Disc insert · · · · · · · · · · · · · · · · · · ·	
■ The method of Disc remove · · · · · · · · · · · · · · · · · · ·	3
Navigation	
Navigation	
Quick Start · · · · · · · · · · · · · · · · · · ·	
Part - 1Getting Started · · · · · · · · · · · · · · · · · · ·	5
Touch Gestures · · · · · · · · · · · · · · · · · · ·	5
Using Touch Gestures in Menu Pages · · · · · · · · · · · · · · · · · · ·	6
The Map View · · · · · · · · · · · · · · · · · · ·	
The Control Bar	
The Search Button	
The Volume Button	
The Last Page Accessed Field / Map View Button	6
The Main Menu Button The Status Bar	6
The GPS Signal Strength Indicator	0
The Current Speed indicator	
The Clock Display	
The Rotation Mode Button and Menu	7
The Panning Mode Button	7
The 2D Mode Button · · · · · · · · · · · · · · · · · · ·	7
The 3D Mode Button	7
The Show North Button · · · · · · · · · · · · · · · · · · ·	
The Select Place On Map Button	
The Smart Zoom Button and Multi-zoom Menu · · · · · · · · · · · · · · · · · · ·	7
The Block View / View Preset 1 Button*	8
The Area View / View Preset 2 Button* · · · · · · · · · · · · · · · · · · ·	
The City View / View Preset 3 Button*	8
The Auto Zoom Button · · · · · · · · · · · · · · · · · · ·	
Map View Location Icons and Buttons · · · · · · · · · · · · · · · · · · ·	8
Your Current Location Icon · · · · · · · · · · · · · · · · · · ·	8
The No GPS Signal Location · · · · · · · · · · · · · · · · · · ·	8
Your Current Location Finder Button · · · · · · · · · · · · · · · · · · ·	8
The Start Point Icon	8
The Start Point Name Button The Destination Icon	g
The Destination Icon The Destination Name Button	
The Via Point Icon · · · · · · · · · · · · · · · · · · ·	9
The Via Point Name Button	9
Additional Via Points Icon	9

The Map Selection Point Name Button · · · · · · · · · · · · · · · · · · ·	0
The Favorite Place Point Icon · · · · · · · · · · · · · · · · · · ·	9
The Favorite Place Point Name Button	9
The Search Result Point Icon	9
The Search Result Name Point Button · · · · · · · · · · · · · · · · · · ·	10
Page View Buttons and Icons	10
The Inactive Route Icon.	10 10
The Pause/Resume/Record Route Button · · · · · · · · · · · · · · · · · · ·	10
The Favorite Place / Priority Favorite Place Button	10
The Map Locator Button	10
The Home Icon · · · · · · · · · · · · · · · · · · ·	10
Part 2: Using the Application · · · · · · · · · · · · · · · · · · ·	11
Using Search	11
Defining Search Categories · · · · · · · · · · · · · · · · · · ·	11
Selecting State	11
Using the Letter/Number/Symbol Toggle Button Using the What Field	11
Using the Where Field · · · · · · · · · · · · · · · · · · ·	12 12
How to Delete a Single Space · · · · · · · · · · · · · · · · · · ·	12
How to Clear the Search Fields	12
How to Get a Complete List of Search Results	12
How to Narrow Your Search Results and View Their Details	12
How to See a Search Result in Map View	12
How to Reveal the Keyboard · · · · · · · · · · · · · · · · · · ·	13
How to Use the Location Details / Route Planning and Options Page · · · · · · · · · · · · · · · · · · ·	13
You Can Get to this Page in a Number of Ways	13
Using the Location Details Bar	13
Using the Route Planning Bar	13
Using the Via Point Order Bar	13
Using the Place Bar · · · · · · · · · · · · · · · · · · ·	14
Getting out of this Page	14
Creating Smart Zoom Menu Presets	14
Restoring Defaults · · · · · · · · · · · · · · · · · · ·	15
Using the Main Menu · · · · · · · · · · · · · · · · · · ·	15
How to Get to the Main Menu and Where I Can Go from There · · · · · · · · · · · · · · · · · ·	15
Using Take Me Home	15
Using Route Options · · · · · · · · · · · · · · · · · · ·	16
Getting to the Trip, Dashboard and Directions Page·····	16
Using the Current Trip Status and Control Bar · · · · · · · · · · · · · · · · · · ·	16
Using the Current Route Details Display Bar	16
Using the Route Planning Bar · · · · · · · · · · · · · · · · · · ·	17
Using the Via Point Order Bar · · · · · · · · · · · · · · · · · · ·	17
Using the Place Bar · · · · · · · · · · · · · · · · · · ·	18
Using the Route Options Bar	18

Using Directions · · · · 19
Using Favorites20
Creating a Favorite Place
Creating a Favorite Route · · · · 20
Getting to the Favorite Places and Favorite Routes Pages
Using Favorite Places 21
Using Favorite Routes 21 Using History 22
Getting to the Destinations and Trip Log Pages
Using Destinations
Using the Trip Log
Creating Settings23
Getting to the Settings and About Page
Using the Settings Page
Selecting Your Voice
Selecting Your Distance and Speed Units
Restoring the Factory Settings
Using the About Page25
About
Ford Custom POI 25 MapmyIndia Maps End User License Agreement 26
The function description and the AV operation
The front panel schematic
The front panel schematic 29 The function description of the front panel part 30 The function description of steering wheel control in Trend , Trend+ , Titanium ,and Titanium + 31 ■ [USB] operation flow chart 33 [USB] operation description 35 MP3 Player 35 MP4 Player 35 ■ [iPod] [Bluetooth] operation flow chart 37 [iPod] operation description 38 [Bluetooth] operation flow chart 39
The front panel schematic 29 The function description of the front panel part 30 The function description of steering wheel control in Trend , Trend+ , Titanium ,and Titanium + 31 ■ [USB] operation flow chart 33 [USB] operation description 35 MP3 Player 35 MP4 Player 35 ■ [iPod] [Bluetooth] operation flow chart 37 [iPod] operation description 38 [Bluetooth] operation description 38 ■ [Phone] [Radio] operation flow chart 39 [Phone] operation description 41
The front panel schematic 29 The function description of the front panel part 30 The function description of steering wheel control in Trend , Trend+ , Titanium ,and Titanium + 31 ■ [USB] operation flow chart 33 [USB] operation description 35 MP3 Player 35 MP4 Player 35 ■ [iPod] [Bluetooth] operation flow chart 37 [iPod] operation description 38 ■ [Phone] [Radio] operation flow chart 39 [Phone] operation description 41 [Radio] operation description 42
The front panel schematic 29 The function description of the front panel part 30 The function description of steering wheel control in Trend , Trend+ , Titanium ,and Titanium + 31 ■ [USB] operation flow chart 33 [USB] operation description 35 MP3 Player 35 MP4 Player 35 ■ [iPod] [Bluetooth] operation flow chart 37 [iPod] operation description 38 [Bluetooth] operation description 38 ■ [Phone] [Radio] operation flow chart 39 [Phone] operation description 41
The front panel schematic 29 The function description of the front panel part 30 The function description of steering wheel control in Trend , Trend+ , Titanium ,and Titanium + 31 ■ [USB] operation flow chart 33 [USB] operation description 35 MP3 Player 35 MP4 Player 35 ■ [iPod] [Bluetooth] operation flow chart 37 [iPod] operation description 38 ■ [Phone] [Radio] operation flow chart 39 [Phone] operation description 41 [Radio] operation description 42 ■ [Sound] [Clock] setting operation flow chart 43
The front panel schematic 29 The function description of the front panel part 30 The function description of steering wheel control in Trend , Trend+ , Titanium ,and Titanium + 31 ■ [USB] operation flow chart 33 [USB] operation description 35 MP3 Player 35 MP4 Player 35 ■ [iPod] [Bluetooth] operation flow chart 37 [iPod] operation description 38 Bluetooth] operation description 38 ■ [Phone] [Radio] operation flow chart 39 [Phone] operation description 41 [Radio] operation description 42 ■ [Sound] [Clock] setting operation flow chart 43 [Sound] setting operation description 44 ■ [Display] setting operation flow chart 45
The front panel schematic 29 The function description of the front panel part 30 The function description of steering wheel control in Trend , Trend+ , Titanium , and Titanium + 31 ■ [USB] operation flow chart 33 [USB] operation description 35 MP3 Player 35 MP4 Player 35 ■ [iPod] [Bluetooth] operation flow chart 37 [iPod] operation description 38 ■ [Phone] [Radio] operation flow chart 39 [Phone] operation description 41 [Radio] operation description 42 ■ [Sound] [Clock] setting operation flow chart 43 [Sound] setting operation description 44 ■ [Display] setting operation flow chart 45 [Display] setting operation description 46
The front panel schematic 29 The function description of the front panel part 30 The function description of steering wheel control in Trend , Trend+ , Titanium ,and Titanium + 31 ■ [USB] operation flow chart 33 [USB] operation description 35 MP3 Player 35 MP4 Player 35 ■ [iPod] [Bluetooth] operation flow chart 37 [iPod] operation description 38 Bluetooth] operation description 38 ■ [Phone] [Radio] operation flow chart 39 [Phone] operation description 41 [Radio] operation description 42 ■ [Sound] [Clock] setting operation flow chart 43 [Sound] setting operation description 44 ■ [Display] setting operation flow chart 45

 [Info] setting operation description
 48

 ■ Standby interface
 48

Appendix

■ About LCD Screen	 	 50 50 50 50
Trouble shooting		
		· · · · · · · · · · · · · · · · · · 51
Common issues · · ·	 	 · · · · · · · 51
■ Navigation·····	 	
Specification		
Universal · · · · · · · · · · · · · · · · · · ·	 	 53 53
FM Tuner Section · · · · ·		
AM Tuner Section · · · · ·		
Installation Steps		
matanation oteps	 	

Important safety information

Before using this navigation system, be sure to read and understand the following security information carefully, while the manual with the car to carry, as a reference for operating procedures and safety information.

Warning

- ★ Do not install or repair your navigation system yourself. The installation or maintenance of this navigation system by personnel who have not been trained by electronic equipment and auto parts may result in electric shock or other hazards.
- ★ National regulations prohibit viewing of video and operating navigation systems while driving a vehicle for the safety of others and others. Do not watch the video and operate the navigation system while driving the vehicle.
- ★ It is strictly forbidden for others to use the system unless they have read and understood the instruction manual.
- ★ It is forbidden to use the navigation system on the way to a hospital, police station or similar.
- Please pay special attention to all the precautions in this manual and strictly follow the operating instructions.
- ★ Do not make the navigation system contact with liquid substances, otherwise it will lead to electric shock, and may cause damage to the navigation system, overheating and smoke.

Security statement

- The navigation function of the navigation system (and the optional reversing camera function) can only be used as an assistive tool when driving your vehicle. It does not mean that you can distract, be careless or lose your judgment when driving your vehicle. The resulting security incidents, we not assume any legal responsibility;
- The routes and navigation information displayed by this system are for informational purposes only and may not accurately reflect the latest approved routes, road conditions, one-way lines, road closures or traffic restrictions;
- The traffic restrictions and recommendations in the current implementation must take precedence over the information given by the navigation system. Therefore, please be sure to comply with the current traffic restrictions, even when the navigation system provides the opposite traffic advice;
- The map data stored on the TF card belongs to the intellectual property of the map supplier and the map supplier will be responsible for such content.

Warning

Do not install this navigation system if one of the following conditions is true:

- ★ It may obstruct the driver's sight;
- ★ It may affect the vehicle operating system or safety performance, including airbags, warning lights and other warning lights.

※ Note

- Failure to enter an accurate place name may cause the navigation system to provide inappropriate routing and navigation instructions;
- ☆ Do not expose this product to moisture;
- ☆ If the battery is powered off or discharged, it will cause the memory in the system to be cleared and must be reprogrammed.

To ensure the safe driving

- Must comply with safe driving regulations and existing traffic rules;
- If you operate this navigation system (and the optional reversing camera function) which will distract you from the safety of driving the vehicle, please do not operate;
- If you want to perform system operation by viewing the display, please park the vehicle in a safe place and then operate it:
- Do not set the volume of the navigation system too high, otherwise you cannot hear the traffic outside the vehicle and emergency rescue signal:
- For safety reasons, you will not be able to operate certain functions of the system while the vehicle is running. Unless the vehicle is stopped or parking brake;
- Please be sure to take a good seat belt when driving the vehicle, or in the event of a car accident, it will bring you serious harm:
- Please do not wear a headset while driving a vehicle:
- In order to avoid car accident and to avoid possible violations of applicable law, please do not use the system for other purposes other than navigation during driving;
- In some areas, the driver or passenger in the vehicle viewing the image of the display may be illegal. These regulations should be observed where applicable;
- The system can detect whether the vehicle parking brake is in use, and will prohibit you to watch the image on the screen during the driving process;
- Part of the menu in the navigation system can not be operated during the vehicle running, either do part of the media function.
 To view the images on the front display, please park the vehicle in a safe place and park the vehicle.

Other safety information

- To avoid battery depletion, please be sure to start the engine when using the system, otherwise the use of the system may cause the battery to run out:
- If the product does not work properly, please consult the manufacturer's customer service department:
- The final interpretation of this product manual is owned by the manufacturer.

Preparation before using the system

Methods of power on and off

Turn the vehicle ACC to ON or start the engine, the system power automatically is connected and started, after a few seconds the following prompt box appears:

SAFETY WARNING Viewing the screen while driving is dangerous. For the safety of you and others, do not operate this product while vehicle is in motion. The map may not reflect the latest road conditions, Please use this product under all the traffic regulations and rules apply

After a few seconds, it will automatically enter the interface of last shutdown, and turn the ACC to OFF or turn off the engine, the power is turned off. The system automatically saves the current media page, the next boot will enter the media page.



- ★ For the sake of safety, it is designed that complicated operations such as destination setting can not be set up when driving the vehicle:
- Please stop the vehicle in a safe place, and operate the system after parking brake. The driver should not operate during the driving.



Note:

When the speed is greater than 8Km / h, the system will pop up safety tips;

When the speed is less than 8Km / h, the prompt will automatically disappear.

Navigation

Quick Star

Simple Search and Navigation

You've now started the app and want to get to a certain address. Here's a quick, super-basic way to start navigating immediately. Finding and Navigating to a Destination







- Tap the Search button on the Control Bar.
 Enter the address in the What field.
- Tap the Get Search Results button.
- Tap on the Search Result.
- Tap Navigate To and you will be automatically guided from your present GPS location to your selected destination.

Part 1 Getting Stared

Or: What the Heck Do All These Icons, Buttons and Fields Mean?

At this point you've probably already opened the app, eagerly tapped several buttons and are now staring blankly at a bunch of unfamiliar icons. Relax. This is the part where we show you what all the nifty little buttons, icons, bars and fields mean. We'll also go through and define some basic terminology (with pictures!) to make things easier to understand.

Touch Gestures

Using Touch Gestures in Map View
Use your fingers to manipulate the map and
page views in the app.



Selecting an Item: Tap the screen surface once with a fingertip to select a button on the Control Bar, a map icon, etc.



Panning the Map: Move or quickly brush your fingertip across the screen surface to pan across the map.



The Intertia Pan feature enables your pan come to a smooth, gradual stop as opposed to an unnatural abrupt one.

Zooming In: Touch and continue pressing a point on the map with a fingertip to zoom in the view.

Using Touch Gestures in Menu Pages

Selecting, Deselecting and Toggling an Item: Tap the screen surface once with a fingertip to select a button, tab, list, deselect or toggle an.



Scrolling a Page: Move or quickly brush your fingertip up and down the screen surface to scroll up and down a page.





The Intertia Pan feature enables your scroll to come to a smooth, gradual stop as opposed to an unnatural abrupt one.

The Map View

This is the first screen you'll see once the app starts. Your device GPS will tell the app where you're at and you'll see your location. This is the app's default start screen and it's called Map View.

The Control Bar



The GPS Signal Strength Indicator

Located along the bottom of your screen, the Control Bar Features the Search button, the Volume button, the Last Page Accessed field and the Main Menu button. It is combined with the Status Bar and features the GPS Signal Strength Indicator, the Current Speed Indicator and the Clock display.



The Control / Status Bar (In Landscape Mode)

The Search Button: Tapping the Search button takes you immediately to the Search page. The Search button is always present on the Control Bar no matter where you are in the app. Tap it from anywhere in the app to go directly to the Search page. You can Instantly return to the Map View by tapping the Close tab in the upper right corner of the Search page

The Volume Button: The volume buttons enables you to adjust the navigation volume

The Last Page Accessed Fled / Map View Button: This field displays the tappable menu category button of the last Main Menu category page you accessed. Tapping it will take you to that menu category page.

When you are in a Main Menu category page, the Last Page Accessed field switches the Map View button which takes you instantly back to your previous Map View.



This is a great tool for toggling quickly between the current Main Menu page and Map View.

The Main Menu Button. Tap the Main Menu button to access the Main Menu page where you can access the Take Me Home, Route Options, Favorites, History and Settings buttons. Return to the Map View by tapping the Map View button on the Control Bar or exit the application completely by tapping the Exit Application button on the Control Bar.

The Status Bar The Status Bar features the GPS Signal Strength indicator, the Current Speed indicator and the Clock display.

The GPS Signal Strength Indicator. This displays your Device's GPS signal strength. Three yellow bars indicate the maximum GPS signal strength (within a 5 meter accuracy). Fewer yellow bars indicate a progressively weaker, less accurate, GPS signal. Three red bars indicate the absence of a usable GPS signal.




The Current Speed indicator. This icon indicates your vehicle's current speed.



The Clock Display. This one shows you the current time.

The Smart Orientation Button and Menu



Tap the Smart Orientation Menu button once to access the Smart Orientation menu.

The Rotation Mode Button. Tap the Smart Orientation Menu button once to access the Smart Orientation menu. Tap the Rotation Mode button to toggle between Panning and Rotation modes.

The Panning Mode Button. Tap the Smart Orientation Menu button once to access the Smart Orientation menu. Tap the Panning Mode button to toggle between Panning and Rotation modes.


The 2D Mode Button. Tap the Smart Orientation Menu button once to access the Smart Orientation menu. Tap the 2D button once to toggle between a two-dimensional (aerial) map view and a three dimensional (depth-perspective) map view.

The 3D Mode Button. Tap the Smart Orientation Menu button once to access the Smart Orientation menu. Tap the 3D button once to toggle between a three-dimensional (depth-perspective) map view and a two dimensional (aerial) map view.

The Show North Button. Tap the Smart Orientation Menu button once to access the Smart Orientation menu. Tap the Show North button to instantly rotate your map view so that north is at the top of your screen.

The Select Place On Map Button. Tap the Smart Orientation Menu button once to access the Smart Orientation menu. Tap the Select Place On Map button, then press and hold any point on the map. A street address, street name or GPS coordinates will appear in the Map Selction Point Name button. Tap on the Map Selction Point Name button to view its Details /Route Planning and Options Page where you can view the locations full information, navigate to it, add it as a destination, set it as your start point, find the closest point of interest, add it to your favorites or set it as home. Close the Details / Route Planning and Options Page by tapping the Close tab.





In the Map View mode, tap the Smart Zoom button once to access the basic Zoom In / Zoom Out function. Tap or continuously press the Plus button to zoom in for a more detailed map view. Tap or continuously press the Minus button to zoom out for a wider map view. Tap on the Smart Zoom button again to access the Multi-zoom menu.

The Block View / View Preset 1 Button*.
Once you're inside the Multizoommenu, tap on the Block View / View Preset 1 button to instantly switch the current map view of your present GPS location to an even closer 3D view of a block within a city, town or village around your GPS location. All street names are displayed.

The Area View / View Preset 2 Button*. When you're in the Multizoom menu, tap on the Area View / View Preset 2 button to instantly switch the current map view of your present GPS location to a closer 3D view of an area, or neighborhood within a city, town or village around your GPS location. Main thoroughfare and highway names are displayed.

The City View / View Preset 3 Button*. From the Multi-zoom menu, tap on the City View / View Preset 3 button to instantly switch the current map view of your present map view to a broad overview of your GPS location. You'll see the entire city, town or village and its surrounding settlements. Main highway and road names leading to and from the locations are displayed.



Learn how to create custom view presets in the Creating Smart Zoom Menu Presets section.

The Auto Zoom Button. After you've accessed the Multi-zoom menu, tap on the Auto Zoom button to switch the map view of your current GPS location back to the 3D/2D Auto Zoom View. The Auto Zoom View function is the default map view mode, which is essentially a relatively close 3D street view that switches automatically to a 2D aerial view when you approach a large intersection or roundabout (for better navigating clarity), and then switches back to the 3D view once you've passed it.

Map View Location Icons and Buttons



Your Current Location Icon. This icon represents your current GPS location in Map View.



The No GPS Signal Location. This icon represents a current lack of GPS signal. It signifies the last point on the map that the application registered your GPS signal.



Your Current Location Finder Button. Any time you are away from your current GPS location in Map View, the Current Location Finder button appears in the middle of the lower half of the screen. Tap on it once to instantly see your current location in Map View.



The Start Point Icon The Start Point Name Button

The Start Point Icon. The Start Point icon represents your trip starting point in Map View. Tapping the Start Point icon once transforms it into the Start Point Name button. You can tap on the map to return the Start Point icon.

The Start Point Name Button. The Start Point Name button shows your trip starting point's name in Map View. Tapping the Start Point Name button takes you to the item's Details / Route Planning / Options page. Tap the Close tab to return to the Start Point Name button in Map View. You can tap on the map to return the Start Point icon.



The Destination Icon The Destination Name Button

The Destination Icon. The Destination icon represents your trip destination in Map View. Tapping the Destination icon once transforms it into the Destination Name button. You can tap on the map to return the Destination icon.

The Destination Name Button. The Destination Name button shows your trip destination's name in Map View. Tapping the Destination Name button takes you to the item's Details / Route Planning / Options page. Tap the Close tab to return to the Destination Name button in Map View.

You can tap on the map to return the Destination icon

The Via Point Icon

New Friends Colony

The Via Point Name Button

Additional Via Point Icon

The Via Point Icon. The Via Point icon represents a programmed stop along your trip route in Map View. Tapping the Via Point icon once transforms It Into the Via Point Name button. You can tap on the map to return the Via Point icon.

The Via Point Name Button. The Via Point Name button shows your trip Via Point's name in Map View. Tapping the Via Point Name button takes you to the Item's Details / Route Planning / Options page. Tap the Close tab to return to the Via Point Name button in Map View. You can tap on the map to return the Via Point icon.

Additional Via Points Icon. The Additional Via Point icon represents additional programmed stops along your trip route in Map View. The numbers increase incrementally and chronologicelly as you add Via Points. Tapping the Via Point icon once transforms it into the Via Point Name button. You can tap on the map to return the Via Point Icon.



The Map Selection Point Icon The Map Selection Point Name Button

The Map Selection Point Icon. The Map Selection Point icon represents a location you've chosen by tapping the Map Selection Point button in the Smart Orientation menu and pressing a point on the map in Map View. Tapping the Map Selection Point icon once transforms it into the Map Selection Point Name button. You can tap on the map to return the Map Selection Point icon.

The Map Selection Point Name Button. The Map Selection Point Name button displays the name and location of the map point you've chosen by tapping the Map Selection Point button in the Smart Orientation menu and pressing a point on the map in Map View. Tapping the Map Selection Point Name button takes you to the item's Details / Route Planning / Options page. Tap the Close tab to return to the Map Selection Point Name button In Map View. You can tap on the map to return the Map Selection Point Icon.





The Favorite Place Point Icon The Favorite Place Point Name Button

The Favorite Place Point Icon. The Favorite Place Point icon represents the location of a Favorite Place in Map View that has not yet been defined as Start Point, Destination, Via Point or Home. Tapping the Favorite Place Point Icon once transforms it into the Favorite Place Point Name button. You cen tap on the map to return the Favorite Place Point icon.

The Favorite Place Point Name Button. The Favorite Place Point Name button shows you the name and the location of the Favorite Place In Map View. Tapping the Favorite Place Point Name button takes you to the item's Details / Route Planning / Options page.

Tap the Close tab to return to the Favorite Place Point Name button in Map View. You can tap on the map to return the Favorite Place Point icon.



If you choose any of the options in the Route Planning Bar (Navigate To, Add As Via Point, Add as Destination, Set As Start on the Details / Route Planning / Options page, the Favorite Place Point Name button will change Into the corresponding type of button once you're back in Map View.





The Search Result Point Icon. The Search Result Point Name Button

The Search Result Point Icon. The Search Result Point icon represents a search result's location in Map View that has not yet been defined as a start point, destination, via point or home. Tapping the Search Result Point icon once transforms it into the Search Result Point Name button. You can tap on the map to return the Search Result Point icon.

The Search Result Name Point Button

The Search Result Point Name button displays your search result's location and name in Map View. Tapping the Search Result Point Name button takes you to the search results's Location Details / Route Planning and Options page.

Tap the Close tab to return to the Search Result Point Name button in Map View. You can tap on the map to return the Search Result Point icon.

Q

If you choose any of the options in the Route Planning Bar (Navigate To, Add As Via Point, Add as Destination, Set As Start on the search result's Location Detalls / Route Planning and Options paga, the Search Result.

Point Name button will change into the corresponding type of button once you're back in Map View.

Page View Buttons and Icons



The Active Route Icon

The Active Route Icon

The Active Route Icon on the Route Details bar indicates that your are currently, actively navigating that route (Active route details and options can be viewed by tapping the Route option in the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.)



The Inactive Route Icon

The inactive Route icon

The Inactive Route icon on the Route Details bar indicates that your are currently not navigating that route (Inactive route details and options can be viewed by tapping the Route option in the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.)



The Pause/Resume/Record Route Button. Tapping the Pause/ Resume/Record Route button on the Trip Display bar lets you pause and resume a navigation session (The Trip Display bar can be viewed by tapping the Route button In the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.) You can record and save any route you drive by first exiting any navigation sessions, then Route? Pause/Resume/Record Route.



The Priority Favorite Place Button

The Favorite Place / Priority Favorite Place Button

The Favorite Place button appears as a blueoutlined star next to any addrass when viawing it's details. You can tap on the Favorite Place button next to the addrass to turn it into a Priority Favorite Place which is now represented by a solid yellow star. This means that the address will now be placed at the top of your Favorite Places list. The Map Locator Button



The Map Locator Button

The Map Locator button is always displayed next to addresses, points of interest (POI) or GPS coordinates in both the summarized info and fully-detailed info display modes. Tap on the Map Locator button to instantly view that item's location in Map View.




The Home Icon


The Home icon is located next to an address in both the summarized info and fully-detailed info display modes and it represents the item that you've designated as Home. This can be your actual home address, your work location, your hotel while on holiday, etc. You can set an address as home by tapping the Set as Home button on its Details / Route Planning / Options page. You need to have this option set to use the Take Me Home button in the Main Menu.

Part 2 Using the Application

Or What happens when I press this?

Using Search







The Cancel Button (In Landscape)

To return to the Map View, tap Close button in the upper right corner.

Defining Search Categories



The Search Category is set by default to All. By tapping on the Search Category button, you can toggle between Streets, POI, Lon/Lat and all.

Selecting State



The default search state is the one your Map View is currently displaying. Tap the Select state button to go to the Select state page. Tap on the specific state you want to search. Tap the Close tab to save your selection and go back to the Search page.

Using the Letter/Number/Symbol Toggle Button



Tap the Letter / Number / Symbol Toggle button to toggle the keyboard inputs between letters, numbers and symbols.

Using the What Field



Tap in a name, street, address, POI or longitude coordinate in the What field using the keyboard. A suggested result will appear in the Suggested Result area automatically as you type.

Using the Where Field



Tap in a city or town or latitude coordinate in the Where field using the keyboard to narrow your search even further Delhi.

How to Delete a Single Space



Tap the Delete Space button to delete a single letter, number or space in either the What or Where fields.

How to Clear the Search Fields



Tap the Clear Field button (x) in the What or Where fields to delete the entire contents of either the What or Where field.

How to Get a Complete List of Search Results



Tap the Get Search Results button at any point in your search to hide the keyboard and display a complete list of search results.

How to Narrow Your Search Results and View Their Details



While viewing the results list, you can narrow your search even further by tapping the Search Category button to toggle between Streets, POI, Lon/Lat and All. Tapping directly on a Search Result will show its Location Details / Route Planning and Options page.

How to See a Search Result in Map View



Tap on the Map Locator button to instantly view your search result's location as a Search Result Name Point button in Map View.

How to Reveal the Keyboard



As your search results are being displayed, tap on the What or Where field to reveal the keyboard again.

How to Use the Location Details / Route Planning and Options Page

You Can Get to this Page in a Number of Ways

By tapping a Map View Location Name button or a Location Result on any page in the app, it will take you to the Location Details / Route Planning and Options page.

For example: From Map View: Location Icon ® Location Name Button ® Location Details / Route Planning and Options page or...



From the Search page: Search Result ® Location Details / Route Planning and Options page or...

From Favorites: Main Menu/ Control Bar®
Favorites ® Location ® Location Details / Route
Planning and Options page... etc.

Using the Location Details Bar



The Location Details bar displays your location's full address, POI icon, GPS coordinates and other details (if available) like phone numbers. Map Locator ® Location in Map View.

Using the Route Planning Bar

ROUTE PLANNING



Depending on whether your selected location is undefined, previously defined (as a Destination, Start Point, Via Point or an undefined Search Result or Map Location Point), or if it is already part of a currently active or saved route, the Route Planning bar presents you with a variety of active and inactive buttons:

Navigate To: instantly begins guiding you to the selected location from your current GPS location. Remove from Trip: removes the selected location from your current route.



This option appears only after the selected location has been set as a start point, via point or destination.

Add as Via Point: adds the selected location to your current route as a via point.



This option appears only when you are adding a third (or higher) location to your trip route.

Add as Destination: sets the selected location as your destination or replaces a previous destination with the selected location.

Using the Via Point Order Bar

VIA POINT ORDER

Move before previous

Move after next



This bar only appears on the Location Details / Route Planning and Options page when there are three ormore locations on your trip route. Move Before Previous: moves the selected location towards the beginning of your journey, i.e. just before the location preceding it.



Moving the selected location before your start point will make the selected location your new start point.

Move After Next: moves the selected location towards the end of your journey, i.e. just after the location following it.



Moving the selected location after your destination will make the selected location your new destination.

Using the Place Bar

PLACE



Depending on whether your selected location is nameless, named, categorized, a favorite or set as home, the Place bar will be present with a number of buttons:

Find Closest POI: Find the closest Points Of Interest (POI) to your selected location. Find Closest POI ® C losest POI page - where nearby Points of Interest (hotels, petrol stations, restaurants, etc.) are automatically listed according to their proximity to your selected location. Tap on a POI Location to go to its Location Details / RoutePlanning and Options page. To further refine your POI results:

Category ® Select Category page where all POI are selected by default. Individually select and deselect or Deselect All categories. Close to go back to the, now modified, Closest POI page. Select Category will now reflect your POI selection preference (i.e. Petrol Station, Multiple, All, etc.)

Categories: Designate your selected location as Business, Family orfriends



- You can select multiple categories, one or none.
- This option only appears after you've saved a location as a Favorite.

Add Name/ Rename: Add or rename and save a name for your selected location. Add Name or Rename → Input Keyboard → Tap in a new name → Save → Location Details / Route Planning and Options page. The new name appears in bold lettering as the top line of your selected favorite location.



This option appears only after you've saved a location as a Favorite.

Add to Favorites: Add the selected location to your list of Favorites. Remove from Favorites: Remove the selected location from your list of Favorites.



This option appears only after you've saved a location as a Favorite.

Set as Home: Set the selected location as Home.

Remove Home Address: Remove the Home designation from the selected location.



This option appears only after you've saved a location as Home.

Getting out of this Page



To exit the Location Details / Route Planning and Options page: Map Locator ® Map View or Close® which takes you back to wherever it is that you came from (e.g., Route, History, Favorites, Map View, etc.)

Creating Smart Zoom Menu Presets
You can create up to three custom View Presets.
First, in the Map View, zoom, tilt and pan the
map view to your liking. Second, tap the Smart
Zoom button twice to access the Multi-zoom
Menu end press and hold the 100, 10 or 1 button
for a few seconds.



The Save View bar will appear at the bottom of the screen asking you to confirm or disregard your choice. Tap the right sign button to confirm your choice or the Close button to exit without saving.

Restoring Defaults



The Restore Defaults Button:
To restore the default City, Area and Block
Views go Settings →Restore Defaults → Yes



Selecting the Restore Defaults option will not only reset your Multi-zoom Menu, but will restore everything in the application to its original, factory setting.

Using the Main Menu: How to Get to the Main Menu and Where I Can Go from There.



Open the Main Menu Page by tapping the Main Menu button (). From here you can continue to the five main menu buttons (Take Me Home, Route, Favorites, History & Settings) or tap the Map View.


Search or Close Application buttons on the Control Bar to go the corresponding screens and pages.

Using Take Me Home



Go Main Menu → Take Me Home at any time to be guided from your current location to your previously designated Home location. If you are in an active navigation session, the Cancel Current Route window will appear. Select Yes to immediately start being guided to your Home location.

Using Route Options



The Trip page bars, buttons and displays covered in the Using Route Options section are desribed as they would look if you've previously set a route with a Start Point, Via Point and Destination. If you need to set a route and don't know how, follow the the Quick Start and Simple Navigation Instructions

Getting to the Trip, Dashboard and Directions Page







Go Main Menu → Route → Trip page where you can view the Current Trip Status and Control bar, Current Route Details Display bar and the Route Options bar.

Go Main Menu → Route → Trip page → Left tab → Dashboard page Go Main Menu → Route → Trip page → Right tab → Directions page


Using the Current Trip Status and Control Bar



The Pause/ Resume/ Record Button

The Current Trip Status and Control bar on the Trip page displays your estimated travel time, estimated route distance, actual travel time and actual travel distance. You can pause your navigation session at any time by tapping the Pause / Resume / Record Route button. You can also use the Current Trip Status bar to record your driving when you are not in an active navigating session by tapping the Pause / Resume / Record Route button once. Tap it again to pause the recording of your drive.

Using the Current Route Details Display Bar




The Current Route Details Display bar on the Trip page shows you your start point, via points and destination. It also shows the estimated route distance and estimated travel time between each stop. The Active Navigation Indicator shows whether your navigation route is active (yellow) or inactive (white). By tapping the Map Locator button next a location you can instantly view the chosen location in the Map View.

By tapping the Map Locator button next to the Active Navigation indicator, Estimated Distance and Time Display, your entire route will be displayed as a 2D aerial map view. Tap on any Location on the Trip Page to access its Location Details / Route Planning and

Using the Route Planning Bar

Options page.





Here you can view your entire trip by stops and stages.

To see a location or portion of your route in Map View: Map Locator → Map View Tap on any Location to view its Location Details

Tap on any Location to view its Location Details / Route Planning and Options page to access the following.

ROUTE PLANNING

Navigate to

Remove from trip

Add as via point

Add as destination

Set as start

So, Location → Location Details / Route Planning and Options page Remove from Trip: removes the selected location from your current route.



This option appears only after the selected location hasbeen set as a start point, via point or destination. Add as Via Point: adds the selected location to your current route as a via point



This option appears only when you are adding a third (or higher) location to your trip route.

Add as Destination:

sets the selected location as your destination or replaces a previous destination with the selected location. Set as Start: sets the selected location as your start point.

Using the Via Point Order Bar

VIA POINT ORDER

Move before previous

Move after next

OK, we're still on the Location Details / Route Planning and Options page. Scroll down to the Via Point Order bar.

Move Before Previous: moves the selected location towards the beginning of your journey, i.e. just before the location preceding it.



Moving the selected location before your start point will make the selected location your new start point.

Move After Next: moves the selected location towards the end of your journey, i.e. just after the location following it.



Moving the selected location after your destination will make the selected location your new destination.

Using the Place Bar

PLACE



And we're still on the Location Details / Route Planning and Options page. Scroll down past the Via Point Order bar to the Place bar. Depending on whether your selected Location is nameless, named, categorized, a favorite or set as home, the Place bar will be present with a number of buttons:

Find Closest POI: Find the closest point of interest to your selected location. Find Closest POI → Closest POI page - where nearby Points of interest (hotels, petrol stations, restaurants, etc.) are automatically listed according to their proximity to your selected location. Tap on POI Location to go to its Location Details / Route Planning and Options page.

To further refine your POI results: Select Category → Select Category Page where all POI are selected by default. Individually select and deselect or Deselect All categories. Close to go back to the, now modified, Closest POI page. Select Category will now reflect your POI selection preference (i.e. Petrol Station, Multiple, All, etc.)

Categories ® Choose Categories page →
Business, Family or Friends. Now close
Location Details / Route Planning and Options
page.



This option appears only when you are adding a third (or higher) location to your trip route.



This option only appears after you've saved a location as a Favorite.

Add Name/ Rename: Add or rename and save a name for your selected location. Add Name or Rename → Input Keyboard → T ap in a new name → Save → Location Details / Route Planning and Options page. The new name appears in bold lettering as the top line of your selected Favorite Location.



This option only appears after you've saved a location as a Favorite.

Add to Favorites: Add the selected location to your list of Favorites. Remove from Favorites: Remove the selected location from your list of Favorites.



This option only appears after you've saved a location as a Favorite.

Set as Home: Set the selected location as Home. Remove Home Address: Remove the Home designation from the selected location.



This option only appears after you've saved a location as a Favorite.

Using the Route Options Bar





Location Details / Route Planning and Options page \rightarrow Close \rightarrow Trip page. Scroll down to the Route Options Bar \rightarrow Type and Avoidance \rightarrow Route Type page.

Here you can select either Fastest or Shortest Route.

The Avoid bar lets you choose one, several or all avoidance options: Highways, Toll Roads, Unpaved Roads and Ferries.



When available, a country or cityspecific avoidance bar will appear below the the Avoid bar.

Close → Route Options Bar ® Reverse Route to go back exactly the way you came. Your destination is now your start point and your start point is now your destination. Save Route saves your route to your list of Favorite Routes. Scroll down to the bottom of the Trip page.

Start Shop Demo will begin a simulated turn-by -turn navigation session in Map View.

From the Map View Control Bar, tap Route in the Last Page Accessed field to go beck to the Trip page.

Stop Shop Demo to stop the simulated turn-byturn navigation session in Map View From the Map View Control Bar, tap Route In the Last Page Accessed field to go back to the Trip page.

Delete This Route → Yes removes the current route as your active navigation route, but does not remove it from your Favorites.




Route → Trip page → Left tab → Dashboard page The Dashboard has no tappable buttons, but it tells you a lot of useful information. It features a speedometer, compass, altimeter, a precision GPS signal strength indicator and your current GPS coordinates.

Using Directions

Route → Trip page → Right tab → Directions page Here you can view your route directions as a list of turn-by-turn textual descriptions with corresponding descriptive icons in sequence, their corresponding Map View by tapping Map Locator next to them or





Individual Directional Description → Individual Directional Description Details page, which displays the descriptive icon, textual directional description, estimated time and distance to your next navigation instruction.

Map Locator ® Map View, where you can see the selected directional description or Next or Previous to view the next or previous directional description on its Individual Directional Description and Details page or Close to go back to the Directions page.





While in the Route pages, you can tap the Map View button on the Control Bar at any point to return to the Map View. Tap the Search button on the Control Bar at any point to go to the Search page. Tap the Main Menu button on the Control Bar at any point to return to the Main Menu.

Using Favorites

Creating a Favorite Place







From Search: Tap on any Search Result or Map View Location to view its Location Details / Route Planning and Options page. Scroll down to the Place bar and tap Add To Favorites.

From Map View → Location Icon → Location Name button → Location Datails / Route Planning and Options page. Scroll down to the Place bar and tap Add To Favorites.





Once you've created a route, you can save it as a Favorite Route: Main Menu → Route → Save Route

Getting to the Favorite Places and Favorite Routes Pages







Go Main Menu → Favorites → Places Go Main Menu → Favorites → Places → Right tab → Routes

Using Favorite Places

Here you can view your favorite places in the order that you saved them. You can bring a favorite to the top of the list by tapping the blue -outline star Favorite button, turning it into a solid-yellow star Priority Favorite button. You can toggle between the Favorite and Priority Favorite button by simply tapping on it.

Tap on Select Category to go the Select Category page where you can narrow your favorite places list according to Business, Family or Friends. Tap Close to go back to the Places page. The Select Category button will read All, Business, Family or Friends, depending on what you've chosen as your display criterion.

Tap on a Location itself to go to its Location Details / Route Planning and Options page.

Tap the Map Locator next to a favorite place to see it in Map View.

Using Favorite Routes



Tap on a Favorite Route to view it in the Route page where you can see the Route's Details Display bar, which shows you your start point, via points and destination. It also shows the estimated route distance and estimated travel time between each stop. The Navigation Indicator shows you that your route is currently inactive (white)

0:00

0_m

0

By tapping the Map Locator button next a location you can instantly view the chosen location in the Map View.

In Map View tap Favorites In the Last Page Accessed field on the Control Bar to go back to the Route Details Display bar on the Route page. By tapping the Map Locator button next to the Inactive Navigation Indicator, Estimated Distance and Time display, that stage of your route will be displayed as a 2D aerial map view.

In Map View tap Favorites in the Last Page Accessed field on the Control Bar to go back to the Route Details Display bar on the Route

page. Scroll down the Route page to the Options bar where you can make the favorite route your current route by tapping Set as Current Route.

You can remove the displayed route from your favorites by tapping Remove on the Options bar.

Tap on any Location on the Route page to access its Location Details / Route Planning and Options page.

Using History

Getting to the Destinations and Trip Log Pages








Go Main Menu → History → Destinations Go Main Menu → History → Destinations → Right tab → Trip Log

Using Destinations





View a list of all your destinations for the last 30 days. Tap on any destination Location to access its Location Details / Route Planning and Options page.

Using the Trip Log

The Current Trip bar shows you how far, long and the average speed at which you've travelled on your current trip.

The Trips bar lists (up to the past 30 days) the dates of your trips as Trip Date buttons that you can tap that will takes you each specific Trip Date Details page. Your total travelled distance and average speed for that date are displayed on the Trip Date button as well.





Tap on any Trip Date button to go to that date's Trip Date Details page where you can view Individual Trip Time bars. You can lock any trip by tapping the Lock button. This will keep the locked trip in your Trip Log while the other, unlocked ones, are erased automatically after 30 days. Tap on any Location or Route to view it's Location Details / Route Planning and Options page.



The Trip Time Bar

Export any trip as a KML file by tapping the Export as KML button. You can delete all of your Trip Logs, except of course the ones you've previously locked, by tapping Delete All Logs.



Please refer to view how to use the Location Details / Route Planning and Options page.

Creating Settings

Getting to the Settings and About Page








Go Main Menu → Settings → Settings Go Main Menu → Settings → Settings → Right tab → About

Using the Settings Page

Selecting Your Language





Select Language → Select Language page → Language

Selecting Your Voice




Select Voice → Select Voice page → Voice

The application contains 10 regional voices also apart from English and International languages. You can select any of the regional voices from this voice menu.

Selecting Your Distance and Speed Units





Select Units → Select Units page → Units

Restoring the Factory Settings





Restore Defaults ? Yes

Using the About Page


About

The About page displays Version, Serial Number, Copyright, Safety Agreement and Installed Content (Base Map, User Interface Language Packs, Voice, etc.) information.

Ford Custom POI











Every Ford custom POI has a nearby RSA (Road Side Assistance) number too. User can call (if needed) to nearby RSA in emergency situation. Ford Roadside Assistance Toll free number: 1800-209-7400, Alternate number 1800-103-7400

MapmyIndia Maps End User License Agreement

This End-User License Agreement (EULA) is a legal agreement between you (either an individual or a single entity) and CE INFO SYSTEMS PVT. LIMITED for the digital maps database and updates hereof that run navigation in associated hardware collectively the "MappyIndia Maps" or "Maps"). By installing or using the MappyIndia Maps, you agree to be bound by the terms of this Agreement. Use of the Maps without acceptance of this Agreement is unauthorized and not permitted.

- License Grant. CE INFO SYSTEMS PVT LIMITED grants you a nonexclusive license to use your purchased copy of the MapmyIndia Maps for your own purposes of accessing the map database and navigation by running the associated hardware and not for service bureau timesharing, or other similar purposes.
- 2. Limitations On Use. You are not permitted to copy, modify, decompile, disassemble, or reverse engineer any portion of the Maps.
- 3. Indemnity. You agree to indemnify, defend and hold free and harmless CE INFO SYSTEMS PVT LIMITED, including its licensors, assignees, subsidiaries, affiliated companies, and the respective officers, directors, employees, shareholders, agents, authorized dealers or sales agents, and representatives of each of them from and against any liability, loss, injury, demand, cost, expense, or claim of any kind of character, including but not limited to attorney's fees, arising out of (a) any use or possession of the Maps, or (b) any breach of any warranties or representations made by you in this Agreement or of your obligations under this Agreement.
- 4. Disclaimer of Warranty. CE INFO SYSTEMS PVT LIMITED does not make any warranties or representations, either express or implied, with respect to the Maps, without limiting the foregoing, CE INFO SYSTEMS PVT. LIMITED expressly disclaims any implied warranties of quality, performance, merchantability, fitness for a particular purpose or noninfringement.
- 5. Limitation of Liability. CE INFO SYSTEMS PVT LIMITED shall not be held responsible for any actual, anticipated or speculative loss of profit or direct, indirect, incidental, special, or consequential damages, including, without limitation, loss of revenue, data, or use incurred by you or any third party arising out of your use or possession of the Maps, whether in an action in contract or tort or based on a warranty, even if CE INFO SYSTEMS PVT. LIMITED has been advised of the possibility of such damages.

Warnings.

- A. Copies of the Maps reflect conditions as they existed at various points in time before your receipt of such copies. Accordingly, copies of the Maps may contain inaccurate or incomplete data or information due to inaccurate or incomplete source materials, the passage of time, road construction, changing conditions, and otherwise.
- B. Neither the Maps nor the Software include, analyze, process, consider or reflect any of the following categories of Information, i.e., neighborhood quality or safety; population density; availability or proximity of law enforcement, emergency, rescue, medical or other assistance; construction work, zones, or hazards; road and lane closures; various legal restrictions (such as vehicular type, weight, load, height and speed restrictions); road slope or grade; bridge height, width, weight or other limits; road, traffic or traffic facilities safety or conditions; weather conditions; pavement characteristics or conditions; special events; traffic congestion; or travel time.
- C. Maps are strictly meant for use in India and you are not allowed to export Maps or its copies anywhere outside India.
- 7. Transfer. This Agreement, including all rights, obligations and representations may be transferred to another individual or single entity, provided the same transfer includes the simultaneous transfer of the associated hardware in which the Maps are installed, and further provided that such other individual or single entity accepts all the terms of this Agreement. In the event such individual or single entity to which the Software is transferred does not accept the terms of this agreement, then the License herein automatically terminates. Further use of the Maps is unauthorized and not permitted.
- 8. Governing Law. This Agreement shall be governed by the laws of India without giving effect to its conflict of laws provisions. CE Info Systems Pvt. Limited Copyright Notice MapmyIndia Maps Copyright® 2015 CE Info Systems Pvt. Limited

All rights reserved. This document and the maps described in it are furnished under license and may be used only in accordance with such license. Information in this document is subject to change without notice and does not represent a commitment on the part of CE Info Systems Pvt. Ltd.

Disclaimer

MapmyIndia reserves all rights concerning the information containedherein. This document or any part thereof may not be reproduced, distributed, or translated into other languages in any way or form except with the written approval of MapmyIndia. This document is provided to the user on an 'as is' basis. Although maximum care was taken during preparation of this manual to provide accurate information and to avoid errors, some technical inaccuracies or editorial errors may occur, for which MapmyIndia accepts no responsibility. In the interest of improving the content of the document, MapmyIndia reserves the right to modify, amend or delete any part of the document at any time without prior notice. This is a generic version of the user manual. Some of the features listed here may vary on your device. In case of confusion, please contact us:

76 - Okhla Industrial Estate, Phase 3, New Delhi - 110020 Contact: +91-9999-333-223 Email: support@mapmyindia.com Web: www.mapmyindia.com





The function description of the front panel part

Touch panel

It displays a variety of different pictures, to click on the screen control menu, and select the control project.

Standby / restart / mute / volume control knob

- Adjust the volume output from the machine; clockwise rotation means volume increases, counterclockwise rotation means volume reduction;
 - Short press the knob to open / unmute;
- Long press the knob for 3 seconds, the display goes into the standby interface, once again press shortly which will release the standby and return to the current interface;
- Long press more than 3 seconds, the navigation system will restart.

Main menu shortcuts [HOME]

Except the reverse state, Bluetooth phone status, standby state, in any other page if you press this button, you can quickly switch to the main menu interface.

Return button [BACK]

Press this button to return to the previous menu interface.

Backward button [SEEK+]

In the multimedia playback mode, short press this button to select the next track, and long press this button for the fast forward; in listening to the radio state, short press will automatically search for the next available channel, and the long press needs to release the hand to stay on the available channel, otherwise it will continue to search.

Forward button [SEEK-]

In the multimedia playback mode, press this button to aelect the previous track, and long press this button for the rewind; in listening to the radio state, short press will automatically search for the previous available channel, and the long press needs to release the hand to stay on the available channel, otherwise it will continue to search.

Navigation functions shortcuts [NAVI]

Enter the GPS navigation shortcut, press this button to quickly switch to the GPS navigation mapping interface.

Backlight brightness adjustment button [DIMM]

- 1. Press this button to adjust the screen brightness, for the first time pressing the acreen brightness level is bright, followed by switching screen brightness to four brightness levels: bright, off the screen, dark, middle bright, and the default brightness level is middle bright.
- Long press 3 seconds to light off the screen, and press again to light up the screen again.

Bluetooth phone button [PHONE]

Before operating this button, you must first confirm that the car is connected to the phone. Press this button to enter the Bluetooth phone interface.

Multimedia switch button [MEDIA]

If you do not press the key to enter the current media interface, the default one will be directly into the FM, and then press this button to continue the switch of AM, MP3, video playback, iPod, Bluetooth music (Bluetooth music needs to confirm that the phone has been connected to Bluetooth).

Radio frequency scanning [SCAN]

Press this button in the radio interface to scan the radio frequency automatically.

Radio function shortcuts [FM/AM]

Enter the radio display shortcuts, and press this button to switch to the radio operating interface.

FM \ Previous and Next \ sound \ navigation control knob

- 1. When listening to the radio, you can rotate the knob to proceed the radio channel FM;
- After going into the GPS navigation interface, please rotate the knob to adjust the map to reduce and zoom:
- 3. Vertically short press this knob, you can quickly enter the sound settings interface;
- In multimedia playback state, rotate clockwise to the next song, rotate counterclockwise to the previous song.

Reset

The navigation system will be restarted.

The function description of steering wheel control in Trend, Trend+, Titanium .and Titanium +





- [M]: In the radio interface, short press to switch to a preset station, and long press to automatically search the radio station; In MP3, ipod, video and other interface, short press to enter next song, and long press means rewind; in the Bluetooth music interface, short press to enter next song, and long press means no function; In incoming call state, short press to answer the phone;
- [M] : In the radio interface, short press to switch to next preset station, and long press to automatically search the radio station; In MP3, ipod, video and other interface, short press to enter next song, and long press to fast forward; in the Bluetooth music interface, short press to enter next song, and long press means no function; In incoming call or answering the phone, short press to refuse or hang up the phone;
- [VOL+]: This button is to increase the volume; short press it to increase the volume +1, and long press to quickly increase the volume;

 [VOL-]: This button is to decrease the volume button; short press it to decrease the volume -1,
- and long press to quickly decrease the volume;
- [MODE]: This button is about the phone media function.

The function description and the AV operation

[USB] operation flow chart





[USB] operation description

MP3 player

Click on the [USB] button in [sources] function, to enter the USB MP3 user interface, as shown below:



- [Idea]: Press this button to play the previous song, and long press it to rewind.
- []]: Press this button to start playback, and press this button in the playback state to pause playback. And again press this button to resume normal playback.
- [>>]: Press this button to play the next song and press it to fast forward.
- [Mute]: Press this button to enter the silent mode, and then press it again to restore the original volume.
- [RPT-One]: It automatically repeat the currently playing clips, tracks.
- [Shuffle]: it randomly plays USB audio or video files.
- Note: In the case of not selecting [RPT-One] and [Shuffle], the system will be defaulted to auto list playback.
- [Folder]: Browse to play USB audio or video files.

Note

 Click the progress bar to display the time of the play time node selection.

MP4 player



- [TRACK 1/10]: The clip number of the currently playing.
- [02:30]: It displays the time that the USB is currently playing.
- [II]: After the USB is plugged in, press this button to start playback, and press the button in the playback state to pause. And again Press this button to resume normal playback.
- [I◄■]: Press this button to play the previous clip or track and press it to rewind.
- [>>|]: Press this button to play the next clip or track and press it to fast forward.
- [Mute]: Press this button to enter the silent mode.
- [Image]: Press this button to enter the video display and operation menu interface.
 As shown below:



[Full]: After you press this button, the screen displays full screen video interface.
Once again press the [Full] button, the screen displays the normal video interface.

(Note: it is related to the USB video format.)

[Set]: To adjust the video image color, contrast, tone, brightness. As shown below:



Press the [Folder] button, the screen as shown below:



Program browsing: press the [\blacktriangle][\blacktriangledown] button on the touch screen to browse the list of folders or files.

[Upper]: Press this button to return to the previous interface.

[1] 1/2 USB]: If you access the two USB devices, click this button to switch between the two USB devices arbitrarily; if you access a USB device, you can not switch it; if no USB device is accessed, this button will not be displayed. Note: If you use the encrypted USB, it will not be able to read. As shown below:




Note

 The AV (Audio & Video) formats and codec formats which the navigation supported are as follows:

supported are as follows:							
Audlo	File formats	codec f	ormats				
	AAC	A	vc				
	MP2	MP	EG				
	MP3	MPEG					
	FLAC	FLAC					
	APE	MonKEY					
	M4A	AAC					
	RA	Cooker					
Video	File formats	Video codec formats	Audio codec formats				
	AVI	XVID	MP3 AC3MP2				
	MP4	XVID	AAC				
	MPG	MPEG2	MPEG				
	RMVB	Realvideo	Cooker RAAC				

[iPod] [Bluetooth] operation flow chart:



[iPod] Operation description

Click the [iPod] in the [Sources] function to enter the iPod operation interface, as shown below:



- [| ress this button to play the previous track, and long press to rewind.
- []]: Press this button to start playback, and press it in the playback state to pause playback. And again press it to resume normal playback.
- [>>|]: Press this button to play the next track, and long press it to fast forward.
- [Mute]: Press this button to enter the silent mode, and then press it again to restore the original volume.
- [RPT]: Press this button to enter the list loop, and then click it again to enter the single loop.

[Shuffle]: It random plays ipod MP3 songs.

Note: In the case of neither selecting [loop] nor
[random], the system will be defaulted to
the automatic list loop.

[Folder]: Browse to play MP3 MP3 songs.

Press the [Folder] button to enter the following display:



Program browsing: press the $[\blacktriangle] [\blacktriangledown]$ button on the touch screen to browse the list of folders or files.

[Upper]: Press this button to return to the previous interface.

[Bluetooth] operation description

Click [Bluetooth] in the [Sources] to enter the Bluetooth interface, as shown below:





- [◄◄]: Press this button to play the previous track.
- [>]: In the case of connecting to the phone, press this button to start playing.
- []: Press this button in the playback mode to pause playback.
- [): Press this button to play the next track.

Note:

- Please match the Bluetooth before using this function. The Bluetooth and mobile phone player should support this function.
- After connected Android or iPhone to the Bluetooth of head unit, open the map in the phone to navigate. The head unit must be in Bluetooth Music page, then the car speaker can broadcast the phone navigation.
- After connecting mobile phone to Bluetooth and playing Bluetooth music head unit, then pull out or plug in the USB cable, there will be two phenomena as below.
- A. Bluetooth music of iPhone will pause, need to click the button to continue.
- B. Bluetooth music of Android phone will pause 2 seconds and then continue to play automatically.

[Phone] [Radio] operation flow chart





[Phone] operation description

Click the [Phone] button in the main menu, the interface is shown as below.



[Turn off]: in the case of Bluetooth connected, click this button, you can turn off the Bluetooth; If it is not connected, click [Turn on] button, you can open the Bluetooth of head unit.

[Pair]: Click this button to pair the Bluetooth of phone.

[Handfree]: Convert into the system calling status. [Handheld]: Switch to the phone answer.

Dial]: Dial out telephone or answer the calling.

[Records]: Click this button, the screen as shown below:



[Missed]: list of calls missed. [Received]: List of calls received.

[Dialed]: list of calls dialed

[Phone book]: Contacts stored on the phone. (device should support it)

[▲] And [▼]: view recent calls [⑤]: Press this button to return to the

[Phone] operation interface.

[Search]: Click above input field in the page, you can enter the Contacts to search for contacts as shown below:



Enter the relevant letter of contact name, will pop up the relevant contact information. And then click the " \ \ " key on the keypad, the keypad will be hidden, as shown below:





[Pair] operation description

Click [Pair] in the [phone] interface to enter the Bluetooth page as shown below.



There are two ways to make phone pairing.

 to search the name of the head unit by phone, click the corresponding device name on the phone screen to enter the password to pair;

click the "Device list" in the prompt box to enter the device list page, select the previous connected phone records to connect as shown below.





Click on the phone name on the device list to enter the device connection settings, you can choose "Primary device", "Connect", "Delete" and other setting options.

After connected to the "Pair", click the "Pair" button again, click "OK" button in the prompt box to disconnect.



[Radio] operation description

Click on the main menu of [Radio], enter the main interface of the radio. Receive the previous broadcasting station.



- Automatically displays the list of radio stations that are stored in the default channel.
- In tunnel, behind the mountain, the cracks in the building, etc.
 The place where the waves are easy to be blocked, receiving signal will be weak.
- Even if the list shows broadcasting station, according to the real situation of the current location and the radio waves, that sometimes can not receive the signal.



(Scan):

Search automatically to browse radio channel, keep in automatically radio channel for searching. [Searching manually]:

To select the radio station in need in the bottom of radio function interface.

If FM/AM want to switch from one mode to another one, please press the corresponding button.

Each mode can provide 10 pieces storage cell which can store in common radio station. To touch the radio frequency, can be listen this channel. If want to revise or set the cell of radio frequency, the operation is to be as below:


- To search in selecting of radio frequency.
- To select one of cell for 10 pleces of Cell, to press longer this cell in 2 seconds, the radio frequency in need will be stored, in this cell, It shows this radio frequency.
- [98.00MHz]: The frequency is playing in currently radio station.
- [FM1/FM2]: Press this button to select in stored FM station.
- [AM1/AM2]: Press this button to select in stored AM station.
- [Mute]: Press this button to enter Mute mode, press this button again, can back to previous volume.



 If due to disconnect the battery or blown off fuse and power outages, stored preset stations may be deleted.

[Sound] [Clock] setting operation flow chart

Main menu



[Sound] setting operation description

The pros and cons of sound effects are largely depends on the treble, bass mixing sound level. In fact, a variety of music and vocal programs in different sound level of the treble, bass combination will be the more pleasant. It is also important to keep the best balance between the left and right stereo channels as well as the front and rear sound levels.

As shown below:



[▲][▼]: It adjusts the sound balance between front and rear speakers.

[|]: It adjusts the sound balance between the left and right speakers.

Each time you press $[\triangle]$ or $[\nabla]$, $[\triangleleft]$ or $[\triangleright]$, the red bar will move one unit in the corresponding direction.

[つ]: Press this button to return to the previous operation interface.


[Surround off]: It is to raise the volume of the high and low frequency components at low volume so that the loudness ratio of the low, medium, and high parts remains the same as the loudness at high volume.



When you listen to a stereo record or broadcast, changing the left / right balance will increases the volume of a group of sounds while reducing the volume of another group of sounds.

ΕQ

Equalizer in the audio equipment is an electronic device that can adjust the amplification of the electrical signal of various frequency components separately. Through the adjustment of electrical signals at different frequencies, it compensate for the defects of the loudspeakers and sound fields, and compensate and modify various sound sources and other special effects. Ordinary Equalizer on the mixer can be adjusted only between high frequency, intermediate frequency, low frequency three frequency electrical signal.



[Classical]: Classical music also is improved in the high and low two parts, which mainly highlights the performance of musical instruments.

[Popular]: It requires that both the combination of vocals and instrumental music are very average, so the curve of the volatility is not great.


[Custom]: The user can adjust the equalizer according to their preferences.

Note: After setting the custom function, you can save the custom settings by long pressing this button.

[Reset]: Resets all equalizers.

[Clock] setting operation description


Press [Clock] button in the [Settings], you can adjust the system time through [▲]
[▼], as shown below:



[24 hour system]: You can set the system time to 12-hour or 24-hour [On] [Off].

[Display] setting operation flow chart

Main menu



[Display] setting operation description

Press [Display] button in [Settings], as shown below:



[Brightness]: In the boot state, the user can set the screen to among three brightness modes of [Dark] [Mid] and [Bri].

[Mode]: Click this button to set the navigation screen to [Day] or [Night].

[Key light intensity]: You can adjust the brightness

of the panel key light by [▲] or [▼] to keep the brightness in accordance to the other keys.

[Auto dim]:

When it is set to [On]:

[Auto headlight models]:

[Auto headlight]: [Day & Night mode] function can not be set manually. When the car in the dark environment, the system will automatically switches to the night mode, and the key light is on while the screen dims; when the car in the bright environment, the system will automatically switches to day mode, and key light is off while the screen becomes bright. [Non-automatic headlight]: [Day & Night mode] function can not be set manually. It needs to turn on the car headlight, and the system switches to night mode when the car in the dark environment, and the key light is on while the screen dims; in other way it is day mode, and the key light is off while the screen becomes bright.


[Non-automatic heedlamp models]: [day and night mode] function can not be set manually. It needs to turn on the car headlight, and the system switches to night mode when the car in the dark environment, and the key light is on while the screen dims; in other way it is day mode, and the key light is off while the screen becomes bright.

When it sets to [Off]: Day / night mode can only be set manually by clicking [day / night mode] option on the screen. The system can not be controlled by car headlight and ambient light.

[也]: Click this button to turn off the navigation

[General] [Info] setting operation flow chart

Main menu



[General] setting operation description

Click the [General] button in the [Settings] of the main menu to enter the interface shown as below:



Auto switch navi [On] [Off]

When it is set to [On], it will automatically switches from the current operation screen to the navigation screen when the other screen operations are finished for 10 seconds. When it is set to [Off], this function will be turned off. Navi voice prompt [On] [Off]

When it is set to [On], the navigation voice prompt is turned on. When it is set to [Off], the navigation voice prompt is turn off. Navi volume level [\triangle][∇]

It can be adjusted through [\blacktriangle][\blacktriangledown]. Boot volume [\blacktriangle][\blacktriangledown]

You can adjust the boot volume by [▲][▼].
[Map update]: Click the [Update] button to set the map update.

Continue to click [General] to set the [▼] on right side, to enter the [General] settings interface in the second page, as shown below:



[System reset]: Click the [Reset] button to select the reset system. Long press to restore factory settings.

[]: Press this button to return to the setting operation interface.

[Info] setting operation description

Click [info] button to display information about MCU, iPod, Barcode, Bluetooth, MPEG, UUID, Hardware, as shown below:



Standby interface



Vertically press the center of the vehicle button panel knob, the system will enter the standby interface; again press it, the system will return to the current interface, as shown above.

Appendix

Use the Monitor correctly

⚠ Notes of use

 Do not expose the monitor under the direct sunlight or high temperature place , otherwise, LCD failure may happen. Please use the monitor within the following temperature:

Using temperature: -10C -+50C

Preservation temperature: -12C -+80C

- * Please do not press the surface of LCD, otherwise, it probably leads to failure.
- * In vehicle with safety air bag device, do not hinder the working of safety device.

About the TFT

- In order to LCD with back-light, inner LCD uses small TFT.
- The life of TFT is about 10000hours (In cold area, the life will be shorten), The LCD will turn dim or can not display once the TFT is close to its using life. Please consult the supplier for help.

About LCD Screen

- The LCD monitor sometimes with a black dot or a flashing dot (bright dot), this is a unique phenomena of LCD monitor, rather than failure.
- When using in cold area, after connecting the power, the LCD may be a little bit dim initially, but the brightness will restore normal after a while.
- LCD is probably difficult to watch clearly because of the direct sunlight.

About Maintenance

- * When cleaning the dirt on screen, pls turn off power and use soft cloth to wipe it.
- * When wiping monitor, please avoid scratching by fingernail.
- Do not use wet cloth, volatile oil or diluents.
 Do not keep corroded items away from LCD Monitor..

Trouble shooting



Common issues

Trouble	Reason	Solution	
	All cables and connectors are not connected correctly	Reconfirm connection stably and correctly	
Unable to power on, Not working	Blown Fuse	Check reason of blown fuse, and replace it with the fuse of the same specification	
	For noise reason, built-in computer error	Press Reset button	
No response to touch button on screen, or being insensitive	Touch button shifting over actual reaction location	Calibrate the Coordinate of the Touch screen	
Black dot or bright dot on LCD screen	Unique LCD phenomena, rather than failure		
	Improper brightness adjustment	Adjust the brightness	
Dark LCD picture	Too code in vehicle	Low surrounding temp. Leads to dark monitor. Use heater to worm up the interier vehicle.	
No Sound	Volume is 0	Increase volume	
No Sound	Connection error	Confirm correct connection	
No impose display	Not connect to parking brake line	Connect to parking brake and execute it	
No image display	No parking brake	Press PWR key or touch the screen again	
Volume is small	Volume at low level	Turn up volume	
No navigation system image display	Not being switched to navigation	Switch image into navigation system	
The front and rear speakers are mute.	Improper volume adjustment in front or rear speaker	Make sure correct adjustment and setup	
The Left or right speakers are mute.	Improper volume adjustment in left or right speaker		

Navigation

Trouble	Reason	Solution	
	The maps program just completed the update.	Please re-press the "Browse" button to set up the correct one, the correct path is "\SDMEM\ Dontpanic\Dontpanic.exe". And	
Navigation system does not work or often loaded into the path of the running navigation interface.	Navigation path is not correct.	then tick the "Auto run next time" button, in the end, press the " Run Navigation" button enter the navigation.	
	The map card does not fit well or damaged.	First at all, please reboot vehicle navigation system. If can't work, please re-install the map card. If both can't work, Please turn to the retailer accordingly.	

Specification

(With the improvement of product, please forgive that we do not offer extra notice)

Universal

Max. Current Consumption: 10.0A System Power: DC14.4V (11V-16V) Grounding: Negative Pole Grounding External Image output level: 1Vp-p/75 External Sound Max. Output level: 1.5V/22K

Image Output Level: 1Vp-p/75

GPS

Approach: L1, C/A Code GPS, SPS standard

Positioning Service
Receiving Way: 12 Channels
Receiving Frequency: 1575.42MHz
Sensitivity: -130dBm
Testing updating time: about 1/second

AMP, Audio Part

Rated Power Output: 48W (12W*4) Max. Power Output: 140W (45W*4) Speaker Impedance: 4Ω

FM Tuner Section

Frequency range (50kHz space): 87.5 MHz – 108.00 MHz

Practical sensitivity: ≤12 dBμV Locking sensitivity: 35 dBμV SNR: Over 50dB (IHF-A network) THD: 0.3%

Frequency response: ≥ 2KHz Stereo crosstaltalk: ≥ 27dB

AM Tuner Section

Received frequency band: 522KHz ~ 1620 KHz (9 KHz)

Practical sensitivity: ≤ 28 dBµV

Read all items carefully before installation, and suggest go to professional and authorized shop for installation.

Installation Steps

- 1. Check and make sure all the attached accessories is available
- 2.Please withdraw the original Radio
- 3. Fix the located screws and plastic in AVN Head Unit (If not attached, no need to fix)
- 4. Following the installation guide to install the Head Unit, make sure all cables connected well; start the engine, turn on head unit for testing; if can not turn on the Head Unit, please check the cables connection correctly or not till the problem solved; if working fine, turn off ACC!
- 5. Put the Head Unit back the original Radio Place, and fix it well!



Special Note items

- 1.Be careful not to break the original cables
- 2.To avoid short circuit issue, it is recommeded to withdraw the Negative pole of Battery.
- 3. To avoid unexpected damage, do not plug harness with power.
- 4. Please check the attached cables label matching the car type or not.
- 5. Make sure original cables and HeadUnit cables connected correctly
- 6.Before power on, please make sure all connection correctly, Battery (+) (Yellow) and GND (Black) not short circuit. Wrong connection of Power cable will bring damage to head unit and car.
- 7.Do not connect head unit's power cable to other product's power directly.
- 8. Attached Map Card already inserted in Card slot.



• please check the "Installation flow chart and attention" for reference!

Poisonous and harmful substances or element table name and content

Part Name	Poisonous and harmful substances or elements						
	Pb	Hg	Cd	Cr6	PBDE	РВВ	Environment protection use period
Main Board	Χ	0	0	0	0	0	•
Display screen	0	0	0	0	0	0	•
Platstic	0	0	0	0	0	0	•
Metal	Х	0	0	0	0	0	•
Non-metal	0	0	0	0	0	0	•
Data wire	0	0	0	0	0	0	•
Antenna	0	0	0	0	0	0	®
Accessory	0	0	0	0	0	0	•

- O: Means that the content of toxic and harmful substances in the parts in all homogeneous materials is lower than the standard of GB/26572-26572
- X: Means that the content of toxic and harmful substances in the parts in all homogeneous materials is higher than the standard of GB/26572-26572

Attention: the reason of "X" for the product is not alternative available technologies or parts at this stage.

This product by the environmental protection use period refers to the use of the information in this quide provides conditions.

Sales agent: Ford India Private Limited

Address: National Parts Distribution Center, S P Koll post, Chengalpattu.
Pincode-603204, Tamilnadu, India
Manufacturer: Guangdong Creator & FlyAudio Ele & Tech Co., Ltd.
Address: Floor 3, Bullding F, Creator & FlyAudio Xinyong Sheng Industrial
Park, No.3 Industrial District, Gekeng Village, Hengli Town,

Dongguan City, Guangdong Province, China, 523460

Issue Date: 1st Jul.2017 Execute Standard: Q/TYFG 1-2016



§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.