# Statement

Thanks for choosing our kids watch model T1601 . You may please have a knowledge of all the functions and how to operate our watches by reading this user manual .All the pictures and instructions in this user manual are for reference only

The functions of this models cover two-way calling, GPS location, SOS, making friends, voice message, checking weather, camera, alarm pedometer and etc.

Our Company reserves the right to make changes to the contents of this manual without prior notice please understand. Before you using this model ,here invite you to download and install the application KidMate in your smart phone ,which binds with watch to make all the functions come

Since the software keep upgrading, the contents in this user manual may be a little different from the reality operation in the final products.

#### 1.Structures Introduction



- 1. Sceen: all the data display on the screen: 2. Power key: short pressing over 3 sec. to power on, long pressing over 8sec. to power
- 3. Return key: press this key to return previous menu, no response pressing this key in the standby page
- 4. Camera: don't cover it when take photos.
- 5.SIM cover:install or uninstall SIM card. please disassemble this cover.
- 6.USB port:connect the USB cable tocharging or transmit data
- 7. Light sensor: this light sersor is telling if the watch drop-off or not
- 8. Mic.:don't cover please.
- 9. Speaker: don't cover please.

2

### 2. Operation Introduction

#### 2.1 Buying SIM card and Installing

Please buy and use the standard nano-SIM card (as iphone 6), which open the CID(Caller Identification) and Cellular Data. Watch keep power off before installing the SIM card. Use the tool to open the SIM cover according to the position of kerf angle to leave the SIM card on the cover then fix it by tool (Usually need wait 1-2 minutes to search signal, if no signal long time, you may please repeat above action.)

2.2 Power on and power off.

Short pressing power key over 3sec.to power on, long pressing power key over 8sec, to power

2.3 Download and install the application

KidMate from Google play store or iPhone App store then bind with watch (In the kid mate application, there is a detailed instructions to bind with watch.)

### 3. Functions Introduction

#### 3.1 Standby page

It display date, time, weather, battery level, pedometer information .signal strength.WIFI buttom.story buttom and unprocessed information buttom. Battery level: The number of cells in the battery

indicates the battery level Pedometer: The number of little foot icon indicates the pedometer information .SIM card The small circle ball indicates the signal information .WIFI buttom: This buttom indicates the WIFI using status. Story buttom: It can download and listen the stories from application .Unprocessed information buttom: It indicates the missed call unread voice messages.

3.2 Contacts Enter this page can make calling and send voice messages.

3.3 Make friends Enter this page to make friends by bluetooth.

3.4 Camera Enter this page to take photos.

Shen7hen Continental Wireless Co., Ltd hereby declares that this Children's smart phone watch, T1601 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Manufacturer: we

Use the Children 's smart phone watch in the environment with the temperature between -10°C and 45°C

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

The product shall only be connected to a USB interface of version USB2.0 Adapter shall be installed near the equipment and shall be easily accessible.

SAR: The device complies with RF specifications when the device used at 0mm from your body.

The plug considered as disconnect device of adapter

Adapter Model: A8-500500 Input: AC 100-240V 50/60Hz 0.15A Output: DC 5.0V. 0.5A

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by

- one or more of the following measures: -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# KIDS WATCH

- Enter this page to check and edit the photos.
- 3.6 Weather Enter this page to check weather
- 3.7 Pedometer Enter this page to check the pedometer information.
- 3.8 Message Enter this page to check the messages from family number.
- 3.9 Settings Enter this page to set the voice volume.
- 3.10 Update Enter this page to check if the software need updatd or not
- 3.11 Story Enter this page to download and listen the stories from application.
- 3.12 Alarm Enter this page to check the alarm setted by application

# 4.KidMate Register&Using Introduction

- 4.1, Register a account & Login If you are a new user ,please register a account then login the application.
- 4.2 Bind with watches First time login, the application will remind to bind a watch automatically . If you want add more watches .please click"+" to add .below two methods:
- a.By scaning the QR code from backside of watch or the sticker on the box
- b. Adding manually, put in the IMEI number, watch phone number, then get a verification code from the watch screen, put it in to add a watch successfully .P.S ,the QR code from the backside of the watch is on-kick, when the first smart phone add the watch successfully ,the KidMate application will generate a QR code for this watch, then the next smart phones scan this QR code to bind watch.
- 4.3 Add family number Choose more-->family number .setting and save, watch will show "set ok", also application will say set ok, too.

# 5 Precautions

- 5.1 Please power off this watch before airplane taking off
- 5.2 The product is inedible , never let the kids or pets to eat this products and accessories.
- 5.3 GPS location may be not exactly right even not work under the bad weather or arround many tall buildings .which weak signal .Don't use this watch under thunderstorm weather.
- 5.4 Please don't steep or wash this watch. better to avoid the water .this watch is only for life water proof .not a special one .
- 5.5 Please keep away from sources of ignition. high temperature and head . If you find the watch high temperature, please put off till it cold, then wear it.
- 5.6 Please don't disassembling the CPU in the watch by yourself without professional instrucions .Or it may caused damage to your body or the watch itself.
- 5.7 All radio transmitting device (including this watch) will cause interference to the medical equipment without complete protection

# 6. Frequently Asked Question

- 6.1 abardeen watch and KidMate introductions? Answer:please install and login the KidMate application, all the functions information are available.
- 6.2 How to bind with watch? Answer: First smart phone bind with the watch by scaning the QR code from watch backside or packing box. The next smart phones should sca the QR code generated by the first smart phones.
- 6.3 Why still show no SIM card after inserting SIM card? How much cellular data does it need for each month ?Answer:Please power off the watch, and insert the SIM card according to the instructions 2.1. Usually 30M cellular data is enough for each month.
- 6.4 Is there calling function? Answer:yes, abardeen watch is with a two-way calling function, it can save 60 contacts.
- 6.5 Does the watch water proof crash proof? Answer: ves .water proof of abardeen watch is IP65 .no problem when wash hands and in rain day .but it's not suggested taking it to swimming or taking bath. Watch is with crash proof function.

GPS&Calling Watch User Manual

5

6