QUICK START GUIDE



Plum

Warning:

measures:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

- Regrient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

correct the interference by one or more of the following

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level,the actual SAR level of the phone while operating can be well below the maximum value.in general,the closer you are to a wireless base station antenna, the lower the power output. Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC.Tests for each phone are performed in positions and locations(e.g. at the ear and worn on the body as required by the FCC. For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 0.5 cm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

Plum Rugged Device Quick Start Guide

1.Ensure the USB Port Cover Flap is correctly sealed to protect from water & moisture.

2.Ensure that the rubber seal inside the battery door is placed correctly. Improper use can cause damage to the device.

3.IP-67/68 Certified devices are water proof in depths of 1 meter or less and can be submerged for up to 20 minutes.

4.Rugged devices are designed to withstand falls from up to 1 meter in height.

Plum Mobile& authorized service centers are responsible for determining warranty status, misuse or abuse.

Quick Power On

1 Circumrotate the screw

Use the coin to rotate the screw of the battery cover counterclockwise.








2 Open the battery cover

Open the unfold battery cover.





After open the battery cover, push up the SIM card as picture and fix it.





4 Insert the Micro-SD card

Insert the SD card into the slot by pushing the SD card downward refering to the drawing.



5 Insert the battery

Insert the battery, cover the battery cover and use the coin to rotate the screw clockwise.



6 Charge 12 hours

Suggestion:charge for 12 hours for the first using.



Keypad Description





Please visit our website for user manual. www.plum-mobile.com

ENGLISH			
ı	NTERN	IET CONNECTION PLUM E800 RAM 8	
To	Conn	ect to the internet,follow these steps:	
Menu			
Settings			
	Coni	nections	
	SIM	SIM 1 Network Account or	
	SIM	SIM 2 Network Account.	
	Option		
	New	New Account	
	1	Rename	
	2	Access Point	
	3	User Name	
	4	Password	
	5	Gateway	
	6	Port	
	7	Auth Type	
	8	Set Homepage	
	9	DNS Address	
	10	Network Type	
Ple	ase co	ntact your Network Provider to receive	
inforn	nation:	APN, Homepage, Proxy address/Port, User	
		name & password.	