(Fold Inward) - - - - **▶**

(Back Cover)

(Front Cover)

Compliance Information

READ CAREFULLY AND SAVE THIS MANUAL FOR FUTURE REFERENCE

CCInformation
This device complete with Part 15 of the PCC Rules. Operation is subject to the following two conditions: (1) This device may not assess harmful interference, and (2) This device must accept any interference received, including interference that may cause

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment

Note: This equipment has been tested and found to comply with the lemit for a Class 8 digital divisor, porsuant to part 14 of the complete of

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable expo



Rating Label Definitions



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the averagement.





Bluetooth

This symbol signifies that this is a wireless device powered by Bluetooth* technology. The Bluetooth* wordmark

Telecom is under Icense.

Telecom is under Icense.

Warranty Information

center for regain must be suitably published.

ADMINISTRATION OF THE PRINTS ON BUYER DELICATED, BUT HOT LIMITED TO, ANY HAN ED WARRANTS OF MESCHAMPHEN THE CONTROLLED AND ADMINISTRATION OF THE CONTROLLED ADMINIST

Some countries, states or provinces do not allow the exclusion or function of incidental or consequential damages or allow funitations or warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from allot to state or province to province. Condect over authorized relative to determine if another warranty audits.





Wireless Earbuds **Instruction Manual** TCU018

Before You Begin...

Customer Support

For any questions or problems, please visit our website at SouthernTelecom.com and click on Product Support.



To ensure safe and proper use, read all safety information before using the device. Only

- use with manufacturer-approved batteries, chargers, accessories, and supplies.

 THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
 Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or
- · Do not submerge in water.
- · Low power may cause poor Bluetooth connection or sound distortion.
- · Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
 Do not allow the USB port or the connectors of the supplied USB cable to be exposed. to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

- •TCU018 Wireless Earbuds (x1) USB Charging Cable (x1)
- User Manual (x1)

Location of Controls

LED Indicator [H-] | [+H] Buttons [ປາ] Button (Press) Skip Tracks (Press + Hold) Power ON/OFF 43 (Press) Pause/resume playback (Press) Answer/end phone calls 5V USB Charging Port **→**

Getting Started

Charging the Earbuds

Attach the small connector of the supplied micro-USB cable to the USB charging port on the side of the earbuds. Attach the large connector to the USB port on a computer, a USB charging device, or a 5V USB adapter (not included) and plug into a wall socket.

The LED indicator will *turn RED* while charging and turn off when fully charged. When low on power, a tone will be heard, indicating that the earbuds should be charged.

Power ON/OFF

- Press and hold the [tot] button to power the earbuds ON/OFF.
- · When powered ON, the earbuds will automatically reconnect to the device they were most recently paired to, so long as that device is within connection range (30 ft.) and

- Bluetooth Pairing
 1. Power the earbuds ON. A tone will be heard and the LED indicator will quickly flash
- Set your mobile device to search for Bluetooth devices. When it appears, select TCU018 from the list of found devices.
- 3. Once successfully paired, a tone will be heard and the LED indicator will slowly flash

LED Indicator Quickly Flash BLUE Earbuds are ready to pair 000 Slowly Flashing BLUE Earbuds are paired Solid RED +ы` Earbuds are charging

Playing Music

To listen to music on your earbuds, make sure they are paired to a Bluetooth-enabled device. For more on pairing the earbuds to your device, please consult the Bluetooth Pairing section of this user manual.

Once paired, you can control media playback and volume adjustment with the earbuds' controls or the ones on your paired device.

Controlling Playback & Volume

- Press the [0] button to pause/resume media playback.
 Press the [n-] and [+n] buttons to skip tracks.
- Press and hold the [н−] and [+ +] buttons to adjust volume. A tone will be heard if trying to increase the volume past the maximum level.

- Press the [פים] button to answer an incoming phone call. Press again to end the phone
- Press and hold the [৩৭] button to ignore an incoming phone call.

 Double press the [৩৭] button to redial the last phone number called.