Legal Information READ CAREFULLY AND KEEP THIS MANUAL

FCC Information FCC ID:

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F)



Rain/Moisture Warning

- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid conditions, or wet conditions.
- · Do not submerge in water
- Do not open this product or attempt to repair the unit yourself should it not be working.

Rating Label Definitions

Direct Current



Comply with Waste Electrical and Electronic Equipment (WEEE) Directive (2012/19/EU)



The product is in compliance of energy efficiency



This symbol indicates that information could be exchanged between wireless devices such as personal digital assistants (PDAs), mobile phones, laptops, computers, printers and digital cameras via a secure, low-cost, globally available shortrange radio frequency band. The Bluetooth word mark and logos are owned by Bluetooth SIG, Inc.



10 6

50-08002018

Made Exclusively for Five Below Distributed By Southern Telecom Inc. 5601 1st Ave, Brooklyn, NY 11220. The BLUETOOTH® wordmark and logos are owned by the Bluetooth SIG, Inc. MADE IN CHIMA / DESIGNED IN THE U.S.A.



Evolve Wireless Earbuds



User Manual -TXBTEVOLVE-

Printed in China 092018

Before You Begin...

Caution

- THIS IS NOT A TOY, please keep away from children
- Keep away from water and extreme temperatures
- Low power may cause poor Bluetooth connection or sound distortion
- Do not overcharge the battery

Specifications

Driver Diameter: 10 mm Impedance: 32 ohm Battery Capacity: 50 mAh Rechargeable: Li-ion Battery 3.7 V Bluetooth Ver.: 4.0 Bluetooth Range: 30 ft Charge Time: 1-2 Hrs Playtime: 1-2 Hrs


In the Box

- TXBTEVOLVE Bluetooth Earbuds (x1)
- Micro-USB Charging Cable (x1)
- User Manual (x1)

Location of Controls

- 1. Micro-USB Charging Port
- 2. [Multi] Button

(Long Press) Power ON/OFF (Quick Press) Pause/resume (Double Press) Redial last phone number called



Getting Started

Charging the Earbuds


Plug the small connector of the USB cable into the micro-USB charging port on the earbuds. Plug the other end into the USB port on your computer, a USB charging device, or a **5V USB charging adapter** (not included) and plug into a wall socket.

The LED indicator will *turn RED* while charging and turn off when fully charged.

On low power, a tone will be periodically heard, indicating that the earbuds should be charged.

Using the Earbuds

Make sure that the earbuds have been charged before using for the first time.



Ů Powering ON/OFF

- Long press the [Multi] button for 3 seconds. A tone will be heard and the earbuds will enter Bluetooth pairing mode. The earbuds will re-pair to any nearby, previously-paired device.
- Long press the [Multi] button for 3 seconds to power OFF.

≯ Bluetooth Pairing

- 1. Power the earbuds ON. A tone will be heard.
- 2. Set your mobile device to search for Bluetooth devices. When it appears, select **TXBTEVOLVE** from the list of found devices. If prompted for a password, enter "0000."
- 3. Once successful, a tone will be heard indicating that the earbuds are paired.

□ Playing Music

To listen to music on your speaker, make sure it is paired to a Bluetooth-enabled device (see the **Bluetooth Pairing** section). Playback and volume adjustment is controlled with the paired or connected device.

• Quick press the [Multi] button to pause/resume playback.

Phone Calls

- Quick press the [Multi] button to answer an incoming phone call.
- Quick press the [Multi] button to end the phone call.
- double quick press the [Multi] button to redial the last phone number dialed.