Size: 85x55 mm

Mini Bluetooth Speaker M3

# **USER MANUAL**



Thank you for choosing our Bluetooth speaker . This manual will help you to operate the Bluetooth speaker, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Bluetooth speaker. For example the computer's Bluetooth functionality

## Safety rules:

- 1. In order to ensure safety, please observe the rules mentioned in this specification. We Would strongly recommend that you read this manual before using this Bluetooth speaker.
- 2. Be more wary of any edges, uneven surfaces, metal parts. accessories and packaging. In order to prevent any possible injury or damage.
- 3. Please do not dismantle, repair this Bluetooth speaker. These action may cause in fire Electric shocks, complete breakdown of this Bluetooth speaker. All of which, are not in the warranty. 4 Please do not use any oil or volatile liquid to clean the Bluetooth
- Please do not use the Bluetooth speaker in a hazardous location.

# Bluetooth speaker x1 | Micro Charging cable x1 | User Manualx1 . Line in cable x1 Product Appearance Introduction

- Charging interface
- 2).Switch button
- 3.AUX interface



Bluetooth Speaker Model:	M3
Bluetooth Specification:	2.1+EDR
Bluetooth Profile:	HFP A2DP
Range:	≤10m
Frequency Response :	100Hz-20KHz
Loudspeaker Output :	3W
Signal-To-Noise:	≽75dB
Distortion:	≤1.0%
Playback Time:	4 hours
Charging Time:	2 hours
Dimension:	62*62*51mm
Weight:	94g

In order to use the Bluetooth speaker, you must first pair your Bluetooth speaker with your phone or computer. If the phone is paired Bluetooth speakers and over, in the effective distance, mobile phones and Bluetooth speakers will automatically paired. If you are using the computer, you only need to select the audio connection on the line

- 1). Paired with your phone and using:
- Turn on your phone and ensure its Bluetooth function is
- Turn on the Bluetooth speaker go into the paring mode.
- Please search bluetooth device "Bluetooth M3" according to the manual of your phone.
- After a few second the phone will list the device as a discover device. Select it and follow your phone's instruction to select this
- Your phone will request a passkey or PIN, enter "0000" as your PIN or passkey.
- Your Phone will confirm the pairing, and then press OK or YES.
- Finally, select to connect with device from your phone, you can open the phone player to play music, watch movies, play games. All sounds are heard from the Bluetooth speakers .

- 2) Pairing with the computer and using:
- If there is no bluetooth function supported by your computer. A bluetooth adapter is necessary. Fix the adapter with your computer and ensure its Bluetooth function is activated.
- Turn on the device go into the pairing mode.
- Turn on Bluetooth on your computer or operating system control software comes with software, such as IVT software. select the menu to search for Bluetooth devices .
- Search to Bluetooth speakers the "Bluetooth M3" will be displayed in the list of devices. Select this device and click the right mouse button and select "pairing" item. Choose this device again, click on the right mouse button, select "connect with audio device\*.
- At this point, your Bluetooth speaker has established a connection with your computer. Then open your computer's media player or play music, or watching movies, or playing games Bluetooth speaker became loud speakers.
- 3). Charging your Bluetooth Speaker:

Bluetooth speaker using a more generic "DC Micro" charging interface, with icons on the product logo, the product provides charging cable which can turn "USB" to "DC Micro". Of course, you can also choose to output interface with "DC Micro" adapter . but please note that you must choose the regular manufacturers of DC output voltage 5V adapter. Ensure that for the first time to use your Bluetooth speaker charging at least 6 hours . Method is to use your charger or charging cable DC output plug into "DC Micro", WhileCharging, the red LED light constantly, When charging is completed, the LED turns off.

4). Put the audio cable into the AUX port to connect the product to a computer or mobile audio output port, which can be used as an external speaker.

You must select a qualified charger from a regular manufacturer. You must charge the Bluetooth speaker if it has been not used for more than 12 months

If your device is not performing as it should please take it to your local service providers or dealer for service.

## FAO:

- 1). Why is there no sound even when the speaker is power on? A: Make sure the battery is being charged up to 4 hours for first time using. The Led is lighted when it starts charging.
- 2). There is no sound when playing the speaker. A: Check that the playback device and the Bluetooth speaker whether to establish a good connection, if there is no connection. please reconnect. Also ensure the speaker device is paired and
- connected with your target phone or other master device. 3 ). How to identify Bluetooth speaker has been fully charged When the red charging indicator automatically turns off, which means that Bluetooth speaker has been fully charged.



## Warranty card: User name:

Product item: Date of survey:

Address:

Fault phenomenon:

Purchase date

Repairmen option: replacement 

grantee repair

please provide proof of purchase of the power bank by a dated itemized receipt to be eligible for this limited warranty.

maintenance □

The orginal warranty card must be presented for

The following staements dose not being to the scope of free maintenance, we can provide paid services.

- 1. Any defect occurring after the expiration of the warranty period.
- 2. Users change, disassemble the prouct's structure or circuit, or use components provide beyond us.
- 3. Damage from human factor or external causes
- such as floods, storms, fires, or other Act of GOD. 4. Damage caused by incorrect linking to other
- 5. The product is different from the warranty card.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.