FCC Information

This device compiles with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

FCC notification to users

This equipment has been tested and found to comply with the limits for a CLASS B diotal device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference, the user is encouraged to try to correct the interference by consulting with a dealer or an experienced technician for technical assistance

Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

The antenna(s) used for this device must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter

▲ DANGER

- . Keep it out of reach of infants and children Be careful for infants and children not to mistake it as a toy. (Ingestion of parts may lead to injury.)
- . Do not insert metals into the connector part or the connector terminal. (Doing so may cause overheating, fire, or electric shock.)
- . Do not disassemble or modify it Never disassemble or modify it. (Doing so may cause electric shock.)
- . Do not replace the batteries or touch the connector part with wet hands. (Doing so may cause overheating, fire, or electric shock.)
- Close supervision of a guardian or an adult is advised to prevent children from using the product. It may cause an injury or electric shock to children when they use the product without supervision of adults.)



↑ WARNING

- Do not swing the main part while using it.
 [The main part may fly into unexpected places and cause accidents.]
- . Do not use the main part in wet places. Do not pour water on it.
- [Doing so may cause electric shock or malfunction.] Make sure to prepare a spare light source and batteries in the places where the
- light of lanten plays a key role. Do not use it beyond the recommended usage temperature.

 [Doing so may cause a leak of the battery liquid or heating of the batteries, or fire.]
- . Do not use it in places with high temperature such as those nearby flammable substances or heaters.
 [Doing so may cause overheating and fire due to disconnection or short circuit.)
- . When using external power, do not use in places with dripping water. (Doing so may cause overheating, fire, or electric shock.)
- Connect this product only to the power source designated as a rated external source (DC12V ZA). (Doing otherwise may cause overheating or fire.)








10. Malfunction due to the use of the product with the products of other companies





SPECIFICATIONS

Product name	AYOND O2	
LED color tamperature	Daylight color / Lightbulb color / Support RGB colo	
Audio (rated output)	4Wx 2, Stereo	
Brightness (fumon)	1200Lm-75Lm	
Use time	4-40hr	
Sim	240 x 99 x 65mm	
Product weight	680g	
Battary capacity	10,400mAh (5,200mAh, 2S2P)	
Changing time	4hrs	
INPUT (changing and power)	DC 12V 2A	
OUTPUT (axiomal device charging)	DC 5V 1.5A	

MAINTENANCE

- Δ Maintain the product regularly so that it will be clean and ready for next use. Carefully wipe out dirt with a wet cloth.

 Wipe out the external terminal with a dry cotton swab or cloth.
- If the main part is wet, completely dry it first with a soft cloth before storage. If water gets into the USB connector or the main part, immediately stop using the product, and contact our
- If the product will be stored and will not be used for a long time, turn off the BT button and the CHARGE button. (Check for the function indicator lamp.)

Problem	Cause	Action
The lantern does not turn on	The batteries are discharged.	Check the residual quantity of the batteries, and recharge the device.
	The terminal is dirty.	If the terminal that gets into contact with the SEI is dirty, clean the product with a dry cloth.
Others	The product is out of order.	Immediately stop using the product, and contact our customer service center.

QUALITY ASSURANCE

We double-check the quality of our products to make sure that they are safe to use. However, we occore create the quanty of our products to make some that may are same to obe. Investigating if a purchased product does not work properly, contact up or the store where you made your transaction, in case of manufacturing defects, it will be repaired free of charge or replaced. For other cases, it will be repaired at reasonable prices, so please bear with us. Please be aware that it would not be repaired or replaced for the following cases

- Life cycle by damages due to the aging of materials
 Malfunction due to modification and poor handling
- . Malfunction due to prohibited handling as described on the manual . Malfunction due to unexpected accidents . Product malfunction due to other manufacturing defects

- Malfunction due to pollution or rust
- Malfunction due to disassembly
 Malfunction due to part deformation and damage because of a fall or other shocks
- 9. Malfunction due to the change of parts because of abrasion



EKOMOS.CO.,LTD., Harryang Univercity Bi Center, 55, Hanyang dehakta, Sangrak gu, Antan-ii, Gyeonggi do, 1558 f, Korea Tel. +82-31-400-3036 Fax. +82-0303-3443-8390









LED Lantern Function (Turning on/off the lights, battery level check, sleep timer, SOS flash function)

 On/Off Dial: Press the on/off dial for 2-3 s to turn on the lights, as shown in the picture. After turning on the lights, it becomes brighter by turning the dial + and becomes darker by turning the dial in the apposite direction. Whenever pressing the on/off dial shortly, the color and lighting quantity of the LED will change.

2. Function Button

- . Battery level check: The battery level is displayed in LED quantity of four levels by pressing
- . Sleen timer function: The lights will automatically be turned on 5 min after pressing the button twice. There of the battary levels ficker when the sleep timer is in operation. (It will be set from 5 to 20 min when controlling an application.)
- SOS Flash Function: The LED light-emitting part will flicker at regular intervals when pressing the function button for 2 s.
- * Disable Function: Press the or/off dial button for 2-3 s to cancel the sleep timer and SOS functions

AYOND 02 User's Manual

EKOMOS.CO.,LTD.

Power Bank Function (External USB Device Charging)

- 1. The external device starging after connecting the device and pressing the CHARGE button once. (The function indicator lamp will be indicated as red)
- Once, The function indicator ramp will be indicated as real.
 2. When the charging is completed, remove the USB terminal from the USB Out port and press CHARGE button once to turn off the external output power. (The external output power will be completely cut off.)

 * The charging time may vary depending on the battery capacity of the product and external device
 - *Furction Indicates lamp: When the charge mode and BT mode are CN, it will be indicated green.When the BT mode is CN, it will be indicated blue.When the charge mode is CN, it will be indicated red.













Attach the botton and strap that passed through both iles of hooks as shown in the image.

USER'S MANUAL

Thank you for purchasing the AYOND 02.

This product is a lighting fixture that has been developed for the lighting of tents, tarps, PC works, or indoor mood lamps. Please read and fully understand this manual to safely and properly use this product. Please keep this manual in a safe place for future reference.

For the proper use of the product, the damage of hazards and the degree of damage caused by improper use are classified as follows:

Safety Precautions

Symbol	Precautions Scope
▲ DANGER	This symbol denotes a potential hazard that will result in serious injury or death
▲ WARNING	This symbol denotes a potential hazard that could result in serious injury or death in some cases.
▲ CAUTION	This symbol denotes a hazard that could result in injury or damage of the main part and other parts.

▲ CAUTION

 A fall or a shock causes an accumulation of damages on the main part and, thus, unexpected malfunctions during use.

Be careful not to apply excessive force or shock to the main part.

Light and Audio Control App

1 Connect Bluetooth

Connect Blueboth Develop Art Those App stors, and nun it. Develop AVVND 02 from the Android or illhore App stors, and nun it. The blue LCD will but non when pressing the BT button for 3 s. Connect details and AVVND 02 or be Blueboth after the app is non. When the device and AVVND 02 are connected, a connection message such as in the image below will be shown.



Select Mode
 Set a desired mode for the user, as shown in the



Control Brightness
 You can control brightness from levels 1 to 9, as shown in the image.



Support for Audio Media Bluetooth Audios
It supports various media platforms such as Media Player, Audio Player, YouTube, etc.



5. Press the BT button for 3 s to turn off the device.