

Model Name:E3

ABRAMTEK E3 True Wireless Earbuds

- User Manual -

# FCC ID:2AGCAE3

Optional Eartips

with Medium eartips.

To improve wearing experience

please select the best fit eartips to use.

It is recommended to try Medium eartips as it's suitable for

most people. The factory assembled earbuds are equipped

IMPORTANT: Please use the best fit eartips. The better the air

Charging Case Battery Indicator

Right Earbud

----- White LED Light

USB-C Charging Port


tightness, the better the sound insulation and sound quality.

- 1.If the earbuds cannot hold a charge, please insert USB-C cable to charge the charging case.
- 2.Please put the earbuds into charging case if not used. Otherwise, the earbuds always stay on.

# How to pair earbuds with your phone Take out the earbuds from charging case, the earbuds will

power on and pair to each other automatically. Then the left earbud indicator turns off and the earbuds enter into pairing mode. Activate your phone's BT and search for "abramtek E3" and select. After initial setup, the earbuds will automatically reconnect to the last paired device.

Note: If the earbuds do not work properly, please put the earbuds into charging case for 2-3 seconds and then try again.



# Support switch between left and right earbuds. You may listen

How to use single earbud

to repeat the pairing process.

How to recharge the earbuds

**Function Points** 

to music with single left earbud or right earbud, with no need

# Put the earbuds into the charging compartment and make

sure it fits the charging port contact receiver properly. When the earbuds are fully charged, the white indicator will turn off.

# How to recharge the battery case

Insert USB-C cable to recharge the battery case. When the battery case is being charged, the white indicator turns on. When the battery case is fully charged, 4 white indicators light




## Take out the earbuds from charging case, the earbuds will

power on automatically (White indicator flash 3 times, and then orange indicator light once). Power OFF

Power ON

Put the earbuds into the charging case, the earbuds will power off automatically (Orange indicator always on)



# interval 0.6s) to reject the call.

Reject Phone Calls

When a phone call comes in, tap the right earbud 3 times (time Play/Pause

When playing music, tap the right earbud twice (time interval 0.6s) to pause and play the music.

### Previous Track/Next Track When playing music, tap the left earbud 3 times (time interval 0.6s)

to switch to the previous track, tap the right earbud 3 times to switch to the next track.

Voice Interaction In standby mode, tap the left earbud twice (time interval 0.6s) to

activate your phone's voice assistant (for example, Siri).

**Product Parameters** Model: E3

Bluetooth Version: 5.0 Bluetooth Distance: 10 meters in open area

(All technological information is subject to practical performance)

Charging Time: 3 hours Standby Time: 150 hours Playback Time: Over 6 hours Battery: Polymer li-ion battery

Answer Phone Calls

Support Protocol: HFP/HSP/A2DP/AVRCP When a phone call comes in, tap the right earbud twice (time Earbuds Battery Capacity: 3.7V --- 60mAh Charging Case Battery Capacity: 3.7V == 1200mAh interval 0.6s) and this will answer the call. After you finish your Charging Case Input: 5V --- 800mA conversation, tap the right earbuds twice to hang up phone.

# 1. Restart the earbuds.

2. Check the compatibility and call quality of your phone. 3. Check if the earbuds are too far away from your phone or

- there is any interference around. 4. Do not stay at the surroundings where signal reflection
- exists.

or there is any interference around.

- What should I do if too much noise from the earbuds? 1. Check the noise control of your phone.

What measures should be taken if signals are unstable?

- 2. Check if the earbuds are too far away from your phone.
- 3. Check if there is any electromagnetic radiation around.

3. Check if the earbuds are too far away away from your phone

- What should I do if I cannot hear the voice from earbuds? Check if the earbuds are muted. 2. Check if the earbuds are connected to your phone.
- rights reserved.

not authorized by the manufacturer.

WARRANTY AND SUPPORT

for use with the product.

Limited Warranty



ShenZhen Abramtek Technology Co., Ltd.

Add: 5th Floor, Building 1, Yonghongfeng Industrial Park, Baiyunshan Village, Dalang Street, Longhua Town, Shenzhen, China 518109

1. If this product or any part thereof is proven to be defective

12 months of purchase, we will at our option repair or replace

the product free of charge, on condition that the original

invoice or sales receipt with the date of purchase, or stamp

2. The warranty does not cover product failures which have

3. The warranty does not cover product failures caused by

4. Any defective unit or part shall become property of the

manufacturer. The warranty does not cover any damage

modifications, repairs and disassembly by any person who is

caused by misuse, drop, hit or neglect. Abramtek Ltd. 2019, All

from the dealer is presented together with the defective unit.

been caused by use of accessories or other peripheral devices

that are not original Abramtek branded accessories intended

by reason of faulty workmanship or defects in materials within

Website: www.abramtek.com Email: support@abramtek.com

# FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.