




Y641


LED**蓝牙**音箱

LED Bluetooth speaker




"The *Bluetooth*[®] word mark and logos are registered trademarks owned by *Bluetooth* SIG, Inc. and any use of such marks by LOGO is under license. Other trademarks and trade names are those of their respective owners."


Controls And Indicators



Controls And Indicators



Controls And Indicators



MODE — The switch from Bluetooth Mode to Lin-in Mode

Bluetooth Mode

- Press the button "ob" over 2 seconds on the speaker or press the button "ob" on the remote control to turn on the *Bluetooth* mode, the *Bluetooth* indicator slowly blinks blue and the speaker emits a tone.
- With your device and LED speaker both turned on, press the button " to make the speaker discoverable or press the button " over 3 seconds. The *Bluetooth* indicator quickly blinks blue and the speaker emits a tone.
- Set your Bluetooth device to be discoverable so it can discover (detect) the LED BLUETOOTH SPEAKER. Locate the Bluetooth device list in the user interface of your device.
- From the Bluetooth device list, select the device named "Y640".
 Press it and the speaker emits a tone. When Bluetooth indicator keeps light, Bluetooth pairing is complete.
- Automatically playing with beating light under the Bluetooth mode.
- Light and play can be separately working.

Line in Mode

Press the button "MODE". The speaker is in the mode of line in when you hear the voice of "line in" from the speaker.

Note:

If you are unable to play your device at any situation, press the button to turn the LED *BLUETOOTH* SPEAKER on again and reconnect, or power-on reset.

Charging

Under charging, the indicator is on red. Indicator does not light when the charging complete (Charging is full).



Note:

- Suggest to put on the cap well when charging has completed, especially in the rainy day.
- Low-battery warning: Auto OFF after red light is flashing for 10 seconds

Operation Reminder

- Suggest use the speaker on the balcony, garden, party on-site, Bar, or other outdoors.
- On the sunshine and rainwater or very low temperature, do not expose the speaker for a long time. Suggest take it back to indoor to increase the service lifetime.
- Power-on reset:Reset one time for Power-ON/OFF
- To smoothly control the LED BLUETOOTH SPEAKER by remote control, do not have any objects (grass, stool, etc.) on the location of showed picture as follows:



Receiver of remote control

Technical Data


- Adapter: Input 100-240AC Output 5V/1A
- RGB LED
- Battery: 4400mAH
- Working time: 30 hours (LED Flashing mode only);
 12 hours (Music mode only)
- Charging time: 8-10H
- Bluetooth: Bluetooth 3.0
- Bluetooth range 10M

Relevant Declaration

 This product bears the selective sorting symbol for waste electrical and electronic equipment (WEEE).



- This means that this product must be handled pursuant to European Directive 2002/96/EC in order to be recycled or dismantled to minimize its impact on the environment.
- For further information, please contact your local or regional authorities.



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement

Note: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body