
Fixed frequency guidance of BT&BLE

- 1. Close the BT function of the VR.
- 2. Copy the "adb" decument to disk C of PC.
- 3. Connect to mrico USB port to PC
- 4. Download from internet and Install the SnapPea-snappea to PC
- 5. Install the adb driver to PC



- 6. Open SnapPea-snappea and connect to VR
- 7. Run cmd
- 8. Please input the following instructions.
 - a. cd c:\adb
 - b. adb root
 - c. adb remount
 - d. adb push brcmbt(please enter "adb push", and push the "brcmbt"decument to cmd)
 - e. adb shell
 - # chmod 777 system/bin/brcmbt
 - # brcmbt



- 9. Copy below instructions to cmd. You can fix the frequency.
- 10. Please enter "hcicmd 03 0C 00" If you want to stop transmit.

BT part: 1DH1: 2402:hcicmd 51 FC 10 FF FFFFFFFFF 01 00 04 01 04 1B 00 09 00 01 2441:hcicmd 51 FC 10 FF FFFFFFFF 01 27 04 01 04 1B 00 09 00 01 2480:hcicmd 51 FC 10 FF FFFFFFFFF 01 4E 04 01 04 1B 00 09 00 01 1DH3: 2402:hcicmd 51 FC 10 FF FFFFFFFF 01 00 04 01 0B B7 00 09 00 01 2441:hcicmd 51 FC 10 FF FFFFFFFF 01 27 04 01 0B B7 00 09 00 01 2480:hcicmd 51 FC 10 FF FFFFFFFF 01 4E 04 01 0B B7 00 09 00 01 1DH5: 2402:hcicmd 51 FC 10 FF FFFFFFFF 01 00 04 01 0F 53 01 09 00 01 2441:hcicmd 51 FC 10 FF FFFFFFFF 01 27 04 01 0F 53 01 09 00 01 2480:hcicmd 51 FC 10 FF FFFFFFFF 01 4E 04 01 0F 53 01 09 00 01 2DH1: 2402:hcicmd 51 FC 10 FF FFFFFFFFF 01 00 04 00 04 36 00 09 00 01 2441:hcicmd 51 FC 10 FF FFFFFFFF 01 27 04 00 04 36 00 09 00 01 2480:hcicmd 51 FC 10 FF FFFFFFFF 01 4E 04 00 04 36 00 09 00 01 2DH3: 2402:hcicmd 51 FC 10 FF FFFFFFFFF 01 00 04 00 0A 6F 01 09 00 01 2441:hcicmd 51 FC 10 FF FFFFFFFFF 01 27 04 00 0A 6F 01 09 00 01 2480:hcicmd 51 FC 10 FF FFFFFFFF 01 4E 04 00 0A 6F 01 09 00 01 2DH5: 2402:hcicmd 51 FC 10 FF FFFFFFFFF 01 00 04 00 0E A7 00 09 00 01 2441:hcicmd 51 FC 10 FF FFFFFFFF 01 27 04 00 0E A7 00 09 00 01 2480:hcicmd 51 FC 10 FF FFFFFFFFF 01 4E 04 00 0E A7 00 09 00 01 3DH1: 2402:hcicmd 51 FC 10 FF FFFFFFFFF 01 00 04 00 08 53 00 09 00 01 2402:hcicmd 51 FC 10 FF FFFFFFFFF 01 27 04 00 08 53 00 09 00 01 2402:hcicmd 51 FC 10 FF FFFFFFFF 01 4E 04 00 08 53 00 09 00 01 3DH3: 2402:hcicmd 51 FC 10 FF FFFFFFFFF 01 00 04 00 0B 28 02 09 00 01 2441:hcicmd 51 FC 10 FF FFFFFFFFF 01 27 04 00 0B 28 02 09 00 01 2480:hcicmd 51 FC 10 FF FFFFFFFFF 01 4E 04 00 0B 28 02 09 00 01

3DH5:	
	2402:hcicmd 51 FC 10 FF FFFFFFFFF 01 00 04 00 0F FD 03 09 00 01
	2441:hcicmd 51 FC 10 FF FFFFFFFFF 01 27 04 00 0F FD 03 09 00 01
	2480:hcicmd 51 FC 10 FF FFFFFFFFF 01 4E 04 00 0F FD 03 09 00 01
Н	lopping:
	1DH1:hcicmd 51 FC 10 FF FFFFFFFFF 00 00 04 01 04 1B 00 09 00 01
	1DH3:hcicmd 51 FC 10 FF FFFFFFFFF 00 00 04 01 0B B7 00 09 00 01
	1DH5:hcicmd 51 FC 10 FF FFFFFFFFF 00 00 04 01 0F 53 01 09 00 01
	2DH1:hcicmd 51 FC 10 FF FFFFFFFFF 00 00 04 00 04 36 00 09 00 01
	2DH3:hcicmd 51 FC 10 FF FFFFFFFFF 00 00 04 00 0A 6F 01 09 00 01
	2DH5:hcicmd 51 FC 10 FF FFFFFFFFF 00 00 04 00 0E A7 00 09 00 01
	3DH1:hcicmd 51 FC 10 FF FFFFFFFFF 00 00 04 00 08 53 00 09 00 01
	3DH3:hcicmd 51 FC 10 FF FFFFFFFFF 00 00 04 00 0B 28 02 09 00 01
	3DH5:hcicmd 51 FC 10 FF FFFFFFFFF 00 00 04 00 0F FD 03 09 00 01
S	top instructions:
h	cicmd 03 0C 00
BLE part:	
Т	ransmit instructions:
2	402:hcicmd 1E 20 03 00 25 00
2	440:hcicmd 1E 20 03 13 25 00
2	480:hcicmd 1E 20 03 27 25 00
S	top instructions:

hcicmd 03 0C 00