# Brookstone<sup>®</sup>

Brookstone® Sport True Wireless Bluetooth® Earbuds

IC:21530-70236B FCC ID: 2AGR4-70236B Instruction Manual

#### OVERVIEW



# **BUTTON CONTROL**

- Volume -, Previous Track (press once to decrease volume, press and hold for previous track)
- 2. Power On/Off, Play/Pause
- 3. Volume +, Next Track (press once to increase volume, press and hold for next track)

# BLUETOOTH® OPERATION

- 1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device.
- Turn one earbud on by pressing the power button for 7-10 seconds until the LED indicator light begins to flash. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode.
- 3. "BRKSTN EB" will appear on the Bluetooth device list, select "BRKSTN EB" to establish pairing. If instructed to enter a PIN code, please enter '0000'.
- Once the <u>one</u> earbud has been paired to the desired mobile device, the indicator light will turn blue to confirm successful pairing.
- Turn on the <u>second</u> earbud on by pressing the power button for 1-2 seconds. The two earbuds will then begin to pair to each other automatically.
- When you want to play audio from another Bluetooth device, disconnect the earbuds from the original device and follow steps 1-5 to re-pair the earbuds with a new Bluetooth enabled device.

#### HANDS-FREE OPERATION

- If you receive a call during Bluetooth mode, press the Power, Play/Pause button to answer the call. Press the button again to end the call.
- To reject a call during Bluetooth mode, press and hold the Power, Play/Pause button.
- To redial the last number called, double click the Power, Play/Pause button.

NOTE: Please press the Power, Play/Pause button on the earbud that you used to pair to your mobile device. For example, if you used the left earbud to pair to your device (step #2 in Bluetooth® operation), press the Power, Play/Pause button on the left earbud to use the hands-free call functions.

# CHARGING THE EARBUDS

- When the battery is low, please charge via the included USB cable. The charging time is approximately 1-2 hours and provides up to 6 hours of continuous operation.
- The LED indicator light will be red during charging and will turn blue once it is fully charged.

Front Cover page 02 page 03 page 04

### SPECIFICATION

PACKING LIST

User Manual

Travel Case

Bluetooth® Earbuds

· Silicone Earbud Covers

USB Charging Cable

Bluetooth specifications: CSR, Bluetooth® version 4.2, 64210

Support profile: A2DP, AVRCP, HSP, HFP

Transmission distance: up to 10m (This may vary based on environmental factors or the type of Bluetooth<sup>®</sup> device being used)

Built-in Lithium Polymer Battery: 100 mAh

USB Recharge voltage: 3.7V Frequency Response: 20hz-20Khz

# indicator

Status	Indicator
Charging	Red (solid)
Fully charged	Blue (solid)

## WARNING

- 1. Do not disassemble, repair, or modify the earbuds.
- 2. Do not place product in or near fire to avoid danger, as it uses a lithium battery.3. Avoid storage at extreme temperatures, this can shorten the
- battery life and may affect the earbuds.

  4. Keep the earbuds dry and do not store the earbuds in damp
- Keep the earbuds dry and do not store the earbuds in damp areas to avoid damage to the earbuds.
- 5. Avoid dropping the earbuds as it may cause damage the product.

### KIND REMINDER

- To prolong the earbuds life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.
- 2. When an error occurs with the earbuds, please turn off the earbuds and restart it to troubleshoot.
- 3. When the earbud power is low, the Bluetooth range may be affected. Please charge the earbuds to avoid disruptions during use.

PROBLEM	TROUBLESHOOTING METHOD
Unable to pair the earbuds with a mobile device	Inspect whether the earbuds are searching for a Bluetooth enabled device to connect to. If not, restart the earbuds.     Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices.     The power of the battery is insufficient, please recharge the earbuds.

PROBLEM	TROUBLESHOOTING METHOD
The music stops from time to time	Inspect the distance between the earbuds and the Bluetooth enabled device, it may exceed the Bluetooth transmission range.     Inspect if there is an obstacle between the earbuds and the Bluetooth enabled device.     The power of the battery is insufficient, please recharge the earbuds.
The sound is low or distorted	Inspect the volume of the connected earbuds or Bluetooth enabled device and adjust the volume as needed.     The power of the battery is insufficient, please recharge the earbuds
The Bluetooth indicator light remains OFF	The power of the battery is insufficient, please recharge the earbuds.     Restart the earbuds.

The *Bluetooth*<sup>®</sup> word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners.

Back Cover page 05 page 06 page 07

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1)this device may not cause interference, and(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables auxappareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :(1) l'appareil ne doit pas produire de brouillage, et(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre lefonctionnement.