
Maximus Bluetooth® Headphones

IC:21530-100157 FCC ID:2AGR4-100157 (вс

Instruction Manual

OVERVIEW



- 1. Microphone
- 2. LED Indicator Light
- 3. 3.5mm audio port
- 4. Micro USB Charging Port
- 5. Previous Track/Volume Up
- 6. Power, Play/Pause, Hands-Free
- 7.Next Track/Volume Down

BI LIFTOOTH® OPERATION

- 1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device.
- 2. Turn the headphones on by pressing the Power, Play/Pause, Hands-Free button for approximately 5 seconds until the LED indicator light begins to flash. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode.
- 3. "GEMLINE HP" will appear on the Bluetooth device list, select "GEMLINE HP" to establish pairing. If instructed to enter a PIN code, please enter '0000'.
- 4. The LED indicator light will flash slowly to indicate successful
- 5. When you want to play audio from another Bluetooth device, disconnect the headphones from the original device and follow steps 1-3 to re-pair the headphones with a new Bluetooth enabled device.

BUTTON CONTROL

- Power On/Off: Press and hold Play/Pause button
- Play/Pause: Short press Play/Pause button

•Volume Up/Previous Track: Short press + button once to increase volume. Press and hold to change music to previous

•Volume Down/Next Track: Short press - button once to decrease volume. Press and hold to change music to next

HANDS-FREE PHONE USE

- •Answer incoming call Short press Play/Pause button.
- •End call Short press Play/Pause button.
- •Redial last call Short press Play/Pause button twice.
- •Reject incoming call Press and hold Play/Pause button.

AUX PLAYBACK OPERATION

- 1. Turn on the headphones.
- 2. Connect the headphones to a smartphone, audio device, or laptop with the 3.5mm AUX cable (included).
- 3. The next/previous song, volume, and play/pause buttons can only be adjusted on the device that is connected through the 3.5mm AUX cable.

CHARGING THE HEADPHONES

- 1. When the battery is low, please charge via the included USB cable. The charging time is approximately 2 hours and provides up to 7 hours of continuous operation. Standby time is approximately 200 hours.
- 2. The LED indicator light will be red during charging and will turn white once it is fully charged.

WARNING

- 1. Do not disassemble, repair, or modify the headphones.
- 2. Do not place product in or near fire to avoid danger, as it uses a lithium battery.
- 3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the headphones.
- 4. Keep the headphones dry and do not store the headphones in damp areas to avoid damage to the headphones.
- 5. Avoid dropping the headphones as it may cause damage the product.

Front Cover page 02 page 03 page 04 page 05

SPECIFICATION

Model: Bluetooth® Headphone

Bluetooth Specifications Bluetooth® V4.2

Profiles supported: A2DP, AVRCP, HFP, HSPV

Wireless working range: 10M (without obstacles)

Built-in battery: Lithium Battery 300mAh USB Recharge voltage: DC 5V

Output power: 15mW

Frequency Response:: 20Hz-20KHz

PACKING LIST

- Bluetooth[®] Headphones
- USB Charging Cable
- · 3.5mm AUX cable
- Storage Pouch User Manual
- Gift Box

KIND REMINDER

DDOBLEM

- 1. To prolong the headphones life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.
- 2. When an error occurs with the headphones, please turn off the headphones and restart it to troubleshoot.
- 3. When the headphone power is low, the Bluetooth range may be affected. Please charge the headphones to avoid disruptions during use.

TROUBLESHOOTING METHOD

TITOBLEIN	THOOBELONGO THE WILLTHOD
Unable to pair the headphones with a mobile device	Inspect whether the headphones are searching for a Bluetooth enabled device to connect to. If not, restart the headphones. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. The power of the battery is insufficient, please recharge the headphones.

	PROBLEM	TROUBLESHOOTING METHOD
	The music stops from time to time	Inspect the distance between the headphones are the Bluetooth enabled device, it may exceed the Bluetooth transmission range. Inspect if there is an obstacle between the headphones and the Bluetooth enabled device. The power of the battery is insufficient, please recharge the headphones.
	The sound is low or distorted	Inspect the volume of the connected headphones or Bluetooth enabled device and adjust the volume as needed. The power of the battery is insufficient, please recharge the headphones.
	The Bluetooth indicator light remains OFF	The power of the battery is insufficient, please recharge the headphones. Restart the headphones.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Develop Canada's licence-exempt RSS(s). Operation is subject to the following two conditions

(1) This device may not cause interference.

(2) This device must accept any interference, including rference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Back Cover page 08 page 09 page 06 page 07