

## Feature

- Changeable high capacity lithium polymer battery
- Brightness adjustment, support switchable far/near LED light 30M
- Invisible IR LED 30M, record without disturbance
- High quality recording up to 1080P
- Support local playback without extra displayer
- WDR function recording
- Alarm buzzer sounds as emergency notification
- IP66 weatherproof
- RFID records the patrol route (optional)

# Languages included in this guidebook are:

1.	English	1
2.	Chinese (冬中)	11

#### **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution**: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

# **PRECAUTIONS**

- Thanks for purchasing our product. Please read instructions before using.
- When put battery's cover on, please make sure it's direction right.
- Do not attempt to service this unit yourself unless you are authorized to do so. Opening cover may exposure you to dangerous voltage or other hazards. Refer all servicing to qualified personnel only.
- Do not use sharp objects to touch the screen.

### **Accessory**



Battery\*2



Power Charge\*1



Micro USB\*1



3.5mm AV out \*1



Handle string \*1





Carry bag\*1

<sup>\*</sup> Power Charge Spec: DC 5V / 2000mA

## **Assembly**

When put battery's cover on after installing batter, please make sure the direction is right as below illustration.







- 1. Press 1st, open lighting LED mode
- 2. Press 2<sup>nd</sup>, open IR LED mode
- 3. Press 3<sup>rd</sup>, close all LED
- 4. (back to 1st)

In lighting LED mode, press bottom button will change 5 different light modes

- 1. Press 1st, weak light
- 2. Press 2<sup>nd</sup>, regular light
- 3. Press 3<sup>rd</sup>, highlight
- 4. Press 4<sup>th</sup>, quick flash
- 5. Press 5<sup>th</sup>, Slow flash
- 6. (back to 1st)



	Icon	illustration		
1		5	ON/OFF	
	lacksquare	Power	* Press the button 3 sec. to shut down	
2		Power Indicator	1. Green light: System is functional	
	Green	Power Indicator	2. Green light flashing: In IR LED mode	
3	Red	Record Indicator	Green light : Record is functional	
4	Mode	mode	Record, Photo and play mode	
5	Menu	Menu	Enter/ Exit	
6			Select items or adjust values	
	Δ	upward	2. In photo mode, this button will be digital zoom	
			in	
7		downward	Select items or adjust values     In photo mode, this button will be digital zoom.	
		downward	2. In photo mode, this button will be digital zoom out	
8		l less sont es a da	Enforce LED flashing and buzzing	
		Urgent mode	(Press again to shut up)	
			In record mode, click this button to start recording	
9	O/OK	Record / OK	* Press 3 sec to stop recording	
			In photo mode, Click this button to take a picture. In menu, this button is OK	
10/11	<u>₩</u> ♀		Upward/Downward button is for adjusting flash light	
	.ılíi	Switch	mode (Please refer to last page)	
			Punch Card	
			* Press the button to scan	
12		RFID (option)	1. Press once, it has 30 Seconds to let user do	
			scanning.	
			2. press one more time if fail to scan over 30 seconds	
13	SCRN	Power safe mode	Press the button to shut off/ wake up backlight	



I/O function		
( <b>2</b> )		

	I/O	illustration
1	SD CARD	Support up to 32G micro SD card
_		* Only support class 🛽
2	AV OUT	Output video and audio to TV
3	USB	For transmission and charge up
J		* Charge by USB needs about 12hr to full

# **Function**

## 1. Record mode



In record mode, user can adjust record resolution, looping reccording, time lapse, HDR, exposure ` record audio and Data stamp

Function	Remark		
	Offer 4 options:		
	1080FHD	1920x1080	
Resolution	720P	1280x720	
	WVGA	848x480	
	VGA	640x480	
Looping reccord	OFF · 3 min · 5 min and 10 min		
Time-lapse record	OFF \ 100ms \ 200ms and 500ms		
HDR OFF/ON			
Evnoguro	+0.0, -1/3, -2/3, -1.0, -4/3, -5/3, -2.0, +2.0, +5/3, +4/3,		
Exposure	+1.0, +2/3, +1/3		
record audio OFF/ON			
Data stamp	OFF/ON		

## 2. Photo mode



In photo mode, user can adjust capture, resolution, sequence, quality, sharpness, white balance, color, ISO, exposure, anti-shaking, quick review and data stamp

Function	Remark		
Capture	OFF > 2S timer, 5S timer, 10s timer		
	12M	4032x3024	
	10M	3648x2736	
	8M	3264x2448	
Resolution	5M	2592x1944	
Resolution	3M	2048x1536	
	2MHD	1920x1080	
	VGA	640x480	
	1.3M	1280x960	
Sequence	OFF/ON		
Quality	Fine, Normal, Economy		
Sharpness	Strong, Normal, Soft		
White Balance	alance Auto, Daylight, Cloudy, Tungsten, Fluorescent		
Color, Black & White, Sepia			
ISO	Auto \ 100 \ 200 \ 400		
Exposure	+0.0, -1/3, -2/3, -1.0, -4/3, -5/3, -2.0, +2.0, +5/3, +4/3,		
Exposure	+1.0, +2/3, +1/3		
Anti-Shaking OFF/ON			
Quick Review	Quick Review OFF, 2 Seconds, 5 Seconds		
Date Stamp OFF, Date, Date/Time			

### 3. Play mode




In play mode, user can select delete, protect or playback files by slide show

### 4. Setup mode



In Setup, user can adjust date/time, language, TV mode, RFID mode, frequency, format, default setting and check version

\*RFID records will be saved on Excel in SD card




Function	Remark		
Date/Time	YY/MM/DD \ MM/DD/YY \ DD/MM/YY		
Language	Deutsch · Italiano · Simple Chinese · Traditional Chinese · Pyccknn · Japan · English · Francais ·		
Language	Espanol · Portugues ·		
TV Out	NTSC/ PAL		
RFID	8 Digit \ 10 Digit		
Frequency	50Hz · 60Hz		
Format	Format SD Card		
Format	* SD Card must be formatted when it's used at the first time		
Default Return to factory setting			
Version	Machine software version information		

# **Specification**

3MP CMOS
2034 X 1296 Pixels
6mm
H.264
MOV
1920 X 1080 30FPS
JPEG
2034 X 1296
Build in
0 LUX
CREE 3W LED X 2
OSRAM IR LED X 1
3 section switch
φ=3.5mm Phone jack
Micro USB
CD, Resolution : 320*240 pixels
MICRO SD max 32GB
Buzzer
125kHz (Optional)
3.7V 5000Ah Lithium
284mm X 60.5mm
2~5hr
630g (Include battery)

# Size



 $\underline{\mathsf{Unit}}$ : mm

### $\divideontimes$ Compatible SD card after testing as below:

Brand	Capacity	Spec.	Brand	Capacity	Spec.
Kingston	8G	CLASS 10	RiDATA(Y32GD38)	32G	CLASS 10
Transcend(9161BA)	8G	CLASS 10	Kingston(SDC10)	32G	CLASS 10
Transcend(9155A4)	16G	CLASS 10	Transcend(9173BA))	32G	CLASS 10
ADATA(G16G)	16G	CLASS 10	SanDisk(Ultra)	32G	CLASS 10
Apacer(E516G)	16G	CLASS 10	SONY(SR-32UY)	32G	CLASS 10

# 產品特點

- 1080P H.264 高畫質錄影
- 使用高容量鋰充電電池(標準 26650 型式),並可自行更換
- 可調亮度遠近的強力白光 LED 燈
- 具備夜視不可見紅外線光,可在不驚擾拍攝物下錄影。有效距離 30M
- 本機影像回放
- WDR 寬動態錄影
- IP66 防水規格
- ■警示蜂鳴器
- RFID 接收模組 (選配品)

# 使用須知

#### ◆前言

感謝您購買本公司手持行動記錄器.

在正式使用之前,請仔細閱讀該手冊,以確保正確使用該產品。妥善保存該手冊, 以備將來不時之需。

### ◆侵犯版權警告

請注意本產品僅供個人使用,其使用方法不得觸犯或侵害國際或國內的版權法規。 即使所錄製的影像僅供個人使用,請注意在某些狀況下運用本產品錄製表演、展覽或 商業活動的影像可能侵犯別人的版權或其他法律權益。

#### ◆注意事項

- 請勿在設備上堆放物品,勿壓按螢幕,否則可能導致螢幕破損。
- 請勿使用尖銳物體接觸螢幕,以免損壞螢幕。

#### ◆使用環境

- 該產品可使用在如物流及軍警保全巡邏、手持攝影等用途亦可當作手電筒照明設備 使用。

### 配件







USB電源充電器\*1












\* 電源充電器規格為 DC 5V / 2000mA


#### 安裝說明

安裝電池完畢後,鎖附電池蓋須注意接點是否有對準機器上的接點。

#### 如下圖圈記處:



### 手電筒啟用模式狀態說明:



- 5. 按壓第一次,開啟白光 LED 照射模式
- 6. 按壓第二次,開啟紅外線 LED 模式
- 7. 按壓第三次,關閉所有 LED 燈
- 8. 按壓第四次,開啟白光 LED 照射模式 (循環進行)

白光模式下,按壓按鍵切換強弱模式


- 7. 第一次按壓, LED 光源為弱
- 8. 第二次按壓, LED 光源為中
- 9. 第三次按壓, LED 光源為強
- 10. 第四次按壓, LED 光源為快閃爍
- 11. 第五次按壓, LED 光源為慢閃爍
- 12. 第六次按壓, LED 光源為弱 (回到模式 1,循環進行)

## 前按鍵功能說明



	位置	圖示	說明			
	1	(h)	電源鍵	開啟或關閉電源		
			电冰蜒	* 壓住按鍵 3 秒關閉電源		
	2		電源指示燈	綠燈恆亮表機器正常運作中		
		綠燈	电冰扫小湿	綠燈閃爍表 IR 燈開啟中		
	3		錄影指示燈	紅燈恆亮表機器處於錄影狀態下		
		紅燈	2000 JU 1 1/1	WE'LE IT O IN MAIN WE'N VENING IN VIEW I		
	4	Mode	拍攝模式	模式切換:可選擇錄影、拍照或播放		
	5	Menu	主選單	進入主選單;離開目前選單		
	6	<b>A</b>	向上	選擇選單項目或調整數值		
				拍照模式下為數位放大之拉近功能		
	7		向下	選擇選單項目或調整數值		
				拍照模式下為數位放大之拉遠功能		
	8		緊急模式開啟	LED 閃爍及蜂鳴器鳴叫 (再按一次就會關閉功能)		
	9			錄影模式下點擊即啟動錄影		
		9		* 壓住按鍵 3 秒結束錄影		
				ッポ ポノ <i>ラ</i> ん 1口 パポ 政 <del>と</del>	拍照模式下為快門鍵	
				選單設定時為 OK 鍵		
	10/11	₹ Ĝ	滑動開關	上推為調整照明模式(細部動作如上頁說明)		
		.ılíi	/月 到   刑   例	下推為亮度調整(細部動作如上頁說明)		
	12		RFID (選配)	巡邏點打卡功能		
		.2 <u> </u> RI		* 按壓一次啟動 30 秒偵測,		
			, ,	1.30 秒內掃瞄到資料,則立即結束掃描.再壓一次重啟掃描.		
				2.30 秒內未掃描到資料,自動結束掃描再壓一次重啟掃描.		





13

SCRN

編號	圖示	說明
1	SD CARD	最高支援到 32G 的 MICRO SD card
_		* 僅支援使用 class 10 規格的記憶卡
2	AV OUT	透過 AV 線可直接將影像傳輸到電視畫面
2		*播放檔案時包含聲音撥放
2	USB	用於 PC 檔案存取或 USB 充電用
3		* 使用 PC USB 充電需時約需 12hr 充滿電池。

按壓第一次關閉螢幕,再按一次開啟螢幕(循環)

螢幕開啟/關閉

# 各項功能說明

#### 1. 錄影模式



在此模式下可調整錄影影像的解析度、是否循環 錄影及循環錄影的時間選擇、間隔錄影、HDR、 曝光、錄影聲音及日期記錄。

功能	設定值		
	有 4 種錄影解析度可選擇:		
	1080FHD	1920x1080	
解析度	720P	1280x720	
	WVGA	848x480	
	VGA	640x480	
循環錄影	關、3分鐘、5分鐘及10分鐘,四種條件可選擇		
間隔錄影	關、100ms、200ms 及 500ms,四種條件可選擇		
HDR	關或開		
曝光	+0.0, -1/3, -2/3, -1.0, -4/3, -5/3, -2.0, +2.0, +5/3, +4/3,		
Maje / U	+1.0, +2/3, +1/3		
錄影聲音	選擇錄影聲音關或開		
日期記錄	選擇日期記錄關或開		

#### 2. 拍照模式



在此模式下可調整拍照的拍攝方式、解析度、連拍、影像品質、銳利度、白平衡、色彩效果、ISO值、曝光值、防手震開啟或關閉的選擇、快速檢視及日期記錄。

功能	設定值			
拍攝方式	關、2 秒自拍、5 秒自拍及 10 秒自拍可選擇			
	有 8 種拍照解析度可選擇:			
	12M	4032x3024		
	10M	3648x2736		
	8M	3264x2448		
解析度	5M	2592x1944		
	3M	2048x1536		
	2MHD	1920x1080		
	VGA	640x480		
	1.3M	1280x960		
連拍	關或開			
影像品質	較佳、一般、經濟			
銳利度	強烈、一般、柔和			

#### 3. 播放模式



在此模式下可刪除、保護或將影片作成幻 燈片模式播放。


功能	設定值
刪除	目前檔案或全部檔案
保護	保護目前檔案、解除保護目前檔案、保護所有檔案、解除保護所有檔案
幻燈片	2秒、5秒、8秒

#### 4 參數設定



在此模式下可調整影像顯示的日期/時間、語系選擇、電視輸出模式選擇、RFID模式選擇、頻率、記憶卡格式化作業、恢復預設值及設備的版本資訊。

\* RFID 打卡紀錄會儲存於 SD 卡內的 Excel 檔案中。




功能	設定值		
日期/時間	有三種模式可切換		
	YY/MM/DD、MM/DD/YY、DD/MM/YY		
語系	   10 種語言可選擇:Deutsch、Italiano、簡體中文、繁體中文、Pyccknn、日本語、English、		
	Francais · Espanol · Portugues ·		
電視輸出	NTSC 或 PAL		
RFID	8 Digit、10 Digit (依各家使用的 RFID Take 切換)		
頻率	50Hz \ 60Hz		
格式化	記憶卡格式化作業		
	* 第一次使用該記憶卡時,請務必將記憶卡做格式化作業		
預設值	恢復出廠預設值		
版本	機器軟體版本資訊		

## 產品規格

3MP CMOS		
2034 X 1296 Pixels		
6mm		
H.264		
MOV		
1920 X 1080 30FPS		
JPEG		
2034 X 1296		
內置麥克風		
0 LUX(白光燈常開)		
CREE 3W LED X 2		
OSRAM IR LED X 1		
三段可切換		
φ=3.5mm Phone jack		
Micro USB		
1.5 英寸·解析度:320*240		
MICRO SD max 32GB		
內建蜂鳴器		
選配 (125KHz)		
3.7V 5000Ah 充電鋰電池		
283mm X 60.5mm		
2~5hr (依不同使用條件時間會有所不同)		
630g(含電池)		

# <u>尺寸</u>



<u>單位</u>:mm

### ※ 僅支援用 micro SD.卡, 如下表為建議的記憶卡規格及品牌。

品牌	容量	讀取速度	品牌	容量	讀取速度
Kingston	8G	CLASS 10	RiDATA(Y32GD38)	32G	CLASS 10
Transcend(9161BA)	8G	CLASS 10	Kingston(SDC10)	32G	CLASS 10
Transcend(9155A4)	16G	CLASS 10	Transcend(9173BA))	32G	CLASS 10
ADATA(G16G)	16G	CLASS 10	SanDisk(Ultra)	32G	CLASS 10
Apacer(E516G)	16G	CLASS 10	SONY(SR-32UY)	32G	CLASS 10