

 <h1>iTrack Easy</h1> <h2>USER GUIDE</h2> <p>Bluetooth Cloud Smart Tracker</p> <p>Lost it? Find it in seconds</p>	 <h1>iTrack Easy</h1> <h2>Benutzerhandbuch</h2> <p>Bluetooth Cloud Smart Tracker</p> <p>So haben Sie überall Zugriff auf Ihren smart Tracker</p>	<p><b>English</b></p> <p><b>STEP 1:</b> Please download App "iTrackEasy" from App Store or Google Play. Or scan the QR code to download.</p> <p><b>STEP 2:</b> Turn on Bluetooth. Make sure your phone Bluetooth is on.</p> <p><b>STEP 3:</b> Sign up for New User. Start "iTrackEasy" App and tap the "Sign Up".</p> <p><b>STEP 4:</b> Pair the iTrack to Your Phone. 1) Make sure to turn on your phone's Bluetooth. 2) Hold the iTrack device close to your phone. 3) Hold the button on the iTrack until you hear a beep and the LED starts flashing.</p> <p><b>Find My Phone via iTrack:</b> When iTrack is connected to your phone, hold the iTrack button and your phone will make sound alert.</p> <p><b>Find iTrack via Phone:</b> When iTrack is connected to your phone, open the iTrack App and tap the "Ring" icon on App, the iTrack will beep and LED will flash.</p> <p><b>Camera Remote:</b> The button on the iTrack also doubles as a camera remote. Never be left out of a group picture again.</p> <p><b>Separation Alarm:</b> When the phone and iTrack is out of range, both phone and iTrack will make sound alert.</p> <p><b>Trouble Shooting:</b></p> <table border="1"> <thead> <tr> <th>Issue</th> <th>Cause</th> <th>Solution</th> </tr> </thead> <tbody> <tr> <td>I'm asked to enter a PIN when trying to pair with my phone.</td> <td>You're trying to pair iTrack with your phone using the iTrackEasy App instead ("+" symbol in the top right corner).</td> <td>Pair iTrack with your phone using the iTrackEasy App instead ("+" symbol in the top right corner).</td> </tr> <tr> <td>iTrack is too far away from the phone.</td> <td>iTrack is too far away from the phone.</td> <td>Place iTrack close to your phone while pairing until you hear a beep.</td> </tr> <tr> <td>iTrack's battery is empty</td> <td>iTrack's battery is empty</td> <td>Replace the battery.</td> </tr> <tr> <td>The battery lasts only a few days.</td> <td>iTrack's control module is faulty.</td> <td>Replace the battery. If you have the same issue with a new battery, please contact us.</td> </tr> <tr> <td>iTrack's location does not appear on the map</td> <td>iTrack is turned off or the iTrackEasy App cannot access GPS.</td> <td>Activate GPS and make sure the iTrackEasy App can access your phone's GPS.</td> </tr> <tr> <td>My phone battery drains too fast.</td> <td>This is a rare issue that may occur with some phones and is related to the power consumption of GPS module or other components.</td> <td>Only activate GPS or Bluetooth when you actually need it, i.e., when you're looking for your iTrack. The more users pass by, the easier to find.</td> </tr> </tbody> </table> <p><b>Battery Safety Notes:</b></p> <ul style="list-style-type: none"> <li><b>WARNING!</b> Fire Hazard! Do not short-circuit batteries. Batteries may overheat or explode.</li> <li><b>WARNING!</b> Danger to life. Keep batteries out of the reach of pets and children. If swallowed, seek medical advice immediately.</li> <li><b>WARNING!</b> Do not expose batteries to water or fire. Do not attempt to charge non-rechargeable batteries. The batteries may explode.</li> </ul> <p><b>Last Seen location:</b> The App will record the last disconnection location in the map.</p> <p><b>Battery replacement:</b></p> <p><b>Mark as Lost:</b> If you lost your item, our iTrack network may help to find.</p> <p><b>IP Rating Notes:</b> The devices are rated to be splash proof only. Do not immerse the device in water to avoid irreparable damage.</p> <p><b>FCC Statement:</b> This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.</p> <p><b>Warranty Provisions:</b> The device has been manufactured and thoroughly tested to meet strict quality standards. The warranty covers defects in the material and manufacturing process. It does not cover product components that are subject to normal wear and tear (wear parts), or damage to fragile components such as switches, batteries or the casing. Consumer-inflicted damage, improper use of incorrect maintenance of the product will void the warranty.</p> <p><b>Disposal:</b> The packaging is made of eco-friendly, recyclable material. Should you experience a fault or manufacturing defect within 1 year of the date of purchase, we will repair or replace the product free of charge. Consumer-inflicted damage, improper use or incorrect maintenance of product will void the warranty.</p> <p><b>Warranty Period:</b> Should you experience a fault or manufacturing defect within 1 year of the date of purchase, we will repair or replace the product free of charge. Consumer-inflicted damage, improper use or incorrect maintenance of product will void the warranty.</p> <p><b>Caution:</b> Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p><b>RoHS:</b> Made in China/Qualified</p>	Issue	Cause	Solution	I'm asked to enter a PIN when trying to pair with my phone.	You're trying to pair iTrack with your phone using the iTrackEasy App instead ("+" symbol in the top right corner).	Pair iTrack with your phone using the iTrackEasy App instead ("+" symbol in the top right corner).	iTrack is too far away from the phone.	iTrack is too far away from the phone.	Place iTrack close to your phone while pairing until you hear a beep.	iTrack's battery is empty	iTrack's battery is empty	Replace the battery.	The battery lasts only a few days.	iTrack's control module is faulty.	Replace the battery. If you have the same issue with a new battery, please contact us.	iTrack's location does not appear on the map	iTrack is turned off or the iTrackEasy App cannot access GPS.	Activate GPS and make sure the iTrackEasy App can access your phone's GPS.	My phone battery drains too fast.	This is a rare issue that may occur with some phones and is related to the power consumption of GPS module or other components.	Only activate GPS or Bluetooth when you actually need it, i.e., when you're looking for your iTrack. The more users pass by, the easier to find.	<p><b>Deutsch</b></p> <p><b>STEP 1:</b> Holen Sie sich die App. Bitte laden Sie unsere APP "iTrack easy" aus dem App Store bzw. Google Play. Oder scannen Sie den QR-Code, um die Anwendung herunterzuladen.</p> <p><b>STEP 2:</b> Schalten Sie Ihr Bluetooth an. Stellen Sie sicher, dass das Bluetooth verbunden ist, drücken Sie die Taste am Tracker und auf Ihrem Telefon wird ein Alarm ertönen.</p> <p><b>STEP 3:</b> Melden Sie sich an. Starten Sie die App "iTrackEasy" und tippen Sie auf die Schaltfläche "Registrieren".</p> <p><b>STEP 4:</b> Verbinden Sie Ihren Tracker mit Ihrem Gerät. 1) Achten Sie darauf, dass Ihr Bluetooth eingeschaltet bleibt. 2) Halten Sie Ihren Tracker in die Nähe des Geräts. 3) Halten Sie die Taste auf dem Tracker gedrückt bis Sie einen Signalton hören und die LED zu blinken beginnt.</p> <p><b>Finden Sie Ihr Gerät via iTrack:</b> Wenn Ihr Tracker mit dem Telefon verbunden ist, drücken Sie die Taste am Tracker und auf Ihrem Telefon wird ein Alarm ertönen.</p> <p><b>Finden Sie Ihren iTrack via Phone:</b> Wenn Ihr Tracker mit dem Telefon verbunden ist, öffnen Sie die iTrack App und tippen Sie auf das Symbol "Ring". Der Tracker gibt einen Signalton aus und die rote LED beginnt zu blinken.</p> <p><b>Kamera Auslöser:</b> Die Taste auf dem Tracker dient auch als Kamera-Fernbedienung. Perfekt zum erstellen von Gruppenbildern.</p> <p><b>Trennungs Alarm:</b> Wenn Ihr Telefon und iTrack geben einen Signalton aus, wenn die Verbindung zum Gerät getrennt wird.</p> <p><b>Fehlersuche:</b></p> <table border="1"> <thead> <tr> <th>Fehler</th> <th>Ursache</th> <th>Lösung</th> </tr> </thead> <tbody> <tr> <td>Bei Kopplung mit Smartphone wird PIN-Code abgefragt.</td> <td>Verbindung wird nicht über die iTrack-App, sondern die smartphone Bluetooth Einstellung hergestellt.</td> <td>Koppeln Sie den iTrack direkt über die App ("+" symbol rechts oben).</td> </tr> <tr> <td>iTrack kann nicht gekoppelt werden.</td> <td>Bluetooth ist ausgeschaltet.</td> <td>Schalten Sie in Den Systemeinstellungen Ihres smartphones Bluetooth.</td> </tr> <tr> <td>Der iTrack ist zu weit vom smartphone entfernt.</td> <td>Der iTrack ist zu weit vom smartphone entfernt.</td> <td>Halten Sie den iTrack beim Koppeln möglichst nah an das smartphone, bis er piept.</td> </tr> <tr> <td>Die Batterie im iTrack ist leer.</td> <td>Die Batterie entleert sich innerhalb weniger Tage.</td> <td>Wechseln Sie die Batterie.</td> </tr> <tr> <td>Das Steuerungsmodul des iTrack ist defekt.</td> <td>Standort wird nicht auf der Karte angezeigt.</td> <td>Sollte auch die Austauschbatterie schnell entleert sein, reklamieren Sie den iTrack bei uns.</td> </tr> <tr> <td>GPS ist ausgeschaltet oder die iTrack-App hat keinen Zugriff auf GPS.</td> <td>Der Akku des smartphone entleert sich schnell.</td> <td>Stellen Sie GPS an und Stellen Sie sicher, dass die iTrack-App zugriff auf GPS hat. Sie können GPS und ggf. weinigen smartphones auf deaktivieren und nur bei Bedarf - wenn Sie Ihren iTrack suchen - aktivieren.</td> </tr> </tbody> </table> <p><b>Sicherheitshinweise Für Batterien:</b></p> <ul style="list-style-type: none"> <li><b>ACHTUNG!</b> LEBENSGEFAHR! Batterien gehören nicht in Kinderhände. Lassen Sie Batterien nicht offen herumliegen. Es besteht die Gefahr, dass diese von Kindern oder Haustieren verschluckt werden. Suchen Sie im Falle eines Verschlucks sofort einen Arzt auf.</li> <li><b>ACHTUNG!</b> BRANDGEFAHR! Batterien dürfen nicht zerbebrochen werden. Überhitzung, Brandgefahr oder Platzen können die Folge sein.</li> <li><b>ACHTUNG!</b> Werfen Sie Batterien nicht ins Feuer oder Wasser. Laden Sie Batterien, die nicht aufladbar sind keinesfalls auf. Die Batterien können explodieren.</li> </ul> <p><b>Garantiebestimmungen:</b></p> <p>Das Gerät wurde nach strengen Qualitätsrichtlinien sorgfältig produziert und vor Auslieferung gewissenhaft geprüft. Die Garantieleistung gilt für Material- oder Fabrikationsfehler. Diese Garantie erstreckt sich nicht auf Produkteile, die normale Abnutzung ausgesetzt sind und daher als Verschleißteile angesehen werden können oder für Beschädigungen an zerbrechlichen Teilen, z.B. Schalter, Batterien, Gehäuse. Diese Garantie verfällt, wenn das Produkt beschädigt, nicht sachgemäß benutzt oder gar nicht eingehalten.</p> <p><b>Garantiefrist:</b> Tritt innerhalb von 1 Jahren ab dem Kaufdatum diese Produkts ein Mangel oder Fabrikationsfehler auf, wird das Produkt von uns für Sie kostenlos repariert oder ersetzt. Diese Garantie verfällt wenn das Produkt beschädigt, nicht sachgemäß benutzt oder gar nicht eingehalten.</p> <p><b>Entsorgung:</b> Die Verpackung besteht aus umweltfreundlichen Materialien, die Sie über die örtlichen Recyclingstellen entsorgen können. Defekte oder verbrauchte Batterien müssen gemäß Richtlinie 2006/66/EG und deren Änderungen recycelt werden. Sie können giftige Schwermetalle enthalten und unterliegen der Sondermüllbehandlung.</p> <p><b>RoHS:</b> Made in China/Qualified</p>	Fehler	Ursache	Lösung	Bei Kopplung mit Smartphone wird PIN-Code abgefragt.	Verbindung wird nicht über die iTrack-App, sondern die smartphone Bluetooth Einstellung hergestellt.	Koppeln Sie den iTrack direkt über die App ("+" symbol rechts oben).	iTrack kann nicht gekoppelt werden.	Bluetooth ist ausgeschaltet.	Schalten Sie in Den Systemeinstellungen Ihres smartphones Bluetooth.	Der iTrack ist zu weit vom smartphone entfernt.	Der iTrack ist zu weit vom smartphone entfernt.	Halten Sie den iTrack beim Koppeln möglichst nah an das smartphone, bis er piept.	Die Batterie im iTrack ist leer.	Die Batterie entleert sich innerhalb weniger Tage.	Wechseln Sie die Batterie.	Das Steuerungsmodul des iTrack ist defekt.	Standort wird nicht auf der Karte angezeigt.	Sollte auch die Austauschbatterie schnell entleert sein, reklamieren Sie den iTrack bei uns.	GPS ist ausgeschaltet oder die iTrack-App hat keinen Zugriff auf GPS.	Der Akku des smartphone entleert sich schnell.	Stellen Sie GPS an und Stellen Sie sicher, dass die iTrack-App zugriff auf GPS hat. Sie können GPS und ggf. weinigen smartphones auf deaktivieren und nur bei Bedarf - wenn Sie Ihren iTrack suchen - aktivieren.
Issue	Cause	Solution																																											
I'm asked to enter a PIN when trying to pair with my phone.	You're trying to pair iTrack with your phone using the iTrackEasy App instead ("+" symbol in the top right corner).	Pair iTrack with your phone using the iTrackEasy App instead ("+" symbol in the top right corner).																																											
iTrack is too far away from the phone.	iTrack is too far away from the phone.	Place iTrack close to your phone while pairing until you hear a beep.																																											
iTrack's battery is empty	iTrack's battery is empty	Replace the battery.																																											
The battery lasts only a few days.	iTrack's control module is faulty.	Replace the battery. If you have the same issue with a new battery, please contact us.																																											
iTrack's location does not appear on the map	iTrack is turned off or the iTrackEasy App cannot access GPS.	Activate GPS and make sure the iTrackEasy App can access your phone's GPS.																																											
My phone battery drains too fast.	This is a rare issue that may occur with some phones and is related to the power consumption of GPS module or other components.	Only activate GPS or Bluetooth when you actually need it, i.e., when you're looking for your iTrack. The more users pass by, the easier to find.																																											
Fehler	Ursache	Lösung																																											
Bei Kopplung mit Smartphone wird PIN-Code abgefragt.	Verbindung wird nicht über die iTrack-App, sondern die smartphone Bluetooth Einstellung hergestellt.	Koppeln Sie den iTrack direkt über die App ("+" symbol rechts oben).																																											
iTrack kann nicht gekoppelt werden.	Bluetooth ist ausgeschaltet.	Schalten Sie in Den Systemeinstellungen Ihres smartphones Bluetooth.																																											
Der iTrack ist zu weit vom smartphone entfernt.	Der iTrack ist zu weit vom smartphone entfernt.	Halten Sie den iTrack beim Koppeln möglichst nah an das smartphone, bis er piept.																																											
Die Batterie im iTrack ist leer.	Die Batterie entleert sich innerhalb weniger Tage.	Wechseln Sie die Batterie.																																											
Das Steuerungsmodul des iTrack ist defekt.	Standort wird nicht auf der Karte angezeigt.	Sollte auch die Austauschbatterie schnell entleert sein, reklamieren Sie den iTrack bei uns.																																											
GPS ist ausgeschaltet oder die iTrack-App hat keinen Zugriff auf GPS.	Der Akku des smartphone entleert sich schnell.	Stellen Sie GPS an und Stellen Sie sicher, dass die iTrack-App zugriff auf GPS hat. Sie können GPS und ggf. weinigen smartphones auf deaktivieren und nur bei Bedarf - wenn Sie Ihren iTrack suchen - aktivieren.																																											