Bluetooth speaker

00T24300 User Manual



WARNING

Please read and follow all of the instructions & safety precautions detailed below prior to using this product. Failure to do so may result in serious personal injury and / or property damage.

Safety Precautions

- Do not expose this product to heat sources (including open flame or direct sunlight).
- Do not expose this product to water or liquids. If liquid enters the product, immediately unplug the product from any connected power sources or devices.
- Do not disassemble or modify the product.
- Avoid dropping this product (or any other heavy impact which might damage the internal circuit).
- In the unlikely event of any abnormalities (such as strange odor, overheating, leaking, color change, etc.), discontinue use immediately.
- Avoid cleaning this product using liquids or chemical substances (use dry cloth only).
- Only use attachments/accessories specified by the manufacturer.
- Dispose of this item properly (do not dispose of it in trash receptacles and do not attempt to incinerate it).
- Do not leave this product unattended while it is in use or while it is being charged.
- This product is not a toy: KEEP AWAY FROM CHILDREN.
- Only re-charge this device using a USB port wall adapter (not included).
- Do not re-charge via USB port on a computer.
- Do not use this product while it is being charged.
- When not being used for prolonged periods of time please charge every 3 months to avoid damaging the battery.

The **00T24300** is a water resistant (IPX4) Wireless V2.1 speaker which includes a carabiner for enhanced portability. Please read below product specifications & user guide.

00T24300 Specifications

Battery Type: Grade A Non-Recycled Lithium Polymer battery

Battery Duration/Lifespan: 300 times

Capacity: 300 mAh

Power Input & Current: DC 5V/0.5A Sound Output: 3Watts x 1 speaker

Sensitivity: 80dB

Frequency Response: 100HZ-18KHZ Wireless Version: Wireless V2.1

Distortion Rate: <1%

Range of Wireless Communication: 10 meters

Charge Time (0-100%): 2 hours Playback Time: 3.5 hours


Accessories: micro-USB charging cable

Product Size: 41/4" x 31/2" x 11/2"

Net Weight: 113g

Water Resistant IPX level 4: Water splashing against the enclosure from any direction shall have no harmful effect.

00T24300 Product Map



00T24300 Operation

NOTE: **00T24300** supports wireless connections only (no integrated AUX input)

- a. Remove dust cover & turn speaker switch ON (Blue LED light will flash quickly to indicate speaker is ready for pairing).
- b. Activate Bluetooth on your audio device and select Bluetooth signal **speaker 00T24300** (blue LED light will remain lit when devices are successfully paired)
- c. To DISCONNECT from wireless mode, press & hold the ▶ button for 3 seconds
- d. To power off, remove dust cover and switch OFF

NOTE: previously paired devices will automatically re-connect to the **00T24300** speaker when both devices are turned on & within range.

2. Operation in Wireless Mode

- 1) Press to play/pause in music mode (Blue LED will flash slowly when music is paused)
- 2) + Press quickly to skip to next song/Press & hold to increase the volume
- 3) Press quickly to skip to previous songs/ Press & hold to decrease the volume
- 4) Press to answer/end incoming call

To Charge 00T24300

- **a.** Insert the Micro-USB charging cable into the speaker & connect USB output to a wall adapter (not included).
- **b.** Red LED light indicates the speaker is in charging mode (LED light will turn off when speaker is fully charged)

FCC Statement

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help
- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

