### Bluetooth® Speaker Audio+XL

The sound of the joy of life. The **Audio+XL** brings innovation and quality together with music to reflect a modern and mobile lifestyle. With high bass and power, this quality Bluetooth<sup>®</sup> spoaker is ideal for use at hon on the move. An installated, transparent LED-ring is available in 14 colors and lights up when the speaker is ready to be connected.

#### Application

To turn on the **Audio+XL** press the power button (1). You are greeted by a friendly." Hello, start pairing." The LED display (2) flashes in blue to indicate that the device is ready to be connected.

Make sure that the bluecoup!\* function of your mobile-device is switched on. You can enteck this in the settings of your device in the Audio-Y. It then appears an the display of your device. Set up the connection to appring an endor-Y. On you display, The LED display (2) lights up blue when the connection is successful.

000000

To switch the Audio+ XL off, press and hold the power button (1) until you are greeted by a friendly "Goodbye" Once you play a song, the LED display (2) flashes blue in about 3- second intervals.

The playback can be paused by a short press of the power button (1). By a second pressing you can resume playback again.

To select the next / previous song, please either use the corresponding function of your device or the corresponding buttons on the back of the speaker (3).

The volume can be adjusted directly with the buttons on the back of the speaker (4) or with the function on your mobile device.

You can connect the **Audio+XI** L toyour PC / Paptop by using the included audio cable. To do this, connect the saminais that go the reactiop part (8) on the **Audio+XI**, and put the other 3.5 mm/ jack plug (5) into the Readprine potenty or your PC/ Taplop.

# Charging the Audio+ XL

Plug the supplied USB cable into the micro USB port (6) and then connect the cable to an appropriate USB pages from included for to uSB port of a numing outquet. The Lib indicator (19) this to printed while charging. The Lib Indicator turns of automatically when the Auddor XL is talk charged.

Specifications

Battery:1000mAh - Bluetooth version: V2.1+EDR - Playing time: 4-6 hours - Bluetooth range: 8-10m outdoors - Charging time: 2 - 2.5 hours - Power; 5-watts

Technical changes and errors reserved!

## Safety instructions

A remodeling or modification of the product impairs the product safety. Risk of injury. Do not open the product. Never perform repairs by yourself!

To prevent damage to the device, do not drop the unit and avoid impact. Do not expose the product to moisture Avoid extreme cold and heat. The product is not suitable for children because it contains fragile, small and swallowable parts.

Notes on disposal: This electrical appliance does not belong in the household waste. For proper disposal, contact a public collection point in your community. Please note warnings in your area regarding the use of electronic devices (for example, near medical equipment).

8 Bluetooth CE RSHS

king Klio-Eterna Schreibgeräte GmbH & Co KG - Klio-Eterna - Glashüttenweg 7 - 77709 Wolfach - Germany

### Bluetooth® Speaker Audio+ XL

Der Klang eines Lebensgefühls: Beim Audio+ XL verbinden sich Botschaften wie Innovation und Qualität mit Musik zu einem modernen, mobilen Lebensgefühl. Der hochwerfige Bletchoth<sup>eit</sup> Laussprecher ist mit ordentlich Bass und Power aber auch zu Hausse. Ein integrierter, transparenter LED-Ring ist in 14 Farben erhältlich und zeigt die Berichobsbereischaft.

#### Anwendung

Zum Anschalten des **Audio+XL** drücken Sie den Powerknopf (1). Sie werden mit einem freundlichen "Hello, start pairing" begrüßt. Die LED-Anzeige (2) blinkt blau, um zu signalisieren, dass das Gerät bereit ist

Vergewissern Sie sich, dass die Bluetoothe Funktion Ihres mobilen of the progression of the progression of the progression of the St. Dies komen sie in der Einstellungen Ihres Endgesdies politich Aschleißend wird Ihren die Audler AL zur Auswahl in Hirmen Endgesdies politich Aschleißend wird in hen die Audler AL zur Auswahl in Hirmen Endgesdies politich Aschleißend wird in hen die Verbindung erfolgreich hergestellt wurde. Sobald Sie einen Musiktitied abspielen blinkt die LED Anzeige (2) ca. im 3-Sekundentakt kurz blau auf.

909900

Zum Ausschalten des **Audio÷ XL** drücken Sie den Powerknopf (1) solange bis Sie freundlich mit einem "Goodbye" verabschiedet wurden.

Durch ein kurzes Drücken des Powerknopfs (1) kann die Wiedergabe pausiert werden. Durch ein nochmaliges Drücken können Sie die Wiedergabe wieder aktivieren.

Um den nächsten/vorherigen Musiktitel auszuwählen, nutzen Sie bitte entweder die entsprechende Funktion Ihres Endgerätes oder die entsprechenden Knöpfe auf der Rückseite des **Audio+ XL** (3). Die Lautstärke können Sie ebenfalls über die entsprechenden Knöpfe (4) auf der Rückseite des Lautsprechers einstellen oder die Funktion an Ihrem Mobilgerät nutzen.

Sie können die Verbindung zum PC/Notebook mit Hilfre des beillegenden Audiokabets herstellen. Hierzu verbinden Sie der Sich Sich Mittelscher mit dem Audio-Engang in an Audio+ Rigang in an Audio+ Rigang in Mittelscher mit dem AC/Notebook.

# Aufladen des Audio+ XL

Stecken Sie hierzu das mitgelleferte USB-Kabel in den Micro-USB-Eingang (6). Verbinden Sie dam das Kabel mit einem passenden USB-Natztell inchti im Lieferunfrang enthalten) oder einem freien USB-Arschlüss eines eingeschalteren Computers. Die LED-Anzeige (2) leuchtet während des Ladevorgangs rot auf. Die LED-Anzeige erlischt automatisch, wenn der Audior +M. vollständig aufgebaben ist.

## Specifications

- Leistung: 5 Watt - Ladedauer: 2 - 2,5 Stunden - Bluetooth Version; V2.1+EDR - Bluetooth Reichweite: 8-10m im Freien - Akku: 1000mAh - Eingang: DC 5V, 560mA - Spieldauer: 4-6 Stunden

Technische Änderungen und Irrtümer vorbehalten!

## Sicherheitshinweise:

En Umbauen oder Verkeidern des Produktes beeinkraftig die Produkteinneit. Achture Werderungsgefahr Öffen ist Sich sortokkt rinnals eigenmächtig. Filter Sic Reparaturen me eulstr, aus Li zeen Sie das Cord kindr fallen und vermeidend Sis Stöte, um eine Beschäsfigtung des Greides zu verhindern. Satzen Sie das Produkt keiner Frachtigkeit oder Siegen aus, Vermeiden Sie zuden euternen Källen Hirzb. Das Produkt Sinnfrkt für Kreine geseigen, das siegen aus Vermeiden Sie zuden auf erum Källen der der beschrein Sie Warminweise in Ihrer Umgebung bezüglich der Verwenfung von elektronischen Geräten (z.B. in der Nähe von medizinischen Geräten).

Hinweis zur Entsorgung: Dieses Elektrogerät gehört nicht in den Hausmüll. Für die fachgerechte Entsorgung wenden Sie sich bitte an eine öffentliche Sammelstelle in ihrer Gemeinde.







Ind. Klio-Eterna Schreibgeräte GmbH & Co KG - Klio-Eterna - Glashüttenweg 7 - 77709 Wolfach - Germany

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. (5mm)

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.