Bluetooth Headphone

BT69

User Manual

SELUII IUM IUMS

Bluetooth version: Bluetooth V4.2 Support: HFPV1.2, A2DPV1.3, AVRCPV1.4, HSP1.6, GAVDP1.2, IOP

Sensitivity: -80dBm<0.1%BER Transmission distance: 10m

SNR: 96dB SNR stereo ADC and stereo DAC

Frequency: 2.402 -2.480GHZ Transmission power: CLASS2,

Audio SNR: >75dB Audio performance: SBC decoding

Battery capacity: 3.7V/200mAH Li-polymer battery Charging voltage: DC5V 250mA

Charging time: about 2 hour Working currency: ≤40mA

Standby currency: <500uA Working temperature: -40°C to +85°C

Play time: about 4 hours Working time: about 3.5 hours

Standby time: about 40 hours

OPERATION GUIDE

PARING

- Initial Pairing: Bluetooth headset will enter pairing mode automatically, sound prompt. Turn on Bluetooth function on devic and select BT69, no PIN code needed. Sound prompt when pairing successfully.
- 2. Re-Pairing: Long press II for about 3 seconds in power off mode, headset enter pairing mode when red and blue LED indicate lights flash quickly.
- 3. Bluetooth headset will pairing connected device automatically when power on.

LED INDICATOR LIGHT

- Charging: Red light keeps on in charging mode, light off when fu charged.
- 2. Power on: Blue light keeps on.
- 3. Pairing mode: Green and blue lights flashing alternately.
- 4. Standby mode: Blue light keeps on.
- 5. Paired mode: Blue light keeps on.6. Play mode: Blue light flash every 1 second.

ATTENTION

- 1. Please charge the Bluetooth headset when sound prompt.
- The port at the button of headset is for audio input only, please DO NOT connect other headphones.

FCC Statement

This equipment has been tested and found to comply with the lim for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection agains harmful interference in a residential installation. This equipment

mannial interreferice to radio communications, riowever, there is in

guarantee that interference will not occur in a particular installatio If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

-- Reorient or relocate the receiving antenna.

interference by one or more of the following measures:

that to which the receiver is connected.

undesired operation.

-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from

-- Consult the dealer or an experienced radio/TV technician for he This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cau harmful interference, and (2) this device must accept any interference received, including interference that may cause

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to opera