## Professional installation instruction

	Radio		Max. Gain (dBi)				Limit of MAX. Output Power(mW)			
No.		Anten		2.4G						
		na	вт	Hz	5GHz	Connector	BT	2.4GHz	5GHz	5GHz
		Туре		Ban	Band				U-NII-1	U-NII-3
				d						
1	Eth6-BCM43694	PIFA	1	-	5.9	IPEX	•	1	261.454	392.312
2	Eth7-BCM43694	PIFA	1	2.7	5.6	IPEX	ı	153.509	345.397	349.272
3	Eth8-BCM43694	PIFA	-	4.3	5.6	IPEX	-	350.273	-	711.904
4	Eth6-BCM43694	Patch	-	-	6	RPSMA	-	-	261.454	392.271
5	Eth7-BCM43694	Patch	-	4	6	RPSMA	-	154.328	345.397	349.272
6	Eth8-BCM43694	Patch	-	4	-	RPSMA	-	350.273	-	-
7	BT-BRF52832	Omni	0.1	-	-	IPEX	4.355	-	-	-
8	BT-BRF52832	Directi onal	4.5	-	-	IPEX	4.355	-	-	-

## 1. Installation personal

This product is designed for specific application and needs to be installed by a qualified personal who has RF and related rule knowledge. The general user shall not attempt to install or change the setting.

## 2. Installation location

The product shall be installed at a location where the radiating antenna can be kept 37cm from nearby person in normal operation condition to meet regulatory RF exposure requirement.

## 3. External antenna

Use only the antennas which have been approved by the applicant. The non-approved antenna(s) may produce unwanted spurious or excessive RF transmitting power which may lead to the violation of FCC limit and is prohibited.

## 4. Installation procedure

Please refer to user's manual for the detail.

## 5. Warning

Please carefully select the installation position and make sure that the final output power does not exceed the limit set force in relevant rules. The violation of the rule could lead to serious federal penalty.

## 1. Installation personal

This product is designed for specific application and needs to be installed by a qualified personal who has RF and related rule knowledge. The general user shall not attempt to install or change the setting.

## 2. Installation location

The product shall be installed at a location where the radiating antenna can be kept 0.38m from nearby person in normal operation condition to meet regulatory RF exposure requirement.

#### 3. External antenna

Use only the antennas which have been approved by the applicant. The non-approved antenna(s) may produce unwanted spurious or excessive RF transmitting power which may lead to the violation of IC limit and is prohibited.

## 4. Installation procedure

Please refer to user's manual for the detail.

## 5. Warning

Please carefully select the installation position and make sure that the final output power does not exceed the limit set force in relevant rules. The violation of the rule could lead to serious federal penalty.

# Instructions d'installation professionnelle

#### 1. Installation

Ce produit est destine a un usage specifique et doit etre installe par un personnel qualifie maitrisant les radiofrequences et les regles s'y rapportant. L'installation et les reglages ne doivent pas etre modifies par l'utilisateur final.

## 2. Emplacement d'installation

En usage normal, afin de respecter les exigences reglementaires concernant l'exposition aux radiofrequences, ce produit doit etre installe de facon a respecter une distance de 37cm entre l'antenne emettrice et les personnes.

#### 3. Antenn externe.

Utiliser uniiquement les antennes approuvees par le fabricant. L'utilisation d'autres antennes peut conduire a un niveau de rayonnement essentiel ou non essentiel depassant les niveaux limites definis par FCC, ce qui est interdit.

## 4. Procedure d'installation

Consulter le manuel d'utilisation.

#### 5. Avertissement

Choisir avec soin la position d'installation et s'assurer que la puissance de sortie ne depasse pas les limites en vigueur. La violation de cette regle peut conduire a de serieuses penalites federales.

#### 1. Installation

Ce produit est destine a un usage specifique et doit etre installe par un personnel qualifie maitrisant les radiofrequences et les regles s'y rapportant. L'installation et les reglages ne doivent pas etre modifies par l'utilisateur final.

## 2. Emplacement d'installation

En usage normal, afin de respecter les exigences reglementaires concernant l'exposition aux radiofrequences, ce produit doit etre installe de facon a respecter une distance de 0.38m entre l'antenne emettrice et les personnes.

#### 3. Antenn externe.

Utiliser uniiquement les antennes approuvees par le fabricant. L'utilisation d'autres antennes peut conduire a un niveau de rayonnement essentiel ou non essentiel depassant les niveaux limites definis par IC, ce qui est interdit.

#### 4. Procedure d'installation

Consulter le manuel d'utilisation.

#### 5. Avertissement

Choisir avec soin la position d'installation et s'assurer que la puissance de sortie ne depasse pas les limites en vigueur. La violation de cette regle peut conduire a de serieuses penalites federales.

## **DETACHABLE ANTENNA USAGE**

This radio transmitter (IC: 3970A-AP43 / Model: AP43E, AP43) has been approved by ISED to operate with the antenna type listed below with maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio(IC: 3970A-AP43 / Model: AP43E, AP43) a été approuvé par ISED pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

## Approved antenna(s) list

For External Antenna (support unit only)

· · · · · · · · · · · · · · · · · · ·								
Antenna Type	Patch							
Antenna Connector	RPSMA							
Part Number	ATS-00-245-46-4RPSP-36							
O : (ID:)	Frequency							
Gain (dBi)	2.4GHz	5GHz						
Ext. WIFI Ant. 1	4	6						