

User Guide













当触发起床间钟,手环会震动想醒,你可通过报一报手势关闭间钟。 4. 1938/EVE

各提醒模式下,指示灯闪烁显示。

来电缆醒	6
信息規程	
久坐提醒	ė,
防丢損醒	₹ 4 6
完成目标提醒	€ ♣ ₺
低电量提醒	

活动记录:记录追踪你每天的活动,在应用中你可以查看当日运动量 諸場所象: に家性がかせておさるが、仕屋市中かり以重を当日と功恵 及送动进度、能量消耗;職職记录: 手环设备可自动记录課報时长及监测深度課報及浅度障据;

辦職任策: 中午收留可用应加定等數的大公益的於地域地址以近级地址; 證如組織: 市场院的企 來 乌龙 等限的方式是障 事机场差: 手机器出一定范围内 (5m内),手环会发出震动提示; 理於拍應: 通过手环滤程温松手机进行拍照; 手环存储能: 通过于环滤程温松手机进行拍照; 手环存储能: 烟天一个小桶环,/天一个大桶环。每天边晨零点手环

用示的数据企自动演览 伯恩王匡内部企自动保存7平

• 在配对时无法找到手环?

· 请做认价的王和巴开户签牙,因时王机居干"专持贫用内" 配对时,请确保手环与手机问题在0.5米范围内,完成配对后篮牙 通信范围10米以内! 请检查手环是否有电量,进行充电后如仍未解决,请联系我们

O 什么偶尔会出现原牙连不上的情况? 部分手机的蓝牙服务再启动时偶尔会出现异常,导致出现这样的

情况; 通常重新开关手机蓝牙或重启手机,即可正常建立连接; o 如何恢复出厂设置

基本参数

主控芯片: Nordic 传感器: Kionix 主体重量: 大約18g 由沙类型:聚合物程由涉

T作温度:-10°C-45°C 防尘防水锈级: IP67

低功耗超长待机:超过7天

太产品循过去少益牙贮经信息处理 21及去少主环糖准算法 计光

黑色边框不要印刷

105克铜板纸

宽60X高95(mm)

















The smart band need to pair with the smart phone through app. Before downloading, please refer to working condition for mobile.

Way to download 1: Searching the QR code, scan and download app

Please use the QR code Scan tool to scan the following QR code and open the link and download app. In case there is any problem to open the link,








2. Device Activate & Charge

Open pair device in the upp, please make sure the Bluetooth is ON when pa the device. When searching and pairing device, please long press on the sc









off the alert by shaking it.

n each notification mode, the lights flashing	
Incoming call notification	(
SMS notification	
Long-sit notification	ů,
Anti-lost notification	(A i
Goal completion notification	€ ♠ ₺
Low energy notification	•

seems, comm amornmently recognize your state and monitoring the sleep progress with analyzing the deep sleep and light sleep hours; Notification Alerts: Alarm alert, call alert, sedentary alert, etc. by silent vibration;

Remote Camera Control:

O Cun't find device when pairing device?

Please make sure the device is near the smart phone wh 0.5m) and among the normal Bluetooth com-

after full charge, please contact us.

O Can't connect the device with app?

smart phone Bluetooth service will be abnormal when reboot. Please

O How to Restore Factory Defaults

CPU: Nordic

"Mine-SystemSetting" and choose "Reboot Device

Battery Type: Polymer Rechargeable Li Battery

Standby: more than 7 days

Battery Capacity: 50mAh Data Sync: Bluetooth 4.0
Working Temperature: -10C-45C
Dustproof and Waterproof level: IP67

O How to update the device

are essigned to provide resonance protection against turman interretence in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cusue harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particule

installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

This device complies with Part 15 of the FCC Rules. Operation is subject

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference

to the sonowing two continuous: (1) this device may not cause hamful interference, and (2) this device must accept any interference received, including that may cause undesired operation.

-- Reorient or relocate the receiving antenna

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.