Remote transmission circuit functional description

When the remote control forward, backward, left, right, each function by pressing the corresponding encoding chip function pin high level, after IC internal A/D conversion circuit, reduction of each function signal. After reduction each function signal, the IC internal to encode their corresponding instructions, encoded output.