







Main User Interfaces

- Earphones
 - Left earphone (slave)




- **1** Earwing
- 2 LED indicator
- 8 Eartip
- Charging Case



- 6 Charging Case Cover
- 1 Left earphone (slave)
- Right earphone(master)

Right earphone (master)




- Touch control(slave)
- Touch control (master)
- 6 Microphone



- 8 Charge indicator(slave)
- & Charge indicator(master)
- Micro USB connector

Get Started




STEP1 case and close the cover.

Put earphones into charging

*Notes:

Please charge the charging case via USB adapter in advance.



STFP2

Open the charging case then earphones will automatically get sync and enter pairing mode.

Bluetooth Pairing

Bluetooth pairing

For first usage of brand new FIIL T1, please refer to page 5 "Get Started", the earphone status indicator will continue to blink blue once entered pairing mode.

To begin a new bluetooth pairing, please press and hold the master earphone (right earphone) until the LED indicator blinks blue.

Search Connection

Enter setup menu of audio source devices, select "search device" in "Bluetooth" then select "FIII. T1" in the device list to connect

6







5

Bluetooth Sync

Auto-Sync

Please refer to page5 "Get Started", the left and right earphones will automatically get synced after Step2.

Manual Sync



1st Step

Place the earphones into charging case, press and hold both earphones untill power off (LED indicates red then off).



2nd Step

Press and hold both earphones again untill their LED indications light purple.




3rd Step

Close charging case then open again, the earphones will automatically get synced with flashing purple LED.

How to Control


User Interface



How to charge

Charge earphone

- When earphone reminds "recharge headset" or the LED indicator blinks red , that means battery is low and earphone should be charged.
- Place the earphone into charging case and close, then earphone will be charged.



*Notes: Earphone will power off during charging, so the left earphone (slave) can not be singly used if right earphone is being charged.

Charging Case indicator

 When the red LED indicator (left or right) is on, it means the corresponding earphone is being charged.



• When the red LED indicator is off, it means the corresponding earphone is fully charged.

How to charge

Recharge Charging Case

 When charging case is not able to charge earphone or its LED indicator blinks red, it means battery low and charging case shoule be recharged.

 Please open USB door at rear side of charging case, connect Micro USB cable with USB adapter to recharge charging case.



Charging Case indicator

 When both red LED indicators are light on, it means the charging case is being charged.



 When both red LED indicators are light off, it means the charging case and earphones are fully charged.

10

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirment. The device can be used in portable exposure condition without restriction.