
Outside


BATTERY INSTALLATION: VEHICLE


BATTERY INSTALLATION: VEHICLE

- 1. Turn your vehicle over, Rotate the battery latch to release the battery holder.

- 1. Turn your vehicle over. Rotate the battery
 2. Slide the battery holder toward the latch.
 2. Slide the battery holder toward the latch.
 3. Lift the battery holder out of the vehicle.









4. Insert 4 AA alkaline batteries into the battery holder, with polarity (+/-) as shown on the battery holder.

4. Insert 4 AA alkaline batteries into the battery holder, with polarity (+/-) as shown on the battery holder. 5. Replace the battery holder in the vehicle and rotate the latch until it clicks shut, locking the battery holder in

lace the battery holder in the vehicle and rotate the latch until it clicks shut, locking the battery holder in






BATTERY INSTALLATION: CONTROLLER

BATTERY INSTALLATION: CONTROLLER

Requires 2 AA type batteries (not included). Use a Phillips screwdriver to unscrew cover, note polarity of batteries, remove and replace with new ones as shown. Attach the cover and fasten screw. Never left a chilld use this product unless battery door is secure. Batteries are small objects and could be ingested. Keep all batteries away from small children.

n incluses). Dévisser le couvercle en utilisant un toumevis cruciforme, noter la polarité reconsists c pleas As (10th incubases), Jeversaler is couverfee est ususant in trothrevis crucinome, hoter as point des piles, network piles usedes of les remplacer par des piles neuves, Attacher le couverée de torrer la vis, jamais laisser un enfant utiliser ce produit si le comparies en est pas fermé. Les piles sont de pe objets qui risquent d'être avalèse. Tenir toutes les piles à l'écart des enfants en bas âge.



SAFETY INFORMATION

SAFETY INFORMATION

>>> NOTE TO ADULTS NOTE TO ADULTS

ults, this toy is recommended for children 8 years of age and older. To ensure that the child's play is both safe and fun, please review the operating instructions and these general safety rules with your child, ults, this toy is recommended for children 8 years of age and older. To ensure that the child's play is both safe and fun, please review the operating instructions and these anomend earlier value with your child.

>>> SAFETY TIPS SAFETY TIPS

- To avoid accidental operatum, returns a Do NUT joks by weblicel while it motion.

 Keep fingers, hair and loose clothing away from tires and wheels while the vehicle is switched ON, Adult supervision is recommended when this vehicle is being operated.

 To avoid accidental operation, remove all batteries when not in use,

DO NOT pick up vehicle while in motion.
 Keep fingers, hair and loose clothing away from tires and wheels while the vehicle is switched ON.
 Adult supervision is recommended when this vehicle is being operated.
 To avoid accidental operation, remove all batteries when not in use.
 CAUTION: Do not operate vehicle through water or snow. Electronic components
 CAUTION: Do not operate vehicle through water or snow. Electronic components

CAUTION: Do not operate vehicle through water or snow. Electronic components can overheat or be damaged as a result of contact with water.

>>> IMPORTANT BATTERY INFORMATION IMPORTANT BATTERY INFORMATION

- Do not use rechargeable batteries.
 Do not mix new and used batteries.
 Do not mix alkaline, standard or rechargeable batteries.
 Alkaline batteries are recommended,
 Non-rechargeable batteries are not to be recharged.
 Only batteries of the same or equivalent type as recommen
 Batteries are to be inserted with the correct polaries.
 Exhausted batteries are to be removed from the toy.
 The supply terminals are not to be short-circuited.
- Exnausted patteries are to be removed from the toy.

 The supply terminals are not to be short-circuited.

 Do not dispose of batteries in fire, batteries may explode or leak,

 Replace with new batteries at the first sign of erratic operation.

- Ne pas utilisar de pleis rechargeables.

 Ine faut pas melanger des piles neuves et usées,

 Ine faut pas melanger des piles neuves et usées,

 Ne pas mélanger des piles neuves et usées,

 Ne pas mélanger des piles neuves et usées,

 Les piles aleafines sont recommandées,

 elles piles aleafines sont recommandées,

 Les piles aleafines out des piles du type recommandé ou d'un type équivalent,

 Les piles doivent être introduites selon la polarité correcte.

 Les piles usées doivent être retirées du jouet,

 Be faut pas court-circuiter les bornes d'alimentation,

 Ne pas jeter les piles au feu car cela présante un risque d'explosion ou de fuite des piles,

 Remplacer les piles par des piles neuves dès que le fonctionnement devient irrègulier,

TROUBLESHOOTING TROUBLESHOOTING

- Vehicle runs slowly or will not run.

- hicle doesn't work after going through water

obable Cause Probable Cause

- Loose battery connection or vehicle switch not ON.
 Weak vehicle or transmitter batteries.
- nection or vehicle switch not ON. anamitter batteries,
- Radio interference likely.
 Radio interference likely.
- Water in the electronics area.

- Check battery connector and vehicle switch.
 Replace with fresh alkaline batteries.

- Change location (see point 2 Quick Tips).
 Change location (see point 2 Quick Tips).
- Vehicle will take serveral hours to dry, Allow to dry thoroughly overnight before trying again,
 Operate your vehicle in a dry area. Avoid driving in water and snow.
 Vehicle well take serveral hours to dry, Allow to dry thoroughly overnight before trying again,
 Operate your vehicle in a dry area. Avoid driving in water and snow.

WARNING: Not suitable for children under 3 years.

Bustrations may vary from actual products.

Please keep this instruction sheet as well as the packaging for future reference as it contains important information.

ATTENTION: No convient pas aux enfants de moins de 3 ans.

Les Bustrations peuvent êtré différentes du produit réel.

Veuillez conserver ce mode d'emploi et Femballage pour toute référence ultérieure aux informations importantes qu'ils contiennent,

Wicked Cool Toys 10 Canal Street, Suite 327, Bristol, PA 19007

28101**-I**SI

Æ

CAUTION: Surfaces

may become hot and cause burns if electronics get wet . Do not operate vehicle through water or snow.



CAUTION: Surfaces

may become hot and cause burns if electronics get wet . Do not operate vehicle through water or snow.

GET STARTED!

Your vehicle has an amazing Gyro Stabilizer that makes it easy to drive - and lets it perform amazing stunts! The stabilizer safely spins at high speed inside the rear wheel, and it works like a gyroscope to help keep your vehicle upright.

Your vehicle has an amazing Gyro Stabilizer that makes it easy to drive - and lets it perform amazing stunts! The stabilizer safely are the stabilizer that makes it easy to drive - and lets it perform amazing stunts! The stabilizer safely spins at high speed inside the rear wheel, and it works like a gyroscope to help keep your vehicle upright.

1. GET SET! 1. GET SET!

Energize the gyro stabilizer! Hold the vehicle off the ground and push the left control stick all the way forward. Once the stabilizer the gyro stabilizer! Hold the vehicle off the ground and push the vehicle from side to side you'll really feel it working!

Energize the gyro stabilizer! Hold the vehicle off the ground and push the left control stick all the way forward. Once the stabilizer to fill the way forward to the ground and push the left control stick all the way forward. Once the stabilizer the gyro stabilizer! Hold the vehicle off the ground and push the left control stick all the way forward. Once the stabilizer the gyro stabilizer!

Energize the gyro stabilizer! Hold the vehicle off the ground and push the left control stick all the way forward. Once the stabilizer the gyro stabilizer!

Energize the gyro stabilizer! Hold the vehicle off the ground and push the left control stick all the way forward. Once the stabilizer the gyro stabilizer!

Energize the gyro stabilizer!

Be sure to hold the vehicle by the drive figure, keeping your fingers clear of the wheels.

Be sure to hold the vehicle by the drive figure, keeping your fingers clear of the wheels. the drive figure, keeping your fingers clear of the wheels, the drive figure, keeping your fingers clear of the wheels.



2. LAUNCH IT! 2. LAUNCH IT!

Now gently hand-launch your vehicle. Set it on the ground and give it a gentle push while pushing the left stick forward. Now you're ready for the coolest stunt driving!

Now gently hand-launch your vehicle. Set it on the ground and give it a gentle push while pushing the left stick Now gently hand-launch your vehicle. Set it on the ground and give it a gentle push while pushing the left stick now you're ready for the coolest stunt driving! 2. LAUNCH IT! 2. LAUNCH IT!







CONTENTS

CONTENTS

VEHICLE VEHICLE



CONTROLLER CONTROLLER Right Stick - Contr Left Stick 0

Controls Forward & Braking Left Stick - Controls Forv & Braking

NOTE: Turn on both your vehicle and controller, LED light flashes indicating pairing in progress. When they are paired, the LED light on the vehicle is on. Then push either controller stick and you will be able to run and control your vehicle.

NOTE: Turn on both your vehicle and


run and control your vehicle.

NOTE: Turn on both your vehicle and controller, LED light flashes indicating pairing in progress. When they are paired, the LED light on the vehicle is on. Then push the controller stick and you will be able to run and control your vehicle.


>>> FEATURES FEATURES

- 2.4 GHz radio control 2.4 GHz radio control • Full function Full function
- Range up to 65' Range up to 198.1m

TOP VIEW TOP VIEW



BOTTOM VIEW BOTTOM VIEW



If you have questions about this vehicle, DO NOT RETURN IT TO THE STORE! Call 1.888.519.1392 for technical help and parts and service assistance.

297mmH (Folded Size摺後尺寸:210mmW x 29

QUICK START

OUICK START

Please read this Owner's Manual thoroughly, Please read this Owner's Manual thoroughly,

1, Start with a fresh set of batteries, 1, Start with a fresh set of batteries,


2. Turn wehicle switch OIL Press transmitter controls for un and control your vehicle.


3. When you're done driving, turn vehicle switch OFF, Remove all batteries for storage.


3. When you're done driving, turn vehicle switch OFF, Remove all batteries for storage.


OPERATING YOUR VEHICLE

OPERATING YOUR VEHICLE









Page 1 of 1

QUICK TIPS QUICK TIPS

away from these!

3. If your vehicle gets too far away, it won't work properly, Your maximum range should be about 65',

4. Don't drive your vehicle in sand or through water or snow. If your vehicle does get wet, wipe with a towel and allow to dry completely overnight.

5. Don't store your vehicle near heat or in direct sunlight. Always turn switch OFF and remove all batteries for storage.

1.When your vehicle starts to lose power, it may lose functions or performance. It's time for fresh batteries, Your vehicle's running time may change depending on your driving style.

2. Radio interference can make your vehicle run badly. Interference can be caused by other R/C vehicles running on the same frequency; electrical wires; large buildings; or C8 radios. Try to stay away from these!

DRIVING TIPS

1. You can also start with your vehicle resting on its side skid plate: push the left stick forward and steer with the right stick (into and then out of the turn). Your vehicle will get up and go! But remember: if you start this way, it'll take the stabilizer a little while to come up to full speed. And you'll get different results on different driving surfaces.

2. Your vehicle will run really well on hard packed dirt, asphalt and other similar surfaces,

3. When you want to stop, it's best to turn into a skid while braking, instead of hitting the brakes suddenty while going straight.

1. You can also start with your vehicle resting on its side skid plate; push the left is tick forward and steer with the right stick (into and then out of the turn), Your vehicle will get up and go! But remember: if you start this way, it'll take the stabilizer a little while to come up to full speed, And you'll get different results on different driving surfaces.

2. Your vehicle will get up and dother similar surfaces,

3. When you want to stop, it's best to turn into a skid while braking, instead of hitting the brakes suddenly while going straight.

8105






Inside

OPERATING YOUR VEHICLE OPERATING YOUR VEHICLE

>>> DIRT-DIGGIN' DONUTS! DIRT-DIGGIN' DONUTS!



Push the left stick forward to drive straight. Now use the right stick to steer hard (either right or left) into a leaning turn. Now let go of the sticks; your vehicle will glide to a stop on its side skid plate. Quickly, while the Gyro Stabilizer is still appinning, push the left stick all the way forward, and use the right stick to atteer "into" the donut. As your vehicle picks up speed, use the right stick to steer "out" of the donut and fring the vehicle upright.

Push the left stick forward to drive straight. Now use the right stick to steer hard (either right or left) into a leaning turn. Now let go of the sticks; your vehicle will gible to a stop on its side skid plate, Quickly, while the Gyro Stabilizer is still spinning, push the left stick all the way forward, and use the right stick to steer "into" the donut. As your vehicle will go the stop to the stick you do the donut and bring the vehicle upright.



This stunt works best on pavement or hard packed dirt.
This stunt works best on pavement or hard packed dirt.








>>> SIZZLIN' SOMERSAULTS! SIZZLIN' SOMERSAULTS!


For amazing somersault stunts, try driving your vehicle downhill, aiming at a small arramp or burn. When you drive over it, your vehicle may flip into a fearsome forward somersault!

For amazing somersault stunts, try driving your vehicle downhill, aiming at a small armp or burns, When you drive over it, your vehicle may flip into a fearsome forward somersault!





| SAMMIU, JAMWIC, SAMMIC, JAMWIC



Push the left stick all the way forward to accelerate, Drive your vehicle off a ramp or curb and watch it catch some "big air." For the smoothest jumps, keep the stick pushed forward during the jump. Depending on speed and ramp angle, your vehicle may land on both wheels - or in a full wheelie!

Push the left stick all the way forward to accelerate. Drive your vehicle off a ramp or curb and watch it catch some "big air." For the smoothest jumps, keep the stick pushed forward during the jump. Depending on speed and ramp angle, your vehicle may land on both wheels - or in a full wheelle!



You can change the position of your cehicle in mid-air by using the left control stick. Push the stick forward to keep the nose up. Pull back to point the nose down.
You can change the position of your cehicle in mid-air by using the left control stick. Push the stick forward to keep the nose up. Pull back to point the nose down.



>>> STOP & START! STOP & START!

Push the left stick all the way forward to accelerate, Now use the right stick to steer into a skid (either right for left), while reducing speed. When your vehicle's die skid just touches the pavenent, quickly jam the left stick forward again and steer out of the turn. Your vehicle will right itself and keep driving to the next exciting stunt! Push the jeft stick all the way forward to accelerate, Now use the right stick to steer into a skid (either right or left), while reducing speed, When your vehicle's die skid just touches the pavenent, quickly jam the left stick forward again and steer out of the turn, Your vehicle will right itself and keep driving to the next exciting stunt!







FCC Warning

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.