





sport &amp; fashion

X7



LP®

sport &amp; fashion

www.lp-music.com.cn



Basic parameters	
Speaker type	Portable Bluetooth speaker
Speaker system	Monobass
Active and passive	Active
Adjust the way	Key dynamic pulley
Functional characteristics	Support APE lossless audio format, Bluetooth audio playback, USB power charging
Storage type	Support large capacity TF Card
Power supply	USB power supply, DC5V-500mA built-in polycarbonate battery charging
Technical parameters	
Loudspeaker unit	10 core strength magnetic speaker
Output power	3W
Frequency response	10Hz--15KHz
Wireless connection	Bluetooth 2.1+EDR
USB connection	USB 2.0, USB1.1
Playback function	MP3\WMA\APE
File format	MP3\WMA\APE



FAQ	
Problem	What To do
Pairing fail	1. Power off and power on 2. Reset the device
Music play interruption	1. Check whether the device is out of the valid connection distance, or any interferent
TF card error	1. Check the TF card format is correct
Playing without sound	1. Check the battery's power enough 2. Check the speaker or the phone is muted state or not
Speaker can not turn on	1. Check battery's power enough 2. Please insert the charging line to reset
Croak or can not power off	1. Please insert the charging line to reset
Technical support hotline	400-099-2577

- Support wireless Bluetooth play
- Support APE\MP3\WMA\format audio files
- With card reader function and voice prompt
- Automatically power off when there is no operation in 10 minutes
- Built-in lithium battery,support USB charging

● Please use and store this product at room temperature  
 ● Do not expose this product to sun or wet conditions  
 ● DO not throw and drop this product to avoid product damage  
 ● Do not self-dismantling, repair and transform the product  
 ● Do not use chemical solvent cleaning the product  
 ● Please don't arbitrarily discarded of placed the lithium battery in the fire in order to avoid the risk of explosion