BLUT-IN BLUETOOTH STEREO SPEAKER BV-B001 INSTRUCTION MANUAL



OPERATING INSTRUCTIONS

PLEASE READ OPERATING INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP FOR FUTURE REFERENCE.

CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE, REFER ALL SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning bolt with an arrowhead within a triangle indicates the presence of uninsulated dangerous voltage within the product enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within a triangle indicates the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.

WARNING:


- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.
- 2. TO AVOID ANY DAMAGE, DO NOT FORCE THE COVER INTO POSITION.


ACCESSORIES INCLUDED

- 1.AC adaptor
- 2.User manual

PARTS / BUTTONS

MAIN UNIT





- 1.POWER ON/OFF SWITCH
- 3.BLUETOOTH PAIRING BUTTON 4.VOLUME CONTROL KNOB
- 5.NEXT BUTTON
- 7.AUX INPUT JACK

- 2.PREV BUTTON
- 6.PLAY/PAUSE BUTTON
- 8.DC IN POWER JACK

GETTING STARTED

POWER SUPPLY

- AN AC-DC Adaptor with the output 9V DC 2.0A (included) is required for operating the main unit .To connect the AC-DC Adaptor to the unit and 120V~60Hz AC outlet:
 - Firmly and securely insert the DC plug of the adaptor to the DC IN JACK on the back of the unit.
 - Plug the adaptor's AC plug into a power outlet rated at 120V AC~60Hz.
 Turn the POWER ON/OF SWITCH(1) to turn on the system.
 The power indicator
 Will light on.

AUXILIARY INPUT

- 1.Set the POWER SWITCH (1) on position and then use an audio cable with a 3.5 mm stereo plug on each end of the cable.
- Plug one end of the cable into the INPUT jack (7) on the top panel of the unit
 and the other end into the Line-out jack or Headphone jack of your external
 audio device to be able to listen to the external source through that system's
 speakers.
- The volume level can now be controlled through the main unit. Operate all other functions on the auxiliary device as usual.

Note:

If the Line-Out jack of your external device is connected, you only need to adjust the system's volume control. If your external device's Headphone jack is connected, you may need to adjust the volume control on both your external device and this system to achieve the desired volume.

OPERATING THE BLUETOOTH

An external device with Bluetooth connectivity can be wirelessly connected to this apparatus using the bluetooth function.

- Set the POWER SWITCH ON on position and the blue light on volume knob will be flash.
- Turn your external device's Bluetooth setting on, wait a moment, and then look for the Bluetooth pairing name "BV-B001".
- Select the Bluetooth pairing name, to connect the unit. Once connect.
 the blue light will stop flashing.
- 4.After initial pairing, you can press PLAY/PAUSE button to playback music.
- 5. Rotate the volume knob(4) to adjust the sound level.

Press the PLAY/PAUSE button(6) again to pause playback.

Press the BACK(2) /NEXT(5) button to change the track number

Press pairing (3) button to reset a new device pairing.

Problem	Possible cause	Solution
The unit does not respond (no power)	The unit is disconnected from the AC outlet. The AC outlet has no power.	Connect to the AC outlet. Try the unit on another outlet.
No sound	Volume not adjusted. Wrong source selected Device not turned ON. Volume set too low.	Adjust the volume level. Select the correct source. Turn ON the device. Press the Volume + button to turn the sound level up.
Sound is distorted	Volume level is set too high.	Decrease the volume
Unit becomes warm after extended play at high volume.	This is normal.	Turn the unit off for some time or lower the volume.

Specifications

AMPLIFIER		
Output power		
Frequency response		
SPEAKER SYSTEM		
Impedance 4 ohm		
Input power Max. 15 W*2		
GENERAL		
Power requirements AC 100/240 V ~ 50/60 Hz		
Power consumption		

Dimensions (LxDxH)

Don't discard electrical and electronic appliances with regular waste.

- Take them to an official collection point.
- Some components may be hazardous to health and the environment.



Notes:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

 The device has been evaluated to meet general RF exposure requirement.

 The device can be used in portable exposure condition without restriction.

 This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.