

CRAIG®

STEREO EARPHONES with Bluetooth® Wireless Technology


Owner's Manual

PLEASE READ BEFORE OPERATING THIS EQUIPMENT.

Model: CBH515

2

Location of Controls



3

Hooks installation:



Battery Recharge:

The unit has a built-in DC == 3.7V Li-ion rechargeable battery, recharges it before use or when the battery is consumed as follow:

1. Connect the Micro USB plug from the USB connection cable to the Micro USB Port on the unit.
2. Connect the full size USB plug from the USB connection cable to the USB Port on a computer or any USB charger having DC 5V output.
3. During charging, the Red Indicator will illuminate. When finished, Red Indicator will turn off.

NOTES:

- Your battery will last longer if you follow these simple guidelines for charging and storing.
A. Recharge and store the device within the temperature range of 5°C ~35°C (40°F ~95°F).
B. Do not overcharge (longer than 24 hours). Excessive charging or discharging may shorten the battery's life.
C. Battery life naturally shortens slowly over time.
D. The rechargeable battery incorporated in this product is not replaceable.

4

Operation:

The first time you use the unit or pair it to a new Bluetooth device, follow these instructions:

1. Press and hold the Button approx. 2 seconds until the Blue and Red Indicators illuminate and blink.
2. Power on the external BT device and enter to BT searching mode. Start pairing following the on screen instructions from the external BT device. After pairing, the Red Indicator will not light and the Blue Indicator will stop blinking. (For details pairing procedures, please refer to the user's manual of your BT device.)

Notes:

- When the external BT device searched the unit, our model number "CBH515" will appear appear on the display of external BT device.
- Pairing code "0000" or "1234" may need to enter.

Normal operation after pairing:

1. Power on the external BT device and enter BT mode.
2. Press and hold the Button approx. 2 seconds until the Blue Indicator is illuminate and blink then release the button. Wait a few seconds until the unit auto paired to the external BT device. (The Blue Indicator will stop blinking.)
3. Plays the music in the paired BT device as usual. (Make sure the sound level of the paired BT Device is set to high. Otherwise, sound from this unit is weak.)
4. During playback:
 - Press and hold the "+" or "-" Buttons to adjust volume level.
 - Press the Button to pause, press again to resume normal playback.
 - Press and release the "+" or "-" Buttons repeatedly to skip tracks.
5. If the unit is paired to cell phone:
 - When you receive an incoming call while listening to music, press the Button to pause the music then speak into the built-in Microphone to answer the call. When your call is complete, press the Button to end the call and resume to the music playback.
 - Press and hold the Button approx. 3 second to reject incoming call.
 - Press the Button twice to redial the last dialed phone number.
6. To shut off the unit, press and hold the Button approx. 3 seconds until the Blue and Red Indicators illuminate and blink then release the button to shut off the unit.

Specifications:

Power Source.....Built-in DC == 3.7V; 70 mAH (0.259WH) rechargeable Li-ion battery, recharge by DC == 5V through Micro USB Port
Bluetooth version.....Bluetooth 4.1+EDR
Impedance of Earphone.....16 ohm, 5 mW x 2
Audio power.....4 mW per channel
BT effective range.....32 Feet in open area

Accessories:

1 x User's Manual
1 x USB Connection Cable (for charge only)
1 x Earphone Hooks (1 pair)

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT NOTICE

LIMITED WARRANTY

Craig warrants this product to be free from manufacturing defects in material and workmanship under normal use for a period of 90 days from date of purchase. If service is required, please return the product to the store where it was purchased for exchange; or, pack the unit in the original packing material with all accessories if applicable, a copy of your sales receipt and a Cashier's check or Money Order for \$3.00 (to cover shipping and handling costs) payable to Craig Electronics Inc. For consumers in Canada, please make sure that the cashier check or money order is redeemable through a U.S. bank. Ship your product freight pre-paid. Your unit will be repaired, replaced or if the unit can not be repaired or replaced, a refund will be forwarded to you within four weeks of receipt of your unit. Please ship your unit to:

Craig Electronics Inc.
1160 NW 163 Drive
Miami, FL 33169

This warranty is void if the product has been: a) Used in a commercial application or rental. b) Damaged through misuse, negligence, or abuse. c) Modified or repaired by anyone other than an authorized Craig service center. d) Damaged because it is improperly connected to any other equipment.

No claim will be honored for ordinary adjustments as outlined in the Owner's Manual which can be performed by the customer. b) Damage to equipment not properly connected to the product. c) Any cost incurred in shipping the product for repair. d) Damage to the product not used in the USA.

This warranty is not transferable and only applies to the original purchase. Any implied warranties, including the warranty of merchantability, are limited in duration to the period of this expressed warranty and no warranty whether expressed or implied shall apply to the product thereafter.

Under no circumstance shall Craig be liable for any loss or consequential damage arising out of the use of this product. This warranty gives specific legal rights. However, you may have other rights which may vary from state to state. Some states do not allow limitations on implied warranties or exclusion of consequential damage. Therefore, these restrictions may not apply to you.

To Obtain Service on your Product
email:service@craigelectronics.com

Printed in China

CBH515_WC_E0FF1_A0US

Size: 148.5(W) x 210(H)mm (A5)

5

6

正面

反面