# K1说明书资料

## 要求: 1, 105G双铜+4C+风琴折

2,彩色单页双面印刷,450\*280mm折叠后140\*90mm

# 配套橙色内卡的盒子










- \* Support Android 4.4 operating system with ARM Cortex A5.
- \* Support many IPTV(Interactive Personality TV)programmes to connect with your ow \* Support three main HD formats: VC-1, H. 265, MPEG-2/4 and many others normal
- AVI/RM/RMVB/TS/VOB/MKV/MOV/ISO/WMV/ASF/FLV/DAT/MPG/MPEG.
- \* Photo formats include HD JPEG/BMP/GIF/PNG/TIFF.
- \* Audio formats include MP3、WMA、WAV、and so on
- \* Support SD/SDHC/MMC cards ect. \* Support standard RJ45 cable network connection and wireless network connection
- \* Support infrared remote controller operation. Environment for System
- Operation : Temperature limitation: 0–40 °C; Humidity limitation: 20–80%
- \* Support two USB 2.0 host connectors with maximum output current of 1.5A/5V. Storage: Temperature limitation: -20-50 °C; Humidity limitation: 10-90%

#### Remote Control











Troubles hooting Warning
Warning
Under no circumstances should you try to repair the TV BOX by yourself, as this will invalidate the warranty. Do not open the as there is a risk of electric shock. TV BOX If a fault occurs, first check with points listed below before taking the TV BOX for repair. If you are unable to remedy a problem by following hints, consult your dealer for help.

Solution

Solution

Check if the power adaptor is properly connected to the power and the TV BOX. The I V BUA.

Press the power on the remote controller to turn on the por
Re-connect with HDTV cable or YUV cable or AV cable.

Check if the TV is switched on.

Adjust the volume. No sound or distorted sound Adjust the volume.
 Check that the speakers are connected correctly.
 Check the digital connections.
 Check if your amplifier is set correctly. Ame the remote control directly at the sensor on the front of the T BOX.

Acting the remote control directly at the sensor on the front of the T BOX.

Replace the distance to the TV BOX.

Replace the batteries in the remote control.

Operations may not be permitted. Refer to the user manual.

-Possibility of system halted,re-insert with power adaptor to resta The player does not respond to the Remote Control Player does not respond to some operating commands during playback -The audio codec may not be supported by the TV BOX.You ca change to the supported audio on playing menu. -Check the volume. No sound during movies playback -The USB flash drive format is not compatible with the box.
-If one of the USB can not be read, please turn off the TV BOX for 30 seconds and restart the TV BOX. The contents of the USB flash drive cannot be read

5

How to add shotcuts at home page?

Press ok to select and cancel the apps. The selected app will be appeared at homepage

DTV Setting DVB-T/T2/ATSC/ISDB-T (Optional) Choose DVB-T2 icon, use function of DVB-T2.

Entering for the first time need to search the channel.

Click on Settings, select "channel search".

Channel search there are two ways: automatic and manual (eg.automatic).

Basic on automatic search, the system will display the channels, It will be playing after searching.

DVB-S2 (Optional) Choose DVB-S2 icon, use function of DVB-S2.

Entering for the first time, you will be prompted to search channels.

Enter to Dish Setup, Channel search there are two ways: automatic and manual(eg.automatic).

Press blue button on the remote. will be display Scan Mode option on screen, and select to Blind Basic on automatic search, the system will display the channels, Press OK button to play after

If you choose to manually search, you must set up the satellite name and parameters.

DTMB-TH (Optional)
Choose DTMB-TH icon, use function of DTMB-TH.
Entering for the first time, you will be prompted to search channels
Channel search there are two ways: automatic and manual(eg.automatic) Basic on automatic search, the system will display the channels, It will be playing after searching.

6

### **FCC STATEMENT:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference

that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio mmunications. However, there is no quarantee that interfer occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. ■ Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### RF warning statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

For 5150-5250 frequency band,

Operations in the 5150-5250 band are restricted to indoor usage only

公司名	称	视壮科技	公司	地址	深圳市宝安23区创业二路东联大厦B座402A			
单	号		图	名	说明书	批	准	
机	型	视壮KI OTT	跟	进			作出	
料号						日	期	2016-4-6