PLACEMENT+FIT

Position earhook over the back of the ear Gently place earbud in ear and adjust as needed



WIRELESS PAIRING

Ensure your device is on the Bluetooth setting Press the middle button on the inline control for 5 seconds Select NOWALL CH-1 to connect to your device



POWER

Press and hold the middle

until the unit blinks three

times and chimes.

button on the inline control

6

WIRE MODE

Insert smaller cable tip into pendant Insert larger cable tip into audio source (Inline volume control and microphone will turn off automatically)







press&hold -next track volume up



play/pause

press&hold- previous track volume down

PHONE CONTROLS



volume up



answer/end call

volume down


CHARGING

Charge using the micro USB cable Flashing light will stop when fully charged











Off power off

fully charged in-wire mode



Flashing low battery

pairing connected

disconnected



Breathing connected



Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

★ Battery life can last 6-10 hours depending on the volume and use device. Bluetooth range can reach 30 ft depending on the environment. In order to reach optimal sound quality, mic and in-line control buttons are disable in in-wire mode.

