



FY Wireless Remote Control Instructions

1 Introduction

With the wireless remote control, you can switch the gimbal mode or adjust the angle from a distance.


2

Product and Accessories



3

Connect Wireless Remote Control



Steps to connect wireless remote control:

- 1 Open the wireless remote control.
- 2 Install the receiver for wireless remote control: Insert the receiver for wireless remote control into the function port of gimbal .
- 3 Open the gimbal.
- 4 Use the wireless remote control to control the gimbal.

Tip: The Remote Control will be automatically powered off to save battery if there is no operation within three minutes.

4

Operation

Please refer to the product manual wireless remote control operating instructions

DISCLAIMER

FY wireless remote control is a feature-rich wireless remote control device, yet lightweight and portable.

It is prohibited for any user to use the gimbal for any illegal purposes.

Guilin Feiyu Electronic Technology Co.,Ltd and our associates assume no liability for any accident, injury, death, loss, or other claim related to or resulting from the use of this product.

In no event shall Guilin Feiyu Electronic Technology Co.,Ltd and our associates be liable for incidental or consequential damages relating to or resulting from the use of this product or any of its parts. Damage resulting from use, accident, or normal wear and tear is not covered by our warranty.

Guilin Feiyu Electronic Technology Co.,Ltd reserves the right to amend this manual and the terms and conditions of this product at any time.



Fy FEIYUTECH

www.feiyu-tech.com

Please visit the official website of Feiyu Tech to get related information: www.feiyu-tech.com
Technical support: service@feiyu-tech.com