


QUERIDOS USUARIOS

GRACIAS POR LA COMPRA DE ESTA LINEA DE PRODUCTOS DE ALTAVOCES. ESTE PRODUCTO TIENE UNA EXCELENTE CALIDAD DE SONIDO Y UN FIABLE RENDIMIENTO. ESPERANDO LOGRAR LA MAYOR COMIDIDAD PARA TU VIDA Y TRABAJO, PARA QUE SEA MAS SALUDABLE Y FELIZ

EL PRODUCTO TIENE PA, TF, TARJETA DE MEMORIA, TARJETA Y FM FUNCION DE RADIO, TAMBIÉN TIENE UNA VOZ ESTEREOFÓNICA CON UN HERMOSO SONIDO, REPRODUCCIÓN DE MEMORIA, RADIO FM DIGITAL Y FUNCIÓN DE ENTRADA AUDIO. ES PARTICULARMENTE ADECUADO PARA EL GUÍA DE TURISTAS. PARA PROMOCIONES, ENSEÑANZA, EL EJERCICIO EN LA MAÑANA, EXPOSICIONES, ENTRENAMIENTOS Y OTROS LUGARES.



FUNCIÓN

1.AÉREO:

EN EL MODO DE RADIO JALE LA ANTENA PARA UN MEJOR DESEMPEÑO

2.MICROFONO CON ECO

EL BOTON DE REVERVERACIÓN DEL MICRÓFONO PUEDE AJUSTAR EL VOLUMEN DE MICRÓFONO Y AMPLITUD DEL SONIDO DE REGRESO

3.INTERFAZ TARJETA DE MEMORIA: INSERTAR TARJETA DE MEMORIA, PUEDE REPRODUCIR ARCHIVOS DE MÚSICA CON LA TARJETA (NOTA: POR FAVOR TOME EN CUENTA LA DIRECCIÓN DE LA TARJETA PARA EVITAR DAÑOS A ESTA Y A LA **ENTRADA DE LA RANURA**

4.RANURA PARA TARJETAS

INSERTA LA TARJETA TF, REPRODUCE MÚSICA DE LA TARJETA. (NOTA: POR FAVOR TENGA EN CUENTA QUE LA DIRECCIÓN DE LA TARJETA SEA LA ADECUADA **CON LA RANURA**

5.INDICADOR DE PODER. INDICA QUE ESTA ENCENDIDO Y QUE ESTA CARGANDO LA BATERIA


POTENCIA Y BOTON DE VOLUMEN: GIRE EN SENTIDO DE LAS MANECILLAS DEL RELOJ PARA APAGAR LA MAQUINA, INDICA TAMBIÉN LA CARGA DE LA BATERIA 6.TECLAS NUMÉRICAS


7. >>|/>>: MANTENGA PRESIONADO EL BOTON PARA AVANZAR MÁS RÁPIDO LA CANCIÓN O CAMBIARLA

8.▶II : REPRODUCIR O PAUSAR: DEJE PRESIONADO PARA ENCONTRAR UNA ESTACIÓN FM, PRESIONE PARA REPRODUCIR UNA CANCIÓN O PARA DETENER LA CANCIÓN.

9.144/44: MANTENGA PRESIONADO PARA ATRASAR LA CANCIÓN O REGRESAR LA CANCION

10.PANTALLA DE LED





12. LUZ LED

13. AUX: SALIDA INTERTACE, PUEDE SER UTILIZADO COMO UN CELULAR OUDIO

11. DC 5 V/ LINE IN: RANURA DE ENTRADA DE ENERGIA Y ENTRADA DE

14. MODO MEMORIA TF/FM/AUX/BT: SELECCIONE EL MODO

AUDIO. CONEXIÓN CON RECARGA. / CABLE DE AUDIO

15. TECLA DE RETORNO (REGRESAR)

16. REC: PRESIONE EL BOTÓN REC PARA GRABAR EL SONIDO EXTERNO EN TF, TARJETA DE MEMORIA O USB

MODO DE BT

1.JALE PARA PONER LA MODALIDAD DE BT , HASTA QUE LA LUZ PARPADEE, ESTO INDICARA QUE LA CONEXIÓN ES EXITOSA Y ESTA **ENCENDIDO**

2.SELECCIONA BT DISPOSITIVO DE BT, PARA BUSCAR LA CONEXIÓN LAS INSDTRUCCIONES SERAN TRANSMITIDAS A LOS ALTAVOCES

3. EN EL PRINCIPAL BT DISPOSITIVO DE MÚSICA, EL SONIDO SALE POR LOS **ALTAVOCES BT**

TECNOLOGIA

*RESPUESTA DE FRECUENCIA: 80HZ-12KHZ

*POTENCIA DE SALIDA DE: 3W

*TENSIÓN DE TRABAJO: 3.5V-4.7V

*BATERÍA ESPECIFICACIONES: 1200MA, BATERÍA RECARGABLE DE LITIO

*CARGADOR EXTERNO: 5L CARGADOR

*TIEMPO DE CARGA: APROXIMADAMENTE 8-10HORAS.

*USO DEL TIEMPO: 2-3 HORAS (RELACIONADOS CON EL VOLUMEN Y LA **TEMPERATURA AMBIENTE)**

AVISO DE USUARIO

ESTE PRODUCTO ESTÁ GARANTIZADO POR UN AÑO BAJO DAÑO FÍSICO (ACCESORIOS: BATERÍAS DE LITIO, CARGADOR Y AURICULARES SON PIEZAS CONSUMIBLES QUE NO CUBREN ESTA GARANTÍA).

CON LA COMPRA DE PRODUCTOS,	POR FAVOR LLENE ESTA TARJETA Y CUSTODIA
MODELO:	DIA DE LA COMPRA:
NOMBRE:	DIRECCIÓN DEL USUARIO :
TELEFONO;	
DISTRIBUIDOR:	
TELÉFONO	PERSONA LEGAL:
DIRECCIÓN	FIRMA:


600 *Stidgeway*BT Speaker User Manual

*In order to better understand and use this product, please read this manual carefully before using.

Foreword:

Dear Users

Thank you for purchasing this boutique loudspeaker products. This product has excellent sound quality and reliable performance. The product has a PA,TF card and Memory card playback and FM radio function. It also has a stentorian voice, beautiful sound, memory playback, FM radio and audio input function. It is particularly suitable for the tour guide, promotion, leaching, morning exercise, exhibitions, entertainment and other places.




Function:

- Aerial: In radio mode to pull up the antenna would be better.
- 2.MIC: MIC jack can be connected to a headset propaganda, teaching guides dedicated. 3. Memory card Interface: Inserted Memory card pendriver, it can play music files on
- the pendriver. 4. Memory card slot: Inserted TF memory card. It can play music files on the card. (Note:

Please note that the card direction, to avoiddamage to the card and the card slot.)

- Power Indicator:Playback status display and Charging battery display. Power and volume switch: Clockwise rotation can switch machine and charging battery display. 6.NUMERAL KEYS.
- 7.▶H/▶▶: Press and hold onfthe next player can play fast track to play 8. II: Play/pause. Long press is FM chanel scaning.
- 9.I◀◀/◀◀: Press and hold on a player can play the tracks in reverse play.
- Display: digital led display screen



- DC 5V/LINE IN: Power input slot and audio input jack, connecting with recharge/ Audio cable.
- 12. LED Light
- 13.AUX: Output intertace, can be used as another oudio source.
- MODE:Memory TF/FM/AUX/BT mode selection.
- 15. RETURN KEY
- 16.REC: Press the record buton to record the sound of the external TF card and Memory card.

BT Mode:

- 1)Position to pull the switch BT. BT will flashing lights(BT pairing BT mode for continuous flash lamp, the connection is successful), light has been on.
- 2) Select the BT device search matching, instructions will be issued a BT connected BT speakers. 3)In the main BT device play music, sound output from the BT speakers.
- Previous(Rewind): When TF Memory card playback, short press is to play previous track,

long press is rewind; When FM radio playback, the function is to choose previous station. Repeat:

When TF Memory card playback, you can select single repeat or all repeat playback.

Technology:

*Frequency response:80HZ-12KHZ

*Output power:3W

*Speaker impedance: 4ohm *Working voltage: 3.5v-4.7v

*Battery specifications:1200mA, rechargeable lithium ion battery.

*External charger:5V charger

*Charging time: about 8-10hours

*Use time: about 2-3 hours(related to the volume and environmental temperature)

User Notice:

This product warranty for one year under the artificial damage(Accessory: lithium battery, charger and headset microphones are consumable parts that not covered under warranty.) Product warranty card:

Model:	Date of purchase:
User Name:	User Address:
Telephone:	
Distributor:	
Telephone:	Legal person:
Address:	Signature:

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.