## Front

## 60mm

## Switch on/off Switch on/off Switch on/off Switch on: Press and hold the button on the device for 3 seconds until you hear the device beep twice. Switch off: Press and hold the button on the device for 3 seconds until you hear a long beep. The detection distance of this device is 75 Feet without obstruction, With this device you can easily find the desired items. This device uses a C72032 Lithium Coin Battery. The lifespan of the battery with normal-use is 6 months. Connection 1. The device will connect to the smart phone automatically when powered on, if it shows "not connected" on the App, please press the "Connect" button to connect it again. Whome page Connected Whame: ITAG Whome page Connected Whome page Connect button to connect it interface, press "Delete" to remove it from the device list. Settings for an Alarm 1. Double click the button on the keyfob device to trigger the alarm on the smart phone. 2. Press the confirm prompt to stop the phone alarm.

88.5mm

## Back

