SBX SERIES

Professional ABS Moulded Loudspeakers. Professionelle ABS Geformter Lautsprecher Cajas Acústicas ABS Profesionales Haut-Parleur Moulé Par ABS Professionnel



SBX-1529BTL

OPERATIONS MANUAL BEDIENUNGSHANDBUCH MANUAL DE INSTRUCCIONES MANUEL D INSTRUCTIONS



SBX-1529BTL with FM Radio/USB/SD Recording



PLEASE READ BEFORE USING APPLIANCE **IMPORTANT WARNING AND SAFETY INSTRUCTIONS!**









RIESGO DE POSIBLE DESCARGA ELECTRICA NO ABRIR!



CAUTION: This product satisfies FCC regulations when shielded cabtes and connectors are used to connect the unit to other equipment. To prevent electromagnetic interference with e such as radios and televisions, use shielded cables and connectors for connections.

The exclamation point within an equitateral triangle is intended to alert the user to the presence of important operating and maintenance(servicing)instructions in the literature accompanying the ap-

The lightening flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

READ INSTRUCTIONS: All the safety and operating instructions should be read before the product is opera

RETAIN INSTRUCTIONS: The safety and operating instructions should be retained for future reference

HEED WARNINGS: All warnings on the product and in the operating instructions should be adhered to. FOLLOW INSTRUCTIONS: All operating and use instructions should be followed.

CLEANING: The product should be cleaned only with a polishing cloth or a soft dry cloth. Never clean with furniture wax, benzine, insecticides or other volatile liquids since they may corrode the cabinet. ATTACHMENTS: Do not use attachments not recommended by the product manufacturer as they may cause hazards.

WATER AND MOISTURE: Do not use this product near water, for example, near a bathtub, wash bowl. kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like

ACCESSORIES: Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product, Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

GART: A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn. See Figure A.

VENTILATION: Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered, The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.



POWER SOURCES: This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company.

LOCATION: The appliance should be installed in a stable location.

NON-USE PERIODS: The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time

GROUNDING OR POLARIZATION:

- If this product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other), it will fit into the outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, by reversing the plug, if the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

 If this product is equipped with a three-wire grounding type plug, a plug having a third (grounding) pin, it will only in a grounding type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding type plug.

POWER-CORD PROTECTION: Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

OUTDOOR ANTENNA GROUNDING: If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Figure 5.

LIGHTNING: For added protection for this product during a lightening storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightening and power-line suges.

POWER LINES: An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatta.

OVERLOADING: Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

OBJECT AND LIQUID ENTRY: Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

SERVICING: Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.



Fig. B

DAMAGE REQUIRING SERVICE: Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:


- When the power-supply cord or plug is damaged.
- If liquid has been spilled, or objects have fallen into the product.
- If the product has been exposed to rain or water.
- If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls
 may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
- . If the product has been dropped or damaged in any way.
- When the product exhibits a distinct change in performance, this indicates a need for service.

REPLACEMENT RARTS: When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.


SAFETY CHECK: Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
WALL OR CEILING MOUNTING: The product should not be mounted to a wail or ceiling.


HEAT: The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.


POWERED SPEAKERS REAR PANELS



SBX-1529BTL









SBX SERIES

INTRODUCTION

Congratulations on your purchase of a CLUB SBX Series loudspeaker. Your product is backed by a 90 days limited warranty. Please register your product by using the included form at the end of this manual.

CAUTIONS: 1. All operating instructions should be read before using this equipment.



To reduce the risk of electrical shock, do not open the unit. there are NO USER OR SERVICABLE PARTS INSIDE

CONTROL ELEMENTS

(POWERED SPEAKERS)

- 1 MIC /LINE LEVEL INPUT JACK-This jack is used for a Microphone and line level in puts. Connect CD players or Tape Decks to LINE inputs.LINE level musical instruments with stereo outputs such as Rhythm Machines, Keyboards or Samplers should also be connected to LINE inputs.
- (2) MIC LINE LEVEL XLR INPUT JACK-This jack is used for Microphone 1 and line level inputs.Connect CD players or Tape Decks to LINE inputs.Line level musical instruments with stereo outputs such as Rhythm Machines or Samplers should also be connected to the LINE inputs. Do not connect mixers to this input, use the Balanced XLR or RCA input (3 or 4) only!
- 3 BALANCED RCA LINE INPUT-This connection is designed to accept a balanced line input signal from a mixer or other line level device with a balanced output jack.Use a balanced cable when the signal cable length exceeds 4 feet, this will reduce ex-

cessive signal loss. Be sure to connect only line level input devices such as mixers and tape machines to this jack.

- 4 BALANCED XLR LINE INPUT-This connection is designed to accept a balanced line input signal from a mixer or other line level device with a balanced output jack. Use a balanced cable when the signal cable length exceeds 15 feet, this will reduce excessive signal loss. Be sure to connect only line level unput devices such as mixers and tape machines to this jack.
- (5) LINEOUTPUT JACK-This Jack is used to send the incoming line level signal to line Input on another mixer or power amplifier.
- (6) MICROPHONE LINE LEVEL INPUT LEVEL- This knob is used to regulate the output sig nal of the microphone or CD player/tape deck that is connected to the Mic/line Level jack(1&2)
- 7 MIC LINE LEVEL INPUT JACK-This jack is used for a Microphone and line level input. Co-Connect CD players or Tape Decks to LINE inputs.Line level musical instruments with stereo outputs such as Rhythm Machines, Keyboards or Samplers should also be connected to Line inputs.
- (8) OUTPUT VOLUME-This knob is used to regulate the output signal being sent to other line level input jacks such as a mixer or power amp 5.
- (9) MP3 CONTROL-This knob is used to regulate to amount MP3 applied to hte output signal.
- 10 5-BAND GRAPHIC EQ

The 5-band channel graphic equalizer allows you to adjust the frequency response of the L and R Channel bus signal, providing a maximum of ±12dB of cut and boost for each frequency band from the flat position.

- (11) POWER LED-This L.E.D will be lit when you switch on the power.
- (12) CLIP L.E.D-LEN indicador de saturacion
- (13) On/Off switch-Press to turn the device on/off.
- (14) AC Input-Use it to plug the supplied power cord.
- (15) USB/SD PLAYER
- (16) SPEAKON This connection is for connecting one 8 ohms passive speaker with minimum 150 Watts RMS power.
- (17) NFC-Help bluetooth to be connected quickly. Details please read page 5.
- (18) RGB switch-Press to turn the RGB on/off.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

RF exposure : The device complies with RF specifications when the device used at 5mm from your body