MX333 user-manual

AOLANGE (HK) INDUSTRIAL LIMITED

1) Quick Start Guide (English)

Packaging Articles

Bluetooth Headphone Quick.start.guide.(this.guide) 2

Bluetooth Headphone 2

Charging cable



2) Function Introduction

Mode switch function

③Switch Mode: Press "M" button to switch among TF card Mode/FM Radio Mode/Bluetooth mode.

FM Radio mode: After pressing M key, there will be a voice prompt "FM Tuner" then long press Play/Pause key and it will automatically search all the available radio stations. (while searching the radio stations the blue light flicker) Once all the radio stations are searched and set the blue light will come in blinking mode. Use Volume control keys to toggle among the radio stations.

Volume control function

- ①Volume -: long press the button " w " to turn down the volume.
- ②Volume +: long press the button " > " to turn up the volume.

Media control function

- 1) Previous track: press the button " for previous track.
- 2) Next track: press the button " > " for next track.
- 4 Play/Pause key, take/end call
- (5) Power switch


Power on:

Long press power for a short period, the power indicator will light flashing while become constant after successful connection.

Power off:

Hold down the power button for a short time, the power indictor light will go off indicating that the device is now powered off.

(Note: Before mobile phone connected with wireless headset, please close other multimedia ensure headset working properly.)



3) Headset User Manual

Power on

Long press power for a short period, when blue light flashing quickly, release the hand.

Power off

Hold down the power switch button for 3 seconds or, until the blue light goes off.

Pairing

Hold down the power button for 3 seconds, when the light turns blue and flashes rapidly, the device is in Bluetooth mode and ready to pair. Turn on your Bluetooth enable device and look for "MX333", select it. Once paired the blue light will become constant indicating the device is now paired.

Answering call

Click on the mode button to answer a call.

Rejecting call

Click on the mode button to reject or end the call.

Adjusting Volume

To turn up the volume, long press the " > ".

To turn down the volume, long press the " < ".

Skip track

Quickly press once of " > "/ " ".

пеаци	ones User Manual	J
Power on	Long press the function button for 3 seconds until Red and Blue LED flashes, then take off.	
Power off	Long press the function button for 3 seconds until Red LED, then take off.	
Pairing	Blue light flashing slowly.	
Answering call	Press the function keys once while the call is coming.	
Pausing call	Short press power switch twice injecting a call.	
Adjusting Volume	To turn up the volume you may long press the "V+"? To turn down the volume, you may long press the "V-".	
Last/Next song	Fastly Press once of " ••• " / " ••• ".	
System requiren	nent:	

4)Parameters Introduction

Working or listening to music
In an instant change your working way

Technical parameters

Distance ≤10M

 $\begin{array}{lll} \text{Battery Volume} & 200\text{mA} \\ \text{Charging voltage} & \text{DC5V} \\ \text{Speaker size} & \Phi\,40\text{mm} \\ \text{Speaker impedance} & 32\Omega \\ \end{array}$

Working time music 4-6h call 8-10h

Bluetooth Version 4.1

Microphone Built-in

Power rating 100mw

Working voltage DC3.7V

Frequency response 20-20kHz

With unique sound quality in the same wireless headsets. Signature appearance and 40mm HD driver unit provide clear sound quality, thus bring real depth and definition of your favorite music. Strong sound quality and function, unique individual character style totem, super light head-band aim to bring the most comfortable wearing experience and the best durability. Let you enjoy music anytime and anywhere.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.