

**Safety Instructions** 

• Heed all warnings. Follow all instructions. Do not use this apparatus near water. Clean only with a dry cloth. Install in accordance with the manufacturer's instructions.

Read these instructions. Keep these instructions.

- Do not install or operate near any heat sources such as radiators, stoves, or other apparatus that produce heat. Refer all servicing to qualified service personnel. There are no user-
- serviceable parts. Batteries (a battery pack or installed batteries) shall not be subject to excessive heat such as sunshine, fire or the like. Do not service the internal battery. Have it examined (and replaced if needed) by a competent service centre.
- This speaker should not be used whilst the user is driving or cycling. **Declarations** Hereby Cyrus Audio Ltd. declares that this pointTWO is in compliance
- with the essential requirements and other relevant provisions of Directive

## Bluetooth SIG, Inc.

The Bluetooth word, mark and logos are registered trademarks owned by

## This device may not cause harmful interference.

**FCC Statement** 

to the following two conditions:

This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party

1. This device complies with Part 15 of the FCC Rules. Operation is subject

- responsible for compliance could void the user's authority to operate the equipment.
  - NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These
  - limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may


cause harmful interference to radio communications. However, there is

no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. \\ Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

**Connections** 



- 3.5mm jack cable (not supplied) 3. Battery indicator light. Displays battery level. Charging connector. Connect the charger or a USB cable to charge from a computer etc.



## The pointTWO will switch on or off. The power indicator will light. Auto power off

• Press (1).

**Power control** 

Switching on or off

To save power, point TWO will switch off automatically after 10 minutes  $\,$ with no audio playing. **Displaying battery Level** • The battery level is displayed for five seconds by the battery indicator

when the pointTWO is switched on.

- Green indicates 90 100%, Orange 60 90%, Red 30 60%. When battery level is less than 30%, the battery indicator will flash red
- When battery power is below 30%, a chime will sound, the indicator will flash red and the volume will be lowered to extend battery life. When low charge is indicated, connect pointTWO to the charger as soon as possible. The maximum volume will be restricted until
- pointTWO is connected to the charger and has re-charged to 45%.

## 2. Plug the charger into the mains and switch on the outlet. The pointTWO will begin to charge. While charging the battery indicator will flash red. When fully charged the indicator will change to green.

Charging the pointTWO

Charging with the charger

It is possible to play pointTWO while it is connected to the charger. Charging with a USB outlet The pointTWO can also be charged from a USB outlet if the charger is not available.

 ${\bf 1.} \quad {\bf Connect\ a\ Mini\ USB\ cable\ (not\ supplied)\ to\ the\ DC\ input\ jack.}$ 

Where possible, always use the charger to charge the pointTWO.

 $1. \ \ \, \text{Connect the cable from the charger to the DC Input jack}.$ 


- 2. Connect the the other end of the cable to a USB outlet such as a PC port or USB charger. The pointTWO will begin to charge. The charge time will be much longer than when using the charger. Volume control and mute

1. Press + to increase the volume level or - to reduce the volume level.

## Playing a Bluetooth source NOTE: Check that there is no cable connected to the AUX jack before using Bluetooth audio. Pairing your first device pointTWO works with *Bluetooth*-enabled devices that support A2DP such

as smartphones, tablets and personal computers. When pointTWO is switched on for the first time, it will automatically search for *Bluetooth* source devices to pair with. Before playing pointTWO it must be paired and connected to the *Bluetooth* source you are using. This may be a mobile phone or *Bluetooth* equipped laptop etc. Pairing with a Bluetooth device

• Switch on pointTWO. The Bluetooth indicator will flash. Activate Bluetooth on the source.



The **Bluetooth** indicator will flash slowly.

connection menu of your Bluetooth device.

should be found in the Control Panel. • In the Bluetooth menu of the source, there should be an option to The source will now scan for other Bluetooth devices and should find the pointTWO, identified as Cyrus pointTWO. Choose to pair with this. Your **Bluetooth** source will now be connected to pointTWO.

If the source is a phone, **Bluetooth** will normally

be activated in the connectivity section of the

After pairing for the first time, the speaker will appear in the

# received on either phone will interrupt music if it is playing on the

Re-connecting

Pairing an additional device

Clearing the Bluetooth memory 1. Press and hold the 1 and  $\nwarrow$  buttons to clear the *Bluetooth* memory. The **Bluetooth** indicator will light in purple for three seconds to Remote control of the source

When a  $\emph{Bluetooth}$  source such as a mobile phone is connected to the

Your device and the pointTWO should re-connect when next used if no

The pointTWO can be paired with up to two *Bluetooth* devices at once.

• To pair a second device, follow the pairing instructions, but using the

When two mobile phones are paired at the same time, a phone call

other device has been connected to the speaker.

second device to search for pointTWO.

pointTWO, it is possible to control the play and pause functions of the source from the point TWO control panel. Press the  $\ \ \ \ \$  button repeatedly to switch the source between play and pause modes.  $NOTE: Some\ Blue tooth\ sources\ may\ not\ support\ this\ feature.$  $Sources\ connected\ to\ the\ AUX\ jack\ cannot\ be\ controlled.$ 

You can connect an analogue source such as the headphone outlet of a

## The indicators will stop flashing while the call is in progress. Refusing the call • Hold the 📞 button to refuse a call. The call will be disconnected.

• Press the 📞 button to answer the call.

Answering the call

Receiving a phone call

Muting the sound during a call • Press the **\cup** button during a call to mute/un-mute the sound. The indicators will light red when the sound is muted.

When an incoming call is received on a paired mobile phone, the

Bluetooth, Power and Battery indicators will flash green.


TWS dual stereo TWS is a special feature available for the pointTWO that enables you to link two pointTWO speakers together as a stereo pair, one for the left channel and one for the right.

**Enabling TWS stereo operation** 


- NOTE: TWS can only be enabled between two Cyrus pointTWO speakers. 1. Connect one of the speakers to a Bluetooth source. 2. Press the TWS buttons on both speakers in the pair. The speakers will connect as a stereo pair. The left speaker is the pointTWO that connected to the Bluetooth source.
- During TWS stereo operation, the volume controls on both pointTWO speakers can change the volume setting. Standby and play/pause controls will also function from either speaker.
- **Exiting TWS Stereo operation**  $\bullet\ \ \,$  To disconnect the link between the two pointTWO speakers and exit TWS stereo operation, press the TWS button on either speaker.

Playing an AUX source


mobile phone to the AUX in jack.




Three stand assembly



1:All accessories for tripod assembly.



4:Insert the screw to the back of the speaker Bracket




Weight ..

Size ..

**Specification** Power supply. ...Internal rechargable battery ....100 - 240 V~, 0.3A AC adapter supply requirement .. .....up to 15 hours at moderate listening level Typical playing time .. Amplifier power output ... ....15 W (woofer), 10 W (tweeter) ...90Hz – 20 kHz Frequency Response. ..HSP(V1.2),HFP(V1.6),A2DP(V1.3),AVRCP(V1.5) Bluetooth profile ...2.402Ghz - 2.48GHz Frequency range.

Max. transmitted power. ...0.52 kg ..156mm x 115mm x 46 mm Cyrus pointTWO EN VO

Made in China



Consequential damage, loss or injury, arising from or in conjunction with this equipment. Equipment for attention under warranty should be consigned return carriage paid. If returned equipment is found to comply with the published specification, CYRUS reserves the right to raise a charge. The above conditions do not affect your statutory rights as a consumer. WEEE

✓ This logo means that this product is not to be disposed of with your household waste. This product should be handed over to a designated collection point to be recycled. Your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information on collection points, contact your disposal service or City Hall.

The warranty should be registered on-line within 30 days of purchase. No retailer or distributor may vary the terms of this warranty, which is

Warranty claims must wherever possible be made through the retailer

personal to the original purchaser and is not transferable.

Please retain the sales receipt as proof of purchase.

**(** 

**(** 



### Warning:

the equipment.

measures:

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. changes or modifications not expressly approved

by the party responsible for compliance could void the user's authority to operate

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.