# User Manual



Bluetooth Speaker with Disco Light

# Dear Customer,

Please read this user manual carefully before using it.

# Warning:

- 1. In order to extend the life of the speaker and your physical and mental health, please do not play music in large volume mode for a long time
- 2. If a fault occurs, please turn off the power switch immediately, and unplug the USB cable to prevent speaker and other component failure.
- 3. The limit of the machine work temperature: -20/+60°C

# Specification:

Bluetooth version: V2.1+EDR

Output power: 3W x 1

Frequency response: 90Hz~18kHz

Impedance: 3 ohm Sensitive: 80dB+/-3dB S/N Ratio:  $\geq 70dB$  Distortion:  $\leq 0.3\%$ 

Input power: USB 5V

Working temperature limit: -20/+60°C

## **Product Features:**

- Bluetooth version: V2.1+EDR

- With Aux in, compatible with 3.5mm audio devices

- Power supply: 2000mAH Li-Battery and micro USB 5V charging


## Accessories:

USB charging cable x 1 pc

User manual x 1 pc

3.5mm Audio cable x 1 pc

## Front Panel:



## **Button identification**

1	*: ON/OFF for the Disco Light
2	ON / OFF: ON/ OFF for the unit
3	DC 5V: Charging by USB cable
4	AUX IN: AUX IN jack for 3.5mm audio device

## **BLUETOOTH MODE**

- 1. Power on the unit, the front blue indicator will flash quick and you can hear the sound to inform you the speaker is defaulted in Bluetooth mode.
- Use your mobile phone or computer to search the Bluetooth device "BTL010".
  You will hear the warning sound and see the blue indicator light on. Then play the music in mobile phone or computer. You can control the music by the buttons on the top panel of the speaker.
- 3. The Blue LED light will flash until you are successfully connect.

# Remarks:

- 1. Some audio devices may need to enter the password (password: 0000 as default) to connect the speaker.
- 2. If the Bluetooth is disconnected, you will hear the warning tone, you need to reconnect again.

- 3. During the Bluetooth mode, if you want to change to AUX in mode, insert AUX cable, change from Bluetooth mode to AUX in mode.
- 4. Music volume level, Play/Pause, Previous/Next Songs can only be controlled in your mobile device.

## **AUX IN MODE**

1. You can plug in the AUX in cable directly with your audio device to enter AUX in mode.

Remark: During the AUX in mode, if you want to change to Bluetooth, Pull out AUX cable, change from AUX in mode to Bluetooth mode.

## **CHARGING**

The unit is used the built-in Lithium battery. In these situation such as the volume of unit is low/sound is not stable/display is blinking/automatically shut down, it means that the battery is out of power and needs to be charged.

During charging – Red LED light will be light on.

After full charge - the LED light will light off.

#### FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

# following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.