NewVastek PTU T12 使用說明書 / Manual



Power Transmitting Unit (PTU)

新 足 脏 布

- ★ 設計對1隻裝置充電
- ★於天線上方區域自由擺放充電裝置

產品規格

- ★ 型號: T1201
- ★尺寸: 12 x 21 x 1.7 cm
- ★ 重量: 191g
- ★ 輸入: QC3.0 12V / 1.5A, QC3.0 12V / 2A
- ★ 輸出: 10W
- ★ 通訊: 藍芽 4.0
- ★ 最佳充電距離: 0-1 cm

安裝 前確認事項

- 1. 確定PTU與其他的PTU最少間距305mm
- 2. 確定桌面為非金屬材質
- 3. 確定PTU安裝的位置,電源線的長度足夠

安裝方式

★ 靜置於桌面或平台上面

安 裝 後 確 認 事 項

- 1. 接上電源線以打開PTU電源; 拔掉電源線以關閉PTU電源
- 2. 確認LED燈號

閃爍綠燈 – 連線中

綠燈 - 东雷模式

紅燈-保護模式/錯誤模式

3. 金屬物品請與PTU保持54mm的水平距離及194mm的下方垂直距離

Product Footur

- ★ Wireless charging for 1 unit
- ★ Wireless charging can be done in a wide area above the antenna.

Product Specification

- ★ Model: T1201
- ★ Dimension: 12 x 21 x 1.7 cm
- ★ Weight: 191g
- ★ Input: QC3.0 12V / 1.5A, QC3.0 12V / 2A
- ★ Output: 10W
- ★ Communication : BlueTooth 4.0
- ★ Best vertical charging distance: 0-1 cm

Refore installation

- 1. Make sure PTU is away from another PTU at least 305mm
- 2. Make sure the table is non-metal material
- 3. Make sure PTU location and power cord length is enough

Install Procedure

★ Put on the table or plateform

After inetallation

- 1. Power on by coonecting adapter; power off by removing adapter
- 2. Confirm LED signal

Flickering - Connecting

Gree light - Charging mode

Red light - Protection mode / Error

3. Please keep metal thing 54mm hotizontally and 194mm vertically away from PTU $\,$

產品安全提示

- ★ 充電中本產品有輕微發熱為正常現象
- ★ 禁止浸水,摔落,撞擊或私自拆解本產品
- ★ 禁止使用其他非原廠電源線
- ★ 建議搭配使用NewVastek PRU,以保證效能

Product Safety Reminder

- ★ Slightly heat up during charging is normal
- \bigstar Please do not soaking in water, drop, bump, or disassemble the product permission for maintenance.
- \bigstar Please only use the adapter from Newvastek permission for maintenance.
- ★ Please use NewVastek PRU to ensure the performance.

Product Safety Logo

★ FCC INFORMATION

Notice :

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE:

To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

★ 低功率電波輻射性電機管理辦法

第十二條

經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條

低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。 前項合法通信,指依電信法規定作業之無線電通信。 低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。









IMPORTANT NOTE:

To comply with the FCC RF exposure compliance requirements, the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. No change to the antenna or the device is permitted. Any change to the antenna or the device exceeding the RF exposure requirements and void user's authority to operate the device.