User manual



How to insert a battery

- 1. Handle with care and open the DOTT from the slit at the bottom
- 2. Separate the front (with a DOTT button) and the back cover
- 3. Insert / replace the battery into the back cover, positive terminal (+) of the battery side facing the back cover
- 4. Please note improper closing the cover and pressing them together too hard may destroy internal locking structures and may affect functions and water resistance
- 5. Check the position of the hanging holes on each side, face the hanging holes of both covers, press the two pieces together with care until you hear a 'click' sound with the handing hole facing each other
- ** For registration instructions, please refer to http://www.dottdogtag.com/manual.php

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/ TV technician for help.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without RF striction.