Quick Start Guide



1. Unpack



Open the packing and checked the material according to the packing list.

2. Install filament holder



Hung on the filament, then mount the filament holder on the machine.

3. Attach eyes




Directly attached eyes to the front of the machine.

4. Attach tray



Open the door, put the tray directly on the support frame.

5. Connect the power supply



The outlet plug directly into the power jack in the bottom right corner of the machine.

6. Turn on the power



Touch the power switch in the lower left corner of the machine.

NOTE: Holding the touch switch for 3 seconds or more, Machine shutdown.

7. Load filament



Control the machine with APP, follow the prompts step loading filament then begin printing.

You can see the APP user guide on the left side of MiniToy.



APP User Guide

1.Open APP, enter the main interface.(Note: Make sure to download MiniToy App from "App Store"and complete 2.Click "Set wifi", select MiniToywifi name, the default password is: 12345678. 3.Click "Connect" .

4.In the dialog box, click "OK".(Note: MiniToy using the default IP address)









5.Click "Update", update APP theme content.

6.Select "Setting>
Advance>Loading filament
".If you have already
loaded, ignore this
operation.

7.Select the theme, click "Start", wait temperature is enough to print.

8. During printing, the print into the real-time display progress. printing is complete, MiniToy stops automatically.









Safety Statement

- 1. Children under 14 years old in the adult guide the operation, if conflict, local laws and regulations shall prevail.

 2. Any part of the body is prohibited direct or indirect contact MiniToy internal components, particularly the print head nozzle area.
- 3.Do not attempt to disassemble MiniToy, to avoid possible accidents and injury.
- 4. Once use MiniToy that depends on you understand, recognize and accept all terms of the content of this statement.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- } -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

*RF warning:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.