atomi™
Smart Outdoor Plug
### User Manual

Watch Video
Open your smartphone camera and point it at the QR Code

atomi smart
Download Free APP

Thank you for purchasing the atomi Smart Outdoor Plug

The atomi Smart Outdoor Plug is brilliantly designed to make your life easier and simple to manage. Any device you plug into the Smart Outdoor Plug can be controlled through the atomi smart app.

Turn on and off outdoor plug-in devices, such as outdoor lighting, decorations, small appliances and more up. If you can plug it in, you can control it.

Includes:

Smart Outdoor Plug   User Manual

Before you begin

1. Know your Wi-Fi network and password.
2. Make sure your mobile device is running iOS® 8 or higher or Android™ 4.1x or higher.
3. Make sure light/lamp source is always turned on.
4. Make sure you're connected to a 2.4GHz Wi-Fi network (atomi smart app can't connect to 5GHz networks.)

Step 1:
Unit Mounting

1. Unpack Smart Outdoor Plug from the box.
2. Plug your Smart Outdoor Plug into a grounded wall outlet and let the unit hang down freely.
3. Note approximate location of the hang tab. Remove the Smart Outdoor Plug and install mounting screw (not included) so that the weight of the unit rests on the mounting screw and not the power cord.
4. Plug the Smart Outdoor Plug back into the grounded outlet and install onto the mounting screw.
5. Ensure the Smart Outdoor Plug receptacles are facing downward.

Step 2:
Download App

Download on the App Store

GET IT ON Google Play

Download the atomi smart app from the App Store or Google Play.

Step 3:
Register

Enter your mobile phone number or email address.

Step 4:
Add Device

Enter the verification code and create a password.

Log into the app.

Select "Add Device" or click (+) at the top right corner of the Devices screen.

Choose "Smart Outdoor Plug" from the Device list.

Step 5:
Connect

Indicator Lights
Wi-Fi indication and plug light will light up once connected

Hold the power button for 10 seconds until the indicator light is flashing rapidly, then press "CONTINUE" in the atomi smart app.

Enter Wi-Fi password
Only supported on 2.4GHz Wi-Fi networks

atomi-smar...   Change Network

12345678

OK

Connecting
Make sure your router, mobile phone, and device are as close as possible

11%

Device found
Register device to the smart cloud
Initializing device

Enter your Wi-Fi network and password.

The atomi smart app will connect your device.

Controls

ON/OFF
Press to turn
Smart Outdoor Plug ON/OFF.

Smart Plug

Power On

Schedule
Set up weekly schedules to fit your lifestyle.

Countdown
Set a countdown to power off Smart Outdoor Plug.

Scheduling   Countdown

Add Schedule   Save

2   27
3   28   AM
4   29   PM
5   30
6   31

Repeat   Never

Switch   ON

Set up weekly schedules to fit your lifestyle.

Set a countdown to power off Smart Outdoor Plug.

Troubleshooting

Cannot connect to your Wi-Fi network.
Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check if there are problems with your internet connection. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

What can I control with the Smart Outdoor Plug?
You can control outdoor lighting, decorations, small appliances in accordance with the Smart Outdoor Plug's specifications.

What should I do when I can't turn devices on or off using atomi smart app?
1. Make sure the devices connected to the Smart Outdoor Plug are turned ON.
2. Make sure your mobile device and Smart Outdoor Plug is connected to the same network.

I'm still having trouble!
Wi-Fi networks come in a lot of shapes and sizes with many quirks of their own. It doesn't mean your Smart Outdoor Plug is malfunctioning. If problems persist, please try these steps, in order:

1. Force quit and re-launch the atomi smart app. Check to see if this fixes the issue.
2. Unplug Smart Outdoor Plug and plug it back in. Check to see if this fixes the issue.
3. Unplug your router and plug it back in. Check to see if this fixes the issue.
4. Delete and reinstall the atomi app. Check to see if this fixes the issue.
5. If all else fails, restore your Smart Outdoor Plug to factory settings: First, Unplug your Smart Outdoor Plug. Plug it back in and hold the power button for 10 seconds.