
QUICK START GUIDE

www.xmkitchenhub.com Technical Support: (646)-801-1380


1. KichenHub™ Key Functions




Indicator Light Modes

- Blinking Blue Operating (Battery mode)
- Blinking Red Low battery (Battery mode)
- Constant Red Sleep Mode (Battery mode)
- Constant Blue Sleep Mode

Front View





2. Safety First

Important: Please read all safety instructions before proceeding.



CAUTION: To reduce the risk of electric shock do not remove cover (or back). No userserviceable parts inside. Refer servicing to qualified service personnel



DANGEROUS VOLTAGE: The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

ATTENTION: The exclamation point within an



ATTENTION: The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



ATTENTION: The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

This product only can be used with the socket outlet. It cannot be used with multiple socket outlet.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

Use only an approved charger to charge your device. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty.

that are not approved by XtremeMac S.AR.L. Doing so may void the compliance of this product and may result in the loss of the user's authority to operate the equipment Your device is equipped with an internal rechargeable battery that is non-

Users of this product are cautioned not to make modifications or changes

removable. You should never attempt to open or disassemble this device . Doing so may cause damage that voids your warranty. Do not use or store your device in extreme temperatures as your device might overheat

and may present a burn and fire risk and cease to function. This device complies with Part 15 of the FCC Rules: Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference and
- 2. This device must accept any interference that is received, including any interference that may cause undesired operation. This device is acting as slave and operating in the 2.4 GHz (2412 $^{\sim}$ 2462

MHz) band. Ad Hoc function is supported but not able to operate on non-US frequencies. Do not use the device with the environment which below

minimum -10 °C or maximum over 50°C.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

3. Basic Instructions

Plug In the Device

- 1. Insert the power cable into the KitchenHub's Power Port.
- 2. Plug the power cable outlet into a standard AC power.

NOTE:

The KitchenHub is meant to be kept plugged-in all times.

While unplugged, some elements or features (such as the

Music Speakers) are disabled.

Turning Your Device On and Off

- To turn on your device, press and hold the **Power Button** for a few seconds. When you turn on your device for the first time, follow the on-screen instructions to set up your device.
- To turn off your device, press and hold the **Power Button** for a few seconds and follow the prompts.

Initial Device Configuration

Follow the on-screen instructions to complete the setup process.

Using Linkr KitchenHub Platform

To watch the Linkr KitchenHub tutorial:

From Home Screen tap **Menu** (at the top-left) → **Support** → **Tutorial**

Connect Your Mobile To The Device (via Bluttoth)

- .. From Home Screen tap **Menu** (at the top-left) → **Connect To Mobile**
- 2. Click the 🛈 icon (next to "Connect To Mobile")
 - Follow the on-screen instructions

FCC statement

This device complies with Part 15 of the FCC Rules: Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference and
- 2. This device must accept any interference that is received, including any interfer ence that may cause undesired operation.

Human exposure to RF emissions from mobile devices (47 CFR ¡ì2.1091) may be evaluated based on the MPE limits adopted by the FCC for electric and magnetic field strength and/or power density, as appropriate, since exposures are assumed to occur at distances of 20 cm or more from persons.

This device is acting as slave and operating in the 2.4 GHz (2412 ~2462 MHz& 2402 -2480 MHz) band.

Ad Hoc function is supported but not able to operate on non-US frequencies. Do not use the device with the environment which below minimum -10 $^{\circ}$ C or maximum over 50 $^{\circ}$ C.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.