

## DJ R3X" INTERACTIVE REMOTE CONTROL DROID


### INSTRUCTIONS




Power and Pairing Buttons



Remote





# Remote Pairing

#### **Remote Pairing Steps**

- 1. Slide the power button on the back of DJ R3X to the ON position.
- 2. Slide the power button on the back of the remote to the ON position.
- 3. The remote and DJ R3X should pair automatically.

Troubleshooting: If having pairing issues, press the pairing button on back of DJ R3X (as shown in step #2) to send out a pairing signal. At the same time, turn the Remote Off and then On again to start pairing process over again.

## Bluetooth® Pairing

#### **Device Pairing Steps**

- 1. Slide the power button on the back of DJ R3X to the ON position.
- Go to your smart device settings and make sure Bluetooth<sup>®</sup> is on.
- Find the Bluetooth® device named DJR3X.
- 4. Connect to the device.
- 5. A special sound will play when paired successfully.



Note: DJ R3X will go to sleep if not activated for 5 minutes.

# WARNING: Warning:

CHOKING HAZARD - Small parts. Not for children under 3 years.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by International Toy, Inc. is under license.



This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a partial aristallation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

· Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or experienced radio / TV technician for help.



Disney Theme Park Merchandise Lake Buena Vista, FL 32830 © Disney © & ™ Lucasfilm Ltd. Made in China