



## **Photo Interface :**


## **Music Interface:**



## Movie Interface



- \*\*1.For HD movie, we suggest to download to iPhone and watch it
- \*\*2.Make sure if the movie file can be supported or not.




I-BOX Mode

AP Mode: Mobile phone or PC/laptop access to network via the module as an AP.

**STA Mode:** To be as a Wifi Station / hotspot(Need to complete the setting of STA SSID first)

## (1) AP Mode



### **Step:**

- 1.Add a new SSID Name:  
Key in SSID name and key you can remember and save the setting.
  - 2.Return to the setting page and select AP Mode.

## (2)STA Mode:



## Step:

1. Add a new SSID Name:  
Key in SSID name and key you can remember and save the setting.
  2. Return to the setting page and select AP Mode.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.