
OPERATION PANEL

CONTROL PANEL





MODEL: LI-S7803

User's manual



ongratulations on purchasing the LAX-MAX LI-S7803 lease read this Instruction manual prior to using this unit.

OPERATION PANEL

FEATURES

- Wireless connectivity
- FM Radio
- USB/SD slot Plays MP3 Files stored in your SD Card or USB Disk Drive
- AUX IN connect your External Audio Players (ipod®/iphone®/ipad® /smartphones etc.)
- Built in Rechargeable battery
- Charging cable included

POWER SUPPLY:

- Connect the supplied cable to USB jack to charge the built in battery.
- Please make sure battery is fully charged prior to initial use. For best results (or to charge faster) do not use the unit while charging.
- Use On/Off button to switch power ON/OFF on unit.

WIRELESS MODE

- Long press MODE button to switch off led light
- Short press Mode button to switch between WIRELESS / USB/SD/FM / AUX
- On your smartphone, scan and select "LI-S7803" to pair.
- Sound will depend on quality of your media file or distance of connected device from speaker (Distance should NOT be more than 30Feet) andthere should be no object blocking the Wireless Signal
- To play your music Press ▶
- To change tracks Short Press (Previous Track) or (Next Track).
- To Pause or Release Pause Short Press
- To adjust the volume use the volume knob
- Suggested maximum distance while using Mic –10 Feet.
- Suggested maximum distance from your smartphone during Wireless mode 30Feet

FM RADIO

- Short press Mode button to switch between WIRELESS / USB/SD/FM/AUX. Please ensure that your speaker is fully charged & correct source has been selected.
- To adjust the volume use the volume knob
- To change the Radio Station Short Press ► (V-(Previous Track) or)/V+(Next Track).

SPEAKER SYSTEM

OPERATION PANEL

USB/SD

- Plug in your USB Disk or SD Card in the slots provided. Please make sure you use the correct file format in your media devices MP3 FILES ONLY and correct mode should be selected.
- Short press Mode button to switch between WIRELESS / USB/SD/FM / AUX. Please ensure that your speaker is fully charged & that your files are Mp3 format and the correct source has been selected.
- To adjust volume Long Press ⋈ √V-(volume down) or ⋈ /V+ (volume up).
- To change tracks Short Press ✓ V-(Previous Track) or (Next Track).▶
- To Play Long press ▶ , to Pause or Release Pause Short Press ▶ |
- Please remember to turn off the power of the Speaker before removing the USB Disk or SD Card.

iPod®, iPhone® & iPad®, are registered Trademarks of Apple Computer Inc. This product is not Designed, Manufactured or Distributed by Apple Computer Inc. All other Trademarks & Trade Names belong to their respective owners.

Copyright © Lakshmi International, Inc., 2016-2017

All Rights Reserved

This publication is protected by copyright and all its rights reserved. No part of it may be reproduced or transmitted by any means or in any form, without prior consent in writing from Lakshmi International, Inc.

The information in this publication has been carefully checked and is believed to be accurate. However Lakshmi International Inc., assumes no responsibility for any inaccuracies, errors, or omissions that may be contained in this document. In the interest of continued product development, Lakshmi International, Inc. reserves the right to make improvements in its documentation and the products it describes at any time, without notice or obligation.

SPE	١KER	SYS	TEM
-----	------	-----	-----

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.