


Ridgeway

QS-J1203

**PORTABLE ACTIVE SPEAKER
SYSTEM WITH TROLLEY**

- USB & SD INPUT PORTS
- BT AUDIO STREAMING
- FM RADIO RECEIVER
- AUDIO LINE (AUX) INPUT
- BASS AND TREBLE CONTROL
- PRESET EQ FOR USB/SD PLAYBACK
- WIRED MICROPHONE INPUT
- DIGITAL ECHO
- GUITAR INPUT
- LED DISCO LIGHTS
- RECHARGEABLE BATTERY



QS-J1203

PORTABLE ACTIVE SPEAKER
SYSTEM WITH TROLLEY

INSTRUCTION MANUAL

Before connecting, operating or adjusting the unit,
please read instructions carefully and completely.

Feature


1. Stylish fashionable and elegant appearance
2. Strong bass, clear and rich vocal
3. Music playing through BT, USB, SD and line in connection

Display Description



1. ▶ : USB flashes when playing
2. II : USB pause display
3. USB MP3 : Read U disk display
4. SD : Read SD card display
5. FM : FM display when playing

Panel Function



1. Source Volume Control
2. Treble Control
3. BASS Control
4. Echo Control
5. Mic Volume Control
6. Guitter Volume Control
7. Mic Input Jacks
8. Guitter Input Jacks
9. Lights ON/OFF Switch
10. Power ON/OFF Switch
11. Charging port: 15V/1A Input
12. DC 12V Input
13. AUDIO Input Jacks
14. FM antenna
15. USB/SD Input port
16. USB/SD/FM/BT Playback Controls
 - a.MODE
 - b.Previous/CH- Button
 - c.Next/CH+ Button
 - d.Play/Pause/FM SCAN Button
 - e.Repeat Button
 - f.Receiving Head
17. USB Function Display

Function Description

General Function Description

- 1.Master Volume :Turnning to adjust master volume.
- 2.Treble Volume :Turnning to adjust volume.
- 3.Bass Volume :Turnning to adjust volume.
- 4.Echo Effect Volume :Turnning to adjust volume.
- 5.Mic Volume :Turnning to adjust volume.
- 6.mode:change to other mode when operating,sequence:
AUX-BLUE-FM-USB/SD.priority to play in usb or micro sd mode when insert usb or micro sd

Mp3 Function Description

- 1.USB:Playing when insert the USB when save with Mp3 music.
- 2.Micro SD:Playing when insert the Micro SD when save with Mp3 music.
- 3.AUX:Playing when Plug in the AUX cable and connected with music device.
- 4.Play/Pause Button: In USB or Micro SD mode,press to play or pause.
- 5.Skip -+& Button: With playing music in USB or Micro SD mode,short press to go back or forward music,long press to adjust volume

BT Function Description


- 1.pairing:press Mode Button To Blue Mode ,speaker Will Be Under Automatic Pairing Mode,led Display Shows "blue",pair The Bt Compatible Device By Selecting "QS-J1203" From The Listed Devices, Speaker Will Call Out "connected" After Paired Successful, Blue Pairing System Will Be Off There Is No Device Connecting After 5 Minutes.
- 2.Music Playing: press play/pause,Skip +/- Button to play music.

Charging function introduction

Red light when charging, when the green light when the battery is full, but also continue to charge, charge 5-6 hours of battery is to charge to the best state.


Remarks:Please charge the power when the power is off or the lower volume to avoid re charging when the sound is distorted.

An External Battery Extend Life Function




This product matched with external 12V storage battery connecting clamp, pls according to red(+),black(-) to connect the extemal storage battery's (+), (-). normal working after opening the power supply.

Lighting Function Description



Light Flashing Alternatively
After Power On

Remote Control Functions



REMOTE CONTROL BATTERY INSTALLATION:

Press the releasing tab and lift the cover of the battery compartment.

Place two AAA size batteries and match the polarity in the battery compartment illustration, (+) to (+) and (-) to (-) signs.

1. POWER - To switch the AUX, Bt USB, SD, FM module of the product to Standby or operational mode.
2. MODE - To select playback input mode, AUX, Bt , USB, SD or FM radio operation.
3. STOP - To stop USB or SD MP3 audio playback.
4. MUTE - To switch the sound to OFF or ON during AUX, USB, SD or FM radio operation.
5. VOLUME (+/-) - To adjust the internal digital volume level of the audio input source.
6. PREVIOUS - To play the previous audio track number during USB, SD or operation.
- CH- - To select the previous programmed FM radio station on the preset memory channel number.
7. NEXT - To play the next audio track number during USB, SD or Bt operation.
- CH+ - To select the next programmed FM radio station on the preset memory channel number.
8. PLAY/PAUSE - To pause or to resume audio playback during USB, SD or Bt operation.
- Scan - Press And Hold To Start Auto-program Fm Radio Stations Into The Preset Memory Channel number
9. REPEAT - To select repeat mode during USB or SD audio playback operation. Repeat modes: Folder/One/All
10. EQ - To select any of the preset equalizer settings according to your listening preferences during USB or SD audio playback mode.
11. Numerical buttons - To access directly to the desired track number during USB or SD MP3 audio playback or to access directly to the preset memory channel numbers of FM radio stations.

Technical Specifications

POWER SOURCE	AC 100~240V~60Hz	DC 12V ---
BUILT-IN RECHARGEABLE BATTERY	12V/4.5A	
POWER CONSUMPTION	60W (max.)	
TOTAL POWER OUTPUT	40W RMS @1kHz, 10% THD	
WOOFER DRIVER	12", 4 OHMS	
TWEETER DRIVER	1", 4 OHMS	
FREQUENCY RESPONSE	45Hz - 20kHz	
TOTAL HARMONIC DISTORTION	0.3% @10W	
CHANNEL SEPARATION	60dB	
FM RADIO TUNING RANGE	87.5MHz to 108MHz	
USB/SD FORMAT COMPATIBILITY	FAT/FAT32 file system (NTFS file system is not supported)	

Packing

QS-J1203 Speaker	*1
Adpater	*1
User Manual	*1

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.