#### Coma 6000 mAh Wireless Power Bank

Instruction Manual 7121-47



#### Features:

- ON/OFF Button
- ON/OFF Button
  LED Indicators (1 red/green wireless convert light; 4 power indicators)
  USB Output 1
- Micro USB Input
- USB Output 2 Wireless Charging Pad

#### What's included:

- 1 x Coma 6000 mAh wireless Power Bank
- 1 x USB to Micro-USB charging cable 1 x Instruction Manual

### Tech Specifications

- 6000mAh poly-li battery
   Input power: 5V/2A
   USB 1 Output power: 5V/1A
   USB 2 Output power: 5V/2.1A
   Wireless Output: DC 5V/1A

LED Indicators:
ON/OFF Button: Press once to to view the remaining power capacity.

#### Instructions:

- Charging the Power Bank:
   a. Using USB to Micro-USB charging cable, a. Using USB to Micro-USB charging cable, insert the USB Charging cable into a certified USB AC adapter or USB port of a computer to begin charging. b. When Charging, LED Indicator will illuminate BLUE, Once fully charged all LED lights will be illuminated.
- 2. Charging with the Power Bank through Cable a. The power bank has a 2xUSB output ports.
- a. The power bank has a 2xUSB output ports, (USB1) has a maximum out 1A and (USB2) has a maximum out 2.1A.
  b. Connect the desired cable to your mobile phone/device by using the appropriate connector. Connect USB head to the power bank outputs. BLUE LED Indicator will libraries under a charging.
- bank outputs. BLOE LEU Indicator will illuminate when charging.

  c. Remove the desired cable from your mobile device when it is fully charged.

  3. Charging Mobile phones and other electronic devices with wireless charging.

  a. Hold ON/OFF Button till the RED LED.
- .Hold ON/OFF Button till the RED LED lilluminates. Place wireless charging enable device on Wireless Charging Pad. LED will illuminate GREEN when charging. Hold ON/OFF Button till LED lights turn off to turn OFF Wireless charging. Note: In order to charge devices, use only the accessory cable or the cable included with your own device by the manufacturer.

#### SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed, including the following:
- Read all the instructions before using the
- product.

  Charge the power bank fully before initial use.
  The unit's full performance is achieved only after 2 or 3 completed charge and discharge
- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- is used near children.
  4. Do not expose the device to moisture.
  5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
  6. Do not use the device if damaged or profifed.
- modified.
- modified.

  7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.

  8. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly movement in order for or injury. may result in a risk of fire or injury
- may result in a risk of tire or injury.

  9. Do not expose the device to fire or
  excessive temperature. Exposure to fire
  or temperatures above 212°F may cause
  explosion.

  10. Have servicing performed by a qualified
- repair person using only identical
- replacement parts.

  11. This will ensure that the safety of the product is maintained.

#### FCC Statement:

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not exlicitly approved by the party responsible for compliance could void the user's authority to operate this equipment. Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radrate and of requering the part of the part o

- measures:

  Reorient or relocate the receiving antenna.

  Increase the separation between the equipment and receiver.

  Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

  Consult the dealer or an experienced radio/TV technician for help.

help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

## WIRELESS CHARGING ENABLED DEVICES:

iPhone 8/8Plus/X, Samsung Galaxy S8/ IPTIONE 6/06/105/X, Samsung calaxy So/ S8+/S7/S7 Edge/S6/S6 Edge, Nokia Lumia 1020/920/928, HTC 8X, HTC Droid DNA, HTC Rzound, HTC Incredibly 4G LTE, Moto Droid Turbo, Motorola Moto 360 Smart Watch, Moto Droid Maxx, Droid Mini, Google Nexus 6/4/5/7 (2013), LG D1L, LG LTE2, LG G2 (Verizon), Blackberry Z30 (Verizon)

Made in China

# 170\*90MM