WIRELESS SPEAKER OPERATING INSTRUCTIONS



Please take a few moments to read through this manual and warnings for important information about the speaker. This speaker is created to fit on the Pringles® can. The can should be used as the sound box. This wireless speaker is compatible with most kind of Bluetooth® audio devices or with uses an audio cable with 3.5mm audio plug (not included) connected to a MP3 player.



THIS SPEAKER IS NOT A TOY! WARNING! CHOKING HAZARD - SMALL PARTS INSIDE, NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.

PRECAUTIONS

- Before placing the speaker onto the Pringles® can, empty and clean the can. Do not use alcohol, benzine or thinner to clean the unit. Do not use the unit in places which are extremely hot, cold, dusty or humid. Do not keep the unit near a heater. Do not expose to direct sunlight. Do not oxpose to direct sunlight. Do not oxpose to direct sunlight. Do not loosen the 3 screws locking the speaker base. Be cautious, high volume levels may cause permanent damage to the hearing. Do not insert any object into the Pringles® can. Avoid overextending and pulling the speaker. Do not put loose batteries in your pocket or purse. Do not remove the battery label.

WARNING! CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

BATTERY INSTALLATION

- To open the battery lid, first loosen the screw using a screwdriver or a small coin. Then, push the latch inwards and pull the lid open. Insert 3 x AAA size, DC 1.5V batteries ("R03/UM4") in proper polarity and position. Close the battery compartment and lock the latch with the screw.

- Close the battery companinent ariu door the laten win the sciew. Do not try to pull the screw lift off the lid. It is designed not to loosen from the lid. Note: in case of battery and DC power source are used at the same time, the unit will default to operate from the DC power input. It will not damage the batteries by automatically cut-off the current to the batteries.

BATTERY WARNINGS

- ATTERY WARNINGS
 Place the batteries in correct polarity and position.
 Misplacement of batteries can cause electrolyte leakage and will corrode the compartment or cause the batteries to burst.
 Do not mix different types of batteries. e.g. Alkaline with Carbon Zinc
 Batteries may explode or leak and cause burn injury if recharges, exposed in fire or disassembled.
 Do not mix old batteries with new ones. Replace them all at the same time.
 Remove the batteries if until will not be used for a longer period of time.
 Alkaline batteries are recommended to use for longer period of time.
 When the batteries are low, the sound will be distorted or unstable. In this case, replace all the batteries with new ones.
 Depleted batteries should be removed from the unit.
 The supply terminals can ont be short-directived or everloaded.

- Depleted batteries should be removed from the unit.

 The supply terminals can not be short-circuited or overloaded.

 Non-rechargeable batteries are not to be recharged.

 Rechargeable batteries are not to be recharged adult supervision.

 Rechargeable batteries are not yet be charged under adult supervision.

 Rechargeable batteries are to be removed from the speaker before being charge

 Batteries shall not be exposed to excessive heat such as sunshine, fire or the like

 Batteries cannot be charged via the micro USB connection.
- LISTENING TO YOUR AUDIO DEVICE (MP3....)

Power ON / Power OFF

- ower UN / Power OFF
 Remove the plastic protection sheet on top of the speaker.
 Push the power button to turn the speaker on until a beep tone is heard.
 The LED will light up with blue light and starts flashing every 1 second.
 The blue LED indicate faster flashing and a beep tone afterwards signify the unit is now ready to be paired.
 To turn off the unit, push the power button again until the LED indicator light goes out.
 Please note, always make sure to turn on the speaker first before pairing to the audio device.
- Bluetooth® Play Mode

- Play your audio wireless with a Bluetooth® enabled device.

 The range during the initial pairing process should not be more than 1 meter.

 Once paired, playing range is within 8 meter. Note that obstructions may result in a shorter range.

 Follow the pairing instructions of your smartphone or other Bluetooth® device.

 Select "device name" from the searching list and press OK to pair the speaker. Device name can be found at the back case of the speaker and no password is needed. Select device name from the searching list and press Uk to pair the speaker. Device name can be roun speaker and no password is needed.
 When pairing is completed, you will hear a beep tone and see a blue LED light flashing every 3 seconds.
 Now the wireless speaker is ready for listening to music.
 After this first pairing, the devices will connect automatically.
 Adjust the volume and select a song from your audio device(s).
 The speaker can be used without batteries via the micro USB plug.

Aux./Line-in Play Mode

In case Bluetooth® is not preferred to connect with the speaker, the speaker is also compatible with 3.5mm audio cable (not included). Please only use this type of cable to connect.

ADJUSTING THE VOLUME

Adjust the volume level from your audio device.

Make sure the sound starts from the lower volume level.

Turn off the Mega Bass function and lower the volume level of your audio device, as it may be too loud and cause sound distortion.

SPECIFICATION

Aux. Line Ir

Battery: DC Jack:

Speaker Type: Speaker Impedance:

Output Power:
Frequency Response:
Bluetooth® Version:
Bluetooth® Profile:

Power Indicator: Operating Frequency:

57mm Full Range Dynamic Mylar Speaker 6 ohm / 1 W 3.5mm Stereo Mini Jack 1 Watt (Rated) 200-20K Hz V4.1 AZDP, GAVDP 3rmm White Base LED, Blue Color 2.402 GHz - 2.490 GHz 3x AAAROSUM4 Size, DC 1.5V (Batteries Included) Micro USB DCSV / 1A

Model No. SI-598 Made in China

Manufacture code: 08-2016 Designed, produced and imported by :



Smidt-imex bvba Middelmolenlaan 148 - 2100 Antwerp - Belgium

www.globalpromotionalgifts.com


In case the presence of excessive electrostatic charges around the speaker in use have interrupted the wireless connection, please reconnect the speaker.

Batteries and electronics contained in the product may be harmful to the environment. Do not dispose of this item in household waste. Please use your local recycling center or collection system as appropriate for disposal of this item.

Please retain the instruction leaflet for future reference since it contains important information.

Pringles® is a registered brand of the Kellogg Company.

If you need further instructions or support, go to www.pringles.com and find the service line number for your country.













FCC ID: 2AJ7OSI598

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a resident installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no

accordance with the instructors, interest to a guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC RADIATION EXPOSURE STATEMENT

This device complies with FCC & IC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

مُعرَّف لحنة الاتصالات الفدر الدة: 2A.J7OSJ598

يترافق هذا الجهاز مع الجزء 15 من قواعد لجنة الاتصالات الفير الية. ويخضع التشغيل للشرطين التاليين: (1) ألا يتسبب هذا الجهاز في حدوث تداخل ضار، و(2) يجب أن يقبل هذا الجهاز أي تداخل يتم استقباله بما في ذلك التداخل الذي قد يتسبب في تشغيل غير

مرغوب أبي. تنبيه: بحب أن بنتبه المستخدم إلى أن أي تغييرات أو تحويلات لم يتم اعتمادها صراحةً من قبل الطرف المسؤول عن الامتثال قد تُبطل حق المستخدم في. تشغر الحديد

تشغيل الجهاز.

بيان لجنة الاتصالات القدرالية كو أخرية الما الجياز فيتات توافقه مع حدود الأجهزة الرقبوة من الفنة ب، وفقاً للجزء 15 من قواحد لجنة الاتصالات القيدرالية، و هذه الحدود تهدف إلى كم يتم تركيه واستخدامه وفقاً للتعليمات فقد يتسبب في حدوث تداخلات ضارة بالإتصالات اللاسائية، ومع نلك، فليس هذاك ما يضمن عدم حدوث التداخل لم يتم تركيه واستخدامه وفقاً للتعليمات، فقد يتسبب في حدوث تداخلات ضارة بالاتصالات اللاسائية، ومع نلك، فليس هذاك ما يضمن عدم حدوث التداخلات ضارة باستقبال التنزيون أو الراديو، وهو ما يمكن تحديد عن طريق إغلاق وقعم العيان، نيمه السنخدم بأن يجدل إصلاح التناخل عن طريق تقيد واحد أو اكثر من الإجراءات الثانية،

إعادة توجيه أو نقل هوائي الاستقبال.

ـ زيادة المسافة الفاصلة بينُ هذا الجهاز وجهاز الاستقبال.

توصيل الجهاز بمقبس على دائرة مختلفة عن الدائرة التي يتصل بها جهاز الاستقبال.
 الرجوع إلى البائع أو فنى راديو إتلفزيون ذى خبرة من أجل المساعدة.

ictQATAR

Type Approval reg. No.: nnnnnn

Importer No:

لله لجنة الاتصالات الفيدر الية بشأن التعرض للإشعاع يتراق هذا الجهار محدود العرض للإشعاع الصادرة عن لجنة الاتصالات الفيدرالية وهيئة الصناعة الكندية شأء السنات عنر الخاصمة للمراقبة

ثم تقييم الجهاز بُحيثِ يلبي المتطلبات العامة الخاصة بالتعرض للتردد اللاسلكي. يمكن استخدام هذا الجهاز في دمنة تعرض محمولة دن فقيد.

OMAN-TRA X/NNNN/YY Dyynnnn

TRA REGISTERED No: nnnnnnn

DEALER No:

AGREE	PAR	LANKI	MARUC