
## **User Manual**





1. Application initialization	1
2. Settings Menu	2
3. Main Screen	3
Status Information	3
Guide To User	4
4. Authentication For Administrative Menu	5
5. Administrative Menu	6
6. User Registration	7
Face detection	7
Input User ID	8
7. System Information	9
8. User Authentication	10
With RFID Card	10
One-To-Many	11
9. Call To Managing Staff	12


◆ This screen indicates initialization of facial recognition engine, configuration and user registration data load.




card tagging first, One-To-Many mode

for facing to camera first


- ◆ User can change the value of device channel ID, network information and facial recognition mode.
- ◆ This screen displayed at the first time system runs. Next time user can open this menu at -> Configure.




- ◆ This screen shows normal status of the system ready for user recognition.
- ◆ User can call to managing staff, check current essential status of device.




- Displays current recognition mode.
- ◆ User can decide whether card tagging is need first or facial recognition is need based on central image.
- is displayed if additional information is need after RFID card tagging




- User can enter into administrative menu after password input.
- Password screen supports numeric keypad and master RFID card.




 Administrative menu supports register user, manage the configuration, checking system information, system restart.




◆ User should take five images need to regist (front, left, right, upward, downward).



- User should input user ID for personal identification.
- ◆ This screen supports both numeric keypad and RFID card.




◆ This screen provides system information such as channel ID, SW version, update date, enroll count, recognition mode.





Back to main screen

◆ If facial recognition mode is One-To-One, user should tag RFID card first to access system.




One-To-One mode indication

- When user tag card to device, square image will be disappeared.
- If face is in the green square, facial recognition is come into action.
- Compare face image from camera and enrolled data with RFID card.




Success case, displays authenticated time and user ID then open gate.





Displays time when authentication failed.

**◆** Authenticate with user's face only.



Indicator for One-To-Many mode.

#### **Guide Image**

- If face is in the green guide line, facial recognition is come into action.
  - Check face image from camera and whole user's image



Success case, displays authenticated time and user ID then open gate.


### Please come close forward

Displayed when user's face is to small for detecting.



Displays time when authentication fails.

- ◆ The guest or not enrolled user will use this function to access.
- ◆ If user use this function, system will send streaming images to system or manager to got grant for accessing





is come into call function

- While displaying this popup, camera preview is send to manager.
- Manager can check person in front of device decide whether opens door or not.



If manager is not answered in dedicated seconds this popup is displayed and back to main screen.

Stop to call manager, back to main screen

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference. and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

#### Caution

Any changes or modifications (including the antenna) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

# Thank You.