KOOCAN

BOX

OTT

(K15)

KOOCAN

官方网址 www.koocan.com

客服邮箱 service@koocan.com

用戶手冊 User Manual

1. 產品說明

1.1 使用指南

- 未經專業人士指導,請勿私自拆卸機頂盒,以防觸電。 為避免火災,長時間不使用機器時,請拔掉電源。
- 若發現電源線有破損,請停止使用并更換電源線。
- 手濕時請勿接觸機頂盒,以避免液體流入機器導致元器件短路。
- 請將機器安放在通風乾燥的地方。 請勿將雜物堆放在機頂盒,避免散熱不良。
- 清洁機器外壳時,請將抹布擰干,以免液體流入。

2. 主要特性

處理芯片

- ARM四核處理器,主頻2.0GHz 五核ARM Mali-450 GPU, 750MHz 3D
- 圖像外理 2.5D圖形處理器
- 4K 視頻解碼. 支持H.265視頻播放
- 電源控制處理器

内存&閃存 • 1GB DDR3内存

- 内置 8GB eMMC
- 網絡
- 内置WiFi/IEEE802.11和蓝牙功能
- Cable RJ45 10/100Mbps高速以太網

其它

- HDMI 2.0
- 可選AV輸出

3G USB接口支持WCDMA/CDMA2000

- 遙控及電源指示 1個USB端口
- 5V/2A 直流電源輸入
- 操作系統
- 安卓 5.1.1 系統
- 支持多语言
- 2.4G無線鍵盤滑鼠

標準功能

- 支持多種格式的視頻電影播放(*.mkv,*.wmv, *.mpg,*.mpeg,*.dat,*.avi,*.mov,*.iso,*.mp4,
- *.rm 等.)

支持多種輸入方式包括遙控器、有線鍵盤滑鼠、

- 支持多種格式的音樂播放(MP3,AAC,WMA,RM, FLAC,Ogg 等.)
- 支持多種格式的圖片播放(JPG,JPEG,BMP,GIF,PNG

- 網百浏警
- 支持日曆顯示
- 特色功能 支持HTML5
- 支持手機遙控
- 支持白定義開機直播
- 支持多屏互動 支持斷點續播
- 支持在線VOD應用 支持安卓應用市場
- DIY電視節目
- 在線電影搜索
- 3D游戲 局域網多媒體共享播放
 - DLNA
- Airplay Miracast
- 語音及視頻诵話
- Samba client
 - KODI
- QQ語音通話

3. 遙控器使用說明



<u>Ф</u>	打開/關閉電源		
0 K	静音		
	四種顏色對應不同快捷功能,具體參照軟體中的		
	電子版説明書		
P-			
P-	向上翻屏		
P+	向下翻屏		
GOTO	快速切换程序		
0	打開或關閉鼠標功能		
VOL-	音量减		
VOL+	音量加		
MENU	1.顯示主菜單或返回上一級菜單		
	2.開機時,連續按壓MENU鍵,可進入RECOVERY模式		
INFO	顯示狀態及當前節目信息		
CH+/CH-(▲)(▼)	切换節目或上下移動光標		
VOL+/VOL-(►)(◀)	左右切换或左右移動光標		
	1.在操作界面上按此鍵確認屏幕上光標或焦點所指		
OK	的選項。		
	2.在媒體播放界面按此鍵暫停與播放。		
HOME	回到主菜單		
EXIT	退出		
0~9	数字輸入		
•	符號:・		
DEL	輸入狀態下删字符		


4. 面板



后面板







正面








AV	AV綫接口
HDMI	HDMI高清線接口
LAN	網線接口
DC 5V	直流5V供電
USB	USB 接口
TF	TF卡接口
RECOVERY	强制恢復出廠設置

5. 網絡機頂盒安裝示意圖

請閱讀下面相應的安裝說明,當需連接新的設備到機器上時,為確保正確安裝,請認真按照下面相應安裝圖示操作。



1. General Information

1.1 Important Safety Instructions

Please read and save for future reference

Thank you for choosing our product. Before installation, we would like to remind you some notes, which is very important to operating safely and properly, as follows:

- Please do not remove the cover without professional guidance to prevent electric shock
- Please unplug the power if long time no use to avoid the fire
- Please stop using the power cable if it is damaged and get a new replacement
 - Please do not touch the box with wet hand, in case the liquid flow inside the box which lead to component short circuit
- Please put the box under a ventilated dry place
- Please do not put other stuffs over the box in case heat dissipation affected
- Please wring the tower when cleaning the box shell, in case the liquid flow into the box

Main Features

Processor

Quad-core ARM Cortex CPU,up to 2.0GHz frequency

Penta-core ARM Mali-450 GPU, 750MHz for 3D Graphics processing

Memory & Flash

1GB DDR3 Memory

8GB eMMC internal

Network

supported

WiFi/IEEE802.11 and Bluetooth

Cable RJ45 10/100Mbps Fast Ethernet

3G USB Dongle for WCDMA/CDMA2000

4K video decoding, support H.265 video format

2.5D graphics processor

Power Management Processor

Standard Applications Video Movie Player(*.mkv,*.wmv,*.mpg,

*.mpeg, *.dat, *.avi, *.mov, *.iso, *.mp4, *.rm etc.) Music Player(MP3, AAC, WMA, RM, FLAC, O99

etc.) Picture viewer (JPG, JPEG, BMP, GIF, PNG etc.)

Web Browser Weather, Calendar etc

Other

HDMI 2.0

Optional for AV output(Ear Jacket)

IR and power indicator

1 Host USB Port

5V/2A DC Input

Operation System

OS Android 5.1.1 or Later Multi languages supported

User Input Method include IR RCU,USB

Keyboard&Mouse, 2.4G Wireless Mi Keyboard&Mouse& RCU

Pre-Load Applications

Online video search

HTML5 supported
Online VOD application
Customized application market
Customized applications

3D Game LAN Multi-media Sharing Play

DLNA

Airplay SKYPE

Samba client

KODI Miracast

QQ Voice Call

3. Remote Control Unit




ტ	Turn on/off the STB		
o k	Enable or disable the audio output		
	The color button have it's special function, please		
	find the corresponding description in TV box		
P-	Page down		
P+	Page up		
GOTO	Fast switching program		
0	Open / Close the mouse function		
VOL-	Decrease the volume		
VOL+	_+ Increase the volume		
MENU	Show the main menu or exit back to previous		
MENU	menu		
TNEO	To display channel status or various program		
INFO	information for current channel		
CH+/CH-(▲)(▼)	Channel change or move cursor up or down		
VOL+/VOL-(▶)(◀)	Volume Control or move cursor left or right		
OK Confirm the selected item			
HOME	E Back to the desktop		
EXIT	Escape from present menu and save the settings		
0~9	Select channels or enter programming		
•	Symbols: •		
DEL	Delete character input state		
	_		

4. Panel

Left Panel



Rear Panel



Right Panel

Top Panel




Front Panel



RECOVERY	RY Mandatory reset factory setting	
AV	Connect to AV port output	
TF	Support TF Card	
НОМІ	Connect to TV's HDMI port	
LAN	Connect the Ethernet port	
DC 5V	Connect to 5V Power Adapter	
USB	Connect to USB device	

5. Installation of receiver

Please find relevant reference of installation described as below: When connecting new equipment to the receiver, be sure checking first related instructions for the proper way of installation.



提示:尊敬的使用者您好,此卡片用於保修及服務帳號的認定,請您保存好此卡

Tips: Hello,Dear User , this card is used for warranty and service identification, please keep it carefully.

產品資訊 Produc	E品資訊 Product Information						
產品型號 Product M	Model Number						
產品序列號 Produc	Serial Number						
經銷商 Distributor							
銷售記錄 Sales Rec	ord						
維修記錄 Maintenance Records							
日期 Date	故障现象 Fault Phenomenon	故障原因 Failure Cause	處理情況 Handling Information				

官方网址 Official Mall: www.koocan.com

客服邮箱 Service E-mail: service@koocan.com

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class

B digital device, pursuant to Part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio

frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However,

there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception.

which can be determined by turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the f

following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

This equipment should be installed and operated with the minimum distance of 20cm.