For the latest, online version of this guide, supplementary documentation for this product includes: DoC, safety and regulatory information, ErP Regulatory information, and other related regulatory notices, please visit creative.com/support/nova

Detailed instructions on removal of integrated battery can be found at Quickstart User Guide / Safety and

Regulatory Information (creative.com/support/nova), these instructions are meant strictly for independently qualified professionals.

IMPORTANT REGULATORY SAFETY INSTRUCTIONS

Use a mains plug / cord that is appropriate for your country or region. DO NOT operate the product with other power sources. CAUTION: Do not expose this apparatus to dripping or splashing fluids, and ensure that no objects filled with liquids - such as vases

- are placed on the apparatus

Place the product near a socket outlet, which is easily accessible.

Do not attempt to service any part of the product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Additional guidelines for wireless devices


- · The short wave radio frequency signals of a wireless device may impair the operation of other electronic and medical devices. Switch off the device where it is prohibited. Do not use the device in medical facilities, aircraft, refueling points, close to automatic
- doors, automatic fire alarms or other automatically controlled devices
- Keep this device at least 20 cm from pacemakers and other medical devices. Radio waves may impair the operation of pacemakers and other medical devices.

For models with embedded battery

- Do not attempt to remove the embedded battery
- The product must be disposed of according to local environmental regulations. To replace the battery, return your product to your regional support office. For product service information, go to www.creative.com
- Do not expose to excessive heat such as sunshine, fire or the like.

Perchlorate material special handling may apply see www.dtsc.ca.gov/hazardouswaste/perchlorate

CAUTION: Risk of explosion if battery is replaced by incorrect types. Replace only with the same or equivalent type.



WARNING The remote control supplied with this product contains a coin/button cell battery. If the coin/button cell battery is swallowed. It can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

BATTERIES DIRECTIVE

FOR REMOVABLE BATTERY (Li-ion/polymer, button/coin cells, cylindrical cells) This product contains one or more of the above removable batteries. The crossed-out wheeled bin symbol indicates that the battery in

this product should not be treated as unsorted municipal waste upon reaching its end of life. Instead it should be taken to separate collection and recycling schemes. Batteries containing heavy metal content will have a two-letter symbol for the chemical under the crossed-out wheeled bin symbol. 'Cd' stands for cadmium, 'Pb' for lead, and 'Hg' for mercury. You can help the environment and avoid public health hazards by recycling the battery at an authorized recycling facility or the place of purchase. To find the nearest authorized recycle centre contact your local authority. Instructions for removing the battery can be found in the product user manual. The instructions should be followed carefully before attempting to remove the battery

FOR INTEGRATED BATTERY This product contains a Lithium ion/polymer battery that should only be removed by an authorized recycling centre. By recycling this

product at your local authorized recycling centre or the place of purchase, the battery will be removed and recycled separately.



電源内蔵製品のみ対象

製品筐体底面または背面に安全警告あり


正三角形の中に矢印の付いたカミナリの形が示されたマークは、製品内に絶縁されていない"高電圧発生部"が存在することを示し、人体に対して感電 の危険性があります。


三角形の中にエクスクラメーションマークが表示されたマークは、警告として重要な取り扱い上の説明、及びメンテナンス(保守)に関する情報がこの



本機がクラスIIまたは二重絶縁電気製品であることを表します。 本機が屋内使用専用であることを表します。







感電防止のため、グリルが取り外されている状態では主電源に接続しないでください。(グリルがある機器の場合)雨や火災や感電の原因となるため、本製品を雨や 水に当たらないようにして下さい。

接地アース付きプラグの場合は、保護接地接続(アース)端子のある電源コンセントに差し込んで下さい。、脱着式の電源コードセットの場合、遮断装置として使用される 電源接続器と電源プラグはすぐに使用できる状態にしておく必要があります。固定式の電源コードセットの場合、遮断装置として使用される電源プラグはすぐに使用で きる状態にしておく必要があります。全極型電源スイッチが遮断装置として使用される場合、すぐに使用できる状態にしておく必要があります。

脱着式電池のモデルの場合

電池は適切にリサイクルまたは処分する必要があります。リサイクルおよび処分に関する方法は、現地当局にお問い合わせください。

- 全屋物が雷池の橋に触れないようにしてください。 充電中、または使用中に遺漏、悪臭、変色、または変形が生じる場合は、電池を抜いて、それ以上使用しないでください。
- 食品や目などの敏感な部分に触れる前に、両手をしっかり洗浄してください
- 日光、火など渦剰な勢に触れないようにしてください。 長期間使用しない場合は、雷池を取り外します。
- 次の記述は、米国カリフォルニア州法においてCRタイプのリチウムボタン電池を含む製品にのみ適用されます。

ヘッドフォン出力つきのモデルの場合

- イヤフォンやヘッドフォンで 毎時間大帝量で開き続けると聴覚障害のおそれがありますのでおやめください、自動車や自転車の運転中 道路横断の際 特 「ラントラント」に交通量が激しい場合や道路での安全が脅かされるような状況ではオーディオデバイスを使用しないでください。道路で使用するような場合は安全に 改造について: Creative Technology Limitedまたはその関連会社によって明示的に承認されたもの以外の変更や改造を加えると、ユーザーの保証権利が無

INSTRUCTIONS IMPORTANTES SUR LA RÉGLEMENTATION ET LA SÉCURITÉ

Utilisez une prise électrique / un cordon correspondant à votre pays ou à votre région. NE faites PAS fonctionner le produit avec d'autres sources d'alimentation

ATTENTION: N'exposez pas cet appareil aux fuites ou éclaboussures. Assurez-vous également qu'aucun récipient contenant du

Positionnement des produit Placez le produit à proximité d'une prise de courant facilement accessible

N'essavez pas de réparer le produit vous même. Ouvrir ou retirer les parties protectrices de l'appareil peut vous exposer à des composants électriques sous haute tension ou à d'autres risques. Toute réparation doit être effectuée par un personnel qualifié

Consignes supplémentaires pour les appareils sans fil

liquide (tels que des vases) n'est placé sur l'appareil

- Les fréquences radio à ondes courtes émises par un appareil sans fil peuvent perturber le fonctionnement des autres appareils électroniques et médicaux
- Arrêtez l'appareil si son utilisation est interdite. Ne l'utilisez pas dans les structures médicales, les aéroports et les stations essence ni à proximité des portes automatiques, des alarmes incendie et des autres dispositifs à commande automatique Ne rapprochez pas cet appareil à moins de 20 cm d'un simulateur cardiaque ou d'un autre appareil médical. Il émet des ondes radio
- qui risquent de perturber leur fonctionnement Pour les modèles dotés d'une batterie incorporé

Ne tentez pas de retirer la batterie intégrée

- Le produit doit être mis au rebut conformément aux réglementations environnementales locales. Pour remplacer la batterie. retournez le produit à votre bureau dfassistance régional. Pour obtenir des informations sur la maintenance du produit, consultez le site www.creative.com
- N'exposez pas votre produit à une chaleur excessive comme la lumière du soleil, un feu, etc.

Des règles spéciales peuvent s'appliquer pour la manipulation des produits contenant du perchlorate. Reportez-vous au site www.dtsc.ca.gov/hazardouswaste/perchlorate

ATTENTION: Risque d'explosion si vous remplacez les piles par des piles d'un type incorrect. Remplacer uniquement avec le même type ou un type équivalent.



NE PAS INGÉRER LA BATTERIE - RISQUE DE BRÛLURE CHIMIQUE La télécommande fournie avec ce produit contient une pile bouton. Si la pile bouton est avalée, elle peut

causer en seulement 2 heures des brûlures graves qui peuvent entraîner la mort. Maintenez les batteries neuves ou usagées hors de portée des enfants. Si le compartiment batterie ne se ferme pas correctement, cessez d'utiliser le produit et maintenez-le hors de portée des enfants. Si vous pensez que des batteries ont été avalées ou introduites dans une quelconque partie du corps, consultez

Symbole WEEE (Waste Electrical and-Electronic Equipment, Déchets électriques et d'équipement électronique) L'utilisation du symbole DEEE indique que ce produit ne peut être traîté comme déchet ménager. En garantissant la mise au rebut appropriée de ce produit, vous contribuez à préserver l'environnement. Pour plus d'informations sur le recyclage de ce produit, contactez les autorités locales, le fournisseur de service d'élimination des déchets ménagers ou le magasin où vous avez acheté le produit.

DIRECTIVE RELATIVE AUX PILES ET ACCUMULATEURS

POUR LES BATTERIES AMOVIBLES (Lithium-ion/polymère, piles bouton, piles cylindriques) Ce produit contient une ou plusieurs des batteries ou piles amovibles citées ci-dessus. Le symbole de la poubelle

barrée d'une croix a pour objet de vous rappeler que la batterie de ce produit doit faire l'objet d'une collecte sélective en fin de vie. Elle doit être déposée dans des points de collecte et de recyclage séparés. Les batteries contenant des métaux lourds sont signalées par un symbole à deux lettres pour la composition chimique imprimé sous le symbole de la poubelle barrée d'une croix. 'Cd' signifie le cadmium, 'Pb' le plomb, et 'Hg' le mercure. Vous pouvez protéger l'environnement et éviter les risques pour la santé publique en recyclant la batterie sur un site de recyclage agréé ou sur le lieu d'achat. Pour trouver le centre de recyclage agréé le plus proche, contactez les autorités locales. Les instructions pour le retrait de la batterie se trouvent dans le manuel utilisateur du produit. Ces instructions doivent être respectées scrupuleusement avant de tenter

POUR LA BATTERIE INTÉGRÉE Ce produit contient une batterie Lithium- ion/polymère qui ne peut être retirée que dans un centre de recyclage agréé. Si vous

déposez ce produit dans votre centre de recyclage agréé local ou sur le lieu d'achat, la batterie sera retirée et recyclée séparément.

CREATIVE - LIMITED HARDWARE WARRANTY

- Creative Lahs Pte Ltd and its affiliates ("Creative") warrants that the retail purchased Creative-branded hardware product herein ("Product") is free of material defects in materials and workmanship ("Defect(s)") that result in Product failure during normal consumer usage for the Warranty Period, according to the following terms and conditions:
- 1. This limited hardware warranty extends only to the original end-user purchaser and holder of this warranty ("You" or "Your") and is not transferable or assignable to any subsequent purchaser
- 2 You must provide proof of original purchase of the Product by a dated itemized receipt to be eligible for this limited warranty. 3. The limited warranty is ONLY applicable in the country or territory
- where the Product was purchased from an authorized retailer/reseller and excludes any product that has not been nurchased as new or is obtained as a result of the purchase of a non-Creative product. 4.If a Defect arises and a valid claim is received during the Warranty
- Period (as provided below). Creative will at its sole option, service the Product at no charge using new or refurbished replacement parts at our sole discretion. Please note that: The limited warranty for the Product is for twelve (12) months (for
- the European Union, twenty-four (24) months (excluding all wear and tear), subject to certain exceptions as stated in the EU Directive f. Any Product that: (i) has had its serial number altered, defaced or 1999/44/EC**) from the date of Your purchase ("Warranty Period"). The Warranty Period will be extended by each whole day that the Product is out of Your possession for repair under this warranty
- b.Creative will cover the labor charges incurred by Creative in repairing or replacing the defective parts during the Warranty Period from the date of your purchase c. You will not have to pay for any such replacement parts.
- Creative also warrants that the renaired or replaced parts will be free from defects in material and workmanship for the remainder of the Warranty Period e.For the limited warranty of the Product's Liquid Crystal Display, please
- refer to the Creative Support Web Page at www.creative.com/support. 5 This warranty gives You specific legal rights. You may also have other rights, which vary from state to state and country to country. The terms of this warranty do not exclude such rights or limit them. Your statutory rights are unaffected. Some states and countries do not allow (i) exclusions of, or limitations on, certain liabilities or warranties, including but not limited to how long a warranty lasts, the exclusion or limitation of incidental or consequential damages or the exclusion of liability for injury (including death) caused by negligence, (ii) the inclusions of certain asymmetrical terms in warranties, or (iii) the expiration of all legal claims after a fixed time, so certain of the above limitations. exclusions or asymmetrical terms may not apply to You depending on the relevant jurisdiction. If adjudged invalid, such term(s) would be severable without affecting the validity of the other terms
- 6 Creative does not warrant uninterrupted or error-free operation of the Product. Creative is not responsible for damage arising from failure to follow all or any instructions relating to the Product's use. Creative is not under any obligation to support the Product for all operating environments, including but not limited to, interoperability with both current and future versions of software or hardware.
- 7.For Products that are capable of storing data: Creative is not responsible or liable for any data stored on the Product that is lost deleted or becomes otherwise inaccessible. All data may be deleted from the Product during servicing. You should remove or make a backup copy of any data stored on the Product before sending the Product to Creative 8 If a problem develops during the Warranty Period, please refer to www.
- creative.com/support or contact Your retailer/reseller. Please note that: (i) You must provide proof of original purchase of the Product by a dated itemized receipt; (ii) You shall bear the cost of shipping (or otherwise transporting) the Product to Creative. Creative will bear the cost of shipping (or otherwise transporting) the Product back to You after completing the warranty service; (iii) Before You send the Product to Creative. You must be issued a Beturn Merchandise Authorisation ("RMA") number from www.creative.com/support. Clearly write the RMA number on the outside of the package containing the Product being sent to Creative. Creative will not accept a return that does not have a RMA number on the outer packaging; and (iv) You can only return the defective Product(s) not excluded under Section 9 below. Creative is not responsible for other products or accessories returned with the defective Product(s). Creative reserves the right to change the method by which Creative may provide warranty service to you and your Product's eligibility to receive a particular method of service Service will be limited to the options available in the country where service is requested. Service options, parts availability and response times may vary according to country. For further details on Creative Warranty terms. Product returns and repair procedure. Creative customer support services and contact information, please refer to the support section of Creative's web site at www.creative.com/support 9. The limited warranty does not apply to:
- a.Consumable parts, such as batteries or protective coatings that, due to their nature, tend to diminish over time, unless failure has occurred due
- to a defect in materials or workmanship b Damage caused by normal wear and tear, abnormal use or conditions

misuse neglect abuse accident improper handling or storage defects or damages resulting from service testing adjustment installation maintenance, alteration, including without limitation, software change or modification in any way by someone other than Creative or its authorised service centres. improper use of any electrical source. undue physical or electrical stress, operator error, non-compliance with instructions or other acts which are not the fault of Creative, including Creative I ahs Pte Ltdおよびその関連会社(以下「Creative」)は以下の damage or loss during shipment or transit.

c Damage from external causes such as floods, storms, fires, sand, dir earthquakes, an Act of God, exposure to sunlight, weather, moisture. heat, vibration or corrosive environments, electrical surges, battery leakage, theft, or damage caused by the connection to other products not recommended for interconnection d.Damage or loss of data due to (i) interoperability with either or both

current and future versions of operating systems or other current or

- future software and hardware (ii) a computer virus worm spyware て日付が明記された領収明細書を提出する必要があります。 Trojan horse or memory content corruption, or (iii) malfunction or defect 3 太陽定保証の規定は 太型品がクリエイティブ認定の販売店/重販業者を of the Product 涌して購入された国または地域でのみ適用され、新品として購入されなかっ e.Counterfeit products/parts or any accompanying products/parts that are た場合、もしくはクリエイティブ以外の製品を購入した際の付属物として入 incompatible with the Product. 手された場合は適用外となります。
- removed: (ii) shows evidence of tampering: (iii) mismatched board 合、クリエイティブは自身の選択により無償にて新品または再生交換部品 serial numbers; or (iv) has non-conforming or non-Creative housing or を使用し、自由裁量にて本製品または修理済の本製品を提供します。下記 g.Any accessories including but not limited to disposable alkaline a. 製品の限定保証は、購入日から12ヶ月間(「保証期間」)(欧州連合の場合 batteries, removable fuses, screen protectors, plugs and pouches. は、EU指令1999/44/EC**に記載されている特定の例外を除き、24ヶ月間
- h.Any defect occurring after the expiration of the Warranty Period or (損耗はすべて除外))です。保証期間は、本保証書に基づく修理の期間(本 where Creative was not advised in writing of an alleged defect or 製品がお客様のお手元にない期間)に応じて延長されます。 malfunction within seven (7) days after the expiration of the Warranty b お客様の購入日を開始日とする保証期間中の不具合部品の修理また は交換のためのクリエイティブ側の作業費については、クリエイティブ自
- O Any Product determined by Creative to be warranty-expire warranty-void or not in need of repair will be subject to a minimum c. お客様はかかる交換部品の代金をお支払いになる必要はありません。 non-refundable diagnostic and handling fee. In the event that You fail d. また、クリエイティブは修理または交換後の部品は、残りの保証期間にお to make the payment. Creative may at its sole discretion, dispose of いて材料や製造上の不具合を有しないことも保証します。 the Product without notice and liability to You e 製品の液晶ディスプレイを対象とする限定保証については、クリエイティフ
- . Subject to any non-excludable limit under applicable law, the maximum liability under this limited warranty is the original price paid for the Product (excluding any shipping and additional charges) Creative and its affiliated companies will not be liable for any other losses or damage unless liability is non-eycludable under applicable law. The remedy stated is Your exclusive remedy for breach of warranty. Any action or lawsuit for breach of this limited warranty must be commenced within eighteen (18) months following the original purchase of the Product or within the limitation period under applicable law. 2 INSOFAR AS PERMITTED BY LAW THE PRODUCT AND
- THE SERVICED PRODUCT IS PROVIDED "AS IS" TO THE EXTENT PERMITTED BY APPLICABLE LAW CREATIVE AND ITS AFFILIATED COMPANIES HEREBY DISCLAIM THE APPLICABILITY OF ANY IMPLIED WARRANTY OF MERCHANTARII ITY 6. クリエイティブは製品の連続動作またはエラーのない動作の保証を行 FITNESS FOR A PARTICULAR PURPOSE OR USE FOR THE PRODUCT AND/OR THE SERVICED PRODUCT. CREATIV AND ITS AFFILIATED COMPANIES WILL NOT BE LIABLE FOR ANY INDIRECT INCIDENTAL SPECIAL PUNITIVE OF CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO ANY LOST PROFITS SAVINGS DATA OR LOSS OF USE ANY THIRD PARTY CLAIMS AND ANY INJURY TO PROPERT OR BODILY INJURY (INCLUDING DEATH) TO ANY PERSON ADISING EDOM OD DELATING TO THE LISE OF THE PRODUCT OR ARISING FROM BREACH OF THE WARRANTY BREACH OF CONTRACT, NEGLIGENCE, TORT, OR STRICT LIABILITY, EVEN IF
- CREATIVE OR ANY OF ITS AFFILIATED COMPANIES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. 8. 保証期間中に問題が発生した場合、www.creative.com/supportをご 13. For Australia only: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. (Creative Technology Ltd. 31 International Business Park, #03-01 Creative Resource, Singapore 609921 Telephone: +65 6895 4101 (standard international call charges apply.))
- 14. This is the entire warranty and supersedes all prior and contemporaneous agreements or understandings, oral or written relating to warranty coverage for the Product, and no representation promise or condition not contained herein will modify these terms. 15. Update(s) of this Limited Hardware Warranty may be posted at www. creative.com/support. An Update will replace any earlier version upon
- posting on the web site. You are advised to check for Undate(s). A seller in the European Union (EU) may be entitled to refuse to repair or replace the goods if it is (i) impossible or (ii) disproportionate (eg. where the costs are unreasonably high for the seller) to do so, taking into account the value the goods would have had (if there were no lack of conformity), the significance of the lack of conformity and

or an appropriate reduction of the price or have the contract rescinded the EU Directive 1999/44/EC The consumer is not entitled to have the contract rescinded if the lack of conformity (or defect or fault) is minor. In which case, the seller is

クリエイティブ - ハードウェア製品を対象とする限定保証書

where an alternative remedy would be completed without significant

inconvenience to the consumer. In such cases, the consumer may ask

この限定保証の対象となるためには、製品を最初に購入した際の証明と

4 保証期間(以下に記載)内に不具合が発生し、正当な請求がなされた場

カサポートウェブページ (www.creative.com/support)をご覧ください

本保証書は、お客様に固有の法的な権利を付与するものです。お住まいの

州および国によっては、その他にも行使できる権利が存在する場合があり

ます。本保証書の各規定はかかる権利を除外または制限しません。お客様

の制定注上の権利は影響を受けません。一部の糾や国は、次のいずれかを

許可していません(i)保証期限や個条的またけ添条的場塞に対する書句

の排除または制限、または過失に配因する負傷(死亡を含む)に対する青

(iii)あらゆる法的な請求を一定の期間で満了とすること。このため前述の

各種制限または排除に関する規定や不条理な規定は、関連する法域によ

っては お客様に適用されない場合があります。上記各相定が無効な相定

と判断された場合には、本保証書から分離され、その他の規定の有効性に

ておりません。Creativeは、製品の使用に関するすべてまたは一部の指

エイティブは、本製品がいかなる動作環境でも稼働することを保証しませ

7. 本製品がデータを保存できる場合:クリエイティブは本製品に保存され

は青仟または義務を負いません。修理時にはすべてのデータが太型品か

必要に応じて本製品に保存されているデータを移動するかパックアップ

覧いただくか 最寄りの販売店/重販業者にご連絡ください。下記車項に

の本製品の配送費(もしくは輸送費)を負担することとします。クリエイラ

ィブは保証サービス完了後に生じるお客様への本製品の配送費はしくに

輸送費)を負担します。(iii) お客様は 本型品をクリエイティブに返送する

手続き クリエイティブカスタマーサポートサービス 連絡先等につきまし

は、クリエイティブのウェブサイトのサポートセクションをご覧くださ

9 本限定保証書の規定が適用されない場合を以下に示します。

たデータの内 当主 削除 その他アクセフ不能となったデータについて

ら削除される場合があります。クリエイティブへ本製品を返送する前に

し。これには、ソフトウェアまたはハードウェアの現行バージョンや今後リ

J-ス予定のパージョンとの互換性の保証が含まれますが、これらのみに

示に従わなかったことに記因する過事に対して責任を負いません。クリ

は影響を及ぼしません。

壬の排除を含むが、これらとは限定しない特定の責任や保証を排除またに

制限すること(ii)保証相定に特定の不条理な相定を含めること 給知または

保証規定に従い、本保証書に記載されているリテール販売向け製品として こより故障が発生した場合を除き、時間とともに減少する傾向があります。 ・ 涌堂の掲載や変化 楽田 不適正な環境 22日 故署 利田 事故 不適比 ついては、保証期間中の通常の使用環境において、材料および製造上の重 取り扱いまたは保管、サービスで生じた欠陥または損傷、テスト、調整、 大な不旦合(以下「不旦合」)を有しないことを保証します。 置、保守、改造、(クリエイティブ以外の者によるソフトウェアの改変、修正を ハードウェア型品を対象とする太陽定保証書は 太型品を直接購入し 今むがこれらに限定されない) またはクリエイティブ以外の認定サービス+ エンドユーザー購入者かつ本保証書の所有者(以下「お客様」または「お客 様の」と称します) にのみ適用され、転得者には譲渡または振替られません

築されていない他製品との接続による損傷。

ンターによる電源の不適切な使用、過度の物理的ストレスまたは電気的 レス、オペレータのエラー、手順の非遵守、出荷中の損傷または損失を含 クリエイティブの過失によらない他の行為といった原因による損傷。 c. 洪水、嵐、火災、砂、汚れ、地震、天災、直射日光、天候、湿気、熱、振動、腐食 環境、電圧異常、バッテリ漏れ、盗難などの外部要因による損傷、または推

a 雷池や保護コーティングなど消耗する性質のものは 材料や製造上の欠

entitled to turn down a request for rescission of the contract in such a

situation. For further details, please refer to Articles 3(3), 3(5) and 3(6) of

- d. 次のいずれかに起因するデータの損傷または損失。(i) オペレーティング テム、またはその他ソフトウェアまたはハードウェアの現行バージョンや 今後リリース予定のバージョンのいずれかまたは両方との互換性、(ii) コン ピュータウィルス、ワーム、スパイウェア、トロイの木馬、またはメモリコンテ wireless technology. Walls and structures may affect range of device. ンツの破損、(iii) 本製品の認動作または不具合。
- e. 偽造品/偽造部品または付帯製品/付帯部品のうち、本製品と互換性
- f. 以下のような製品: (i) シリアル番号が変更、損傷、削除されている本製 品、(ii) 改ざんされていることが明白な本製品、(iii) ボードのシリアル番 号が不一致な本製品、または(iv) クリエイティブの筐体またはケースと 規格等が合わないか、クリエイティブ以外の筐体またはケースを使用し . あらゆる付属品(使い捨て型アルカリ電池、脱着可能ヒューズ、画面保護
- プラグ、およびポーチ等を含むがこれらのみには限定されない)。 h. 保証期間後に発生した不具合、または保証期限切れ7日後以内にクリエイ ティブが書面にて通知を受けていない不具合または認動作。
-) クリエイティブが、保証期限切れの製品、保証対象外製品、または修理: 不必要な製品だと判断したあらゆる本製品については、最低限の仮金不同 の診断料および取扱手数料をご負担頂きます。お客様からのお支払いがな い場合、クリエイティブは、別途通知することなく、またお客様に対しいかな る責任も負うことなく、自由裁量で本製品を処分できます。
- 11 クリエイティブは 準拠法の下での非排除性へのいかたる損害によって 4. 木限定保証書を根拠とする書士限の書任範囲として 木制具について 当初払い受けた額(出荷費用や追加費用を除く)に相当する金額を上限と します。クリエイティブとその関連会社は、準拠法の下で非排除性が責任と ならない限り、その他の損失または損害についていかなる責任も負いませ 前述の救済は、保証規定に反する行為があった場合の排他的な救済。 なります。本限定保証の規定に反する行為を訴因とするあらゆる法的措施 または訴訟は、本製品の最初の購入から18ヶ月以内か、準拠法に基づく関 れた期間内に始めなければなりません
- 2. 準拠法に基づき許される範囲内で、本製品や修理済の本製品は「現状 のまま」で提供されます。また準拠法により許される範囲内で、クリエイティ やその関連会社は、本製品および / または修理済の本製品を対象とす る商品性 特定の目的への適合性 または用法に関するいかなる默示の保 証も放棄します。クリエイティブとその関連会社は、本製品の使用、保証規 記に反する行為、契約の規定に反する行為、過失、不法行為、厳格責任を うべき行為に起因または関連する、間接的損害、付随的損害、特別な損 微罰的または誘発的損害についていかなる責任も負いません。なお れらの指字には 漁生利益 貯蓄の事生 データ事生 使用損失 サードハ ニティの誘す 資産の掲案またけ↓身の角傷(死亡を今れ)等が今まれます。 がこれらのみには限定されません。なお本規定は、クリエイティブかそのい ずれかの関連会社が上記損害の発生可能性について告知されていた場合 であっても適用されます
- 本保証書は完全な保証書であり、本保証書の締結前か締結と同時に口 頭または書面で行われた、本製品の保証範囲に関するすべての合意または 了解事項に優先します。本保証書に記載されていない、いかなる表明、約束 意してください。(i) 本製品が最初に購入された際の日付が記載された領 事項、または条件も、本保証書内の規定を変更しません。 収書等の購入証明書を提示する必要があり、(ii) お客様はクリエイティブ 14. ハードウェア製品を対象とする本限定保証書の更新版は、www
 - m/supportに掲載されます。更新版は トシウェブサイト 掲載された時点で、旧版の後継版となります。お客様には、更新版の確認 をお勧めしています。 ** 欧州連合(FU)の売主は、商品の修理または交換を行うことが(i)不可能が
- 前に、www.creative.com/supportから返却承認 (「RMA」)番号の発行 を受ける必要があります。クリエイティブへご返送になる製品のパッケーシ 場合、または(ii)不相応(例:売主にとってコストが不当に高い)な場合、(ii) 、RMA番号を明記してください。クリエイティブはパッケージの外側 性の欠如がなかった場合の)商品が持つ価値、適合性欠如の重要性、 RMA番号が付いていない返送品は受け取りません、(iv) お客様は、以下セ よび消費者に重大な不便を与えることなく代替となる措置を完了できるこ クションQに担定されていない場合にのみ不具合型品を返送できます。クリ とを老慮に入れて それを拒否する権利を有することがあります。そのようた エイティブは不具合のある本製品と共に同梱されて返送されたその他の製 場合、消費者は価格の適切な減額を求めたり、契約を取り消したりするこ B. または付属品に関しては一切責任を負いません。Creativeは、保証サー いできます。適合性の欠切(または欠陥または故障)が軽微な場合は 消費 者は契約を取り消す権利を有しません。その場合、売主はそのような状況 ごスをお客様に提供する方法、および特定のサービスに関するお客様の製 品の適合性を変更する権利を有します。サービスについては、サービスが休 ける契約解除の要求を拒否する権利を有します。詳細については、FU指 た国で提供されているオプションにのみ限定されます。サービスのオ 今1999/44/FCの3(3) 3(5)および3(6)を参昭してください。 プション、提供される部品、および回答に要する時間は、国によって異なる http://creative.com/warranty 場合があります。より詳細なクリエイティブ保証条件 木型品の返送と修理

Technical Specifications

Input: 18V - 2A

Wifi Support: 802.11b/g/n: WPA2 Wifi Operating Frequency: 2412-2462MHz Maximum peak conducted output power: 802 11b: <20dBm 802 11g: <15dBm 802 11g: SISO <15dBm MIMO <18dBm

Bluetooth Operating Frequency: 2402 - 2480 MHz Bluetooth Operating Range / RF output power: Up to 10 meters, measured in open space. < 4dBm RF output power.

Supported Bluetooth® Profiles: A2DP (Wireless Stereo Bluetooth®) AVRCP (Bluetooth® Remote Control), HFP (Handsfree profile)

Supported Codec: SBC Lithium Ion Battery: 14 8V 2200mAH (32 56Wh

Output Power: 8W v 2 15W v 1 Battery Saving Mode: The speaker automatically powers down when

there is no Bluetooth®, Wifi, or power connection or no audio cable attached for more than 15 minutes Operating Temperature Range: 0°C - 45°C

Power Adapter Information - Model No: FJ-SW1802000N Input: 100-240VAC 50/60Hz Output: 18VDC 2A Note: Compliance markings are located on the bottom of the product. Wireless performance is dependent on your devices Bluetooth or WiFi

Caractéristiques Techniques Support WiFi: 802.11b/g/n: WPA2

Fréquence de fonctionnement WiFi: 2412 - 2462 MHz Puissance de sortie WiFi: 802.11b: <20dBm. 802.11g: <15dBm 802.11n: SISO <15dBm, MIMO <18dBm Fréquence de fonctionnement Bluetooth: 2402 - 2480 MHz

Fréquence de fonctionnement Bluetooth / Puissance de sortie RF: Jusqu'à 10 mètres, mesuré dans un espace ouvert, <4dBm Puissance de sortie RF

Profils Bluetooth® compatibles: A2DP (Wireless Stereo Bluetooth®), AVRCP (Bluetooth® Remote Control), HFP (Profil mains-libres) Codec pris en charge: SBC Batterie lithium-ion: 14.8 V: 2200 mAh (32.56 Wh)

Entrée: 18 V = 2 A Puissance de sortie: 8W x 2, 15W x 1

Mode d'économie d'énergie: L'enceinte s'arrête automatiquement lorsqu'il n'y a pas de connexion Bluetooth®, Wifi ou d'alimentation électrique ou aucun câble audio n'est connecté pendant plus de 15 Température de fonctionnement: 0°C à 45°C

Power Adapter Information - Model No: EJ-SW1802000N Input: 100-240VAC 50/60Hz Output: 18VDC 2A emarque: Le marquage de conformité est situé sur la partie inférieure

de ce produit. Les performances de la transmission sans fil dépendent. de la technologie sans fil Bluetooth de votre appareil. les murs et les structures peuvent influer sur la portée de fonctionnement

WiFi Betriebsfrequenz: 2 412 - 2 462 Mhz WiFi Ausgangsleistung: 802.11b: <20dBm, 802.11g: <15dBm, 802 11n: SISO <15dRm MIMO <18dRm Bluetooth Betriebsfrequenz: 2 402 - 2 480 MHz



Produkts. Bluetooth- oder WiFi- Leistung Ihres Gerätes. Wände und feste Strukturen können die Reichweite des Geräts vermindern

・ 技術仕様 WiFi規格:802.11b/g/n:WPA2

☐ Technische Dater

Unterstützte Codecs: SBC

Leistungsabgabe: 8W x 2, 15W x 1

Betriebstemperatur: 0°C - 45°C

Eingang: 18 V == 2 A

Audiokahel verhunden ist

WiFi Unterstützung: 802.11 b/g/n: WPA2

Bluetooth Reichweite / RF Ausgangsleistung: Bis zu 10 m,

gemessen im offenen Gelände. < 4dBm RF Ausgangsleistung.

AVBCP (Bluetooth® Remote Control) HEP (Handsfree-Profil)

Lithium-lonen-Akku 14 8 V: 2200 mAH (32 56 Wh)

Unterstützte Bluetooth®-Profile: A2DP (Wireless Stereo Bluetooth®).

Energiesparmodus: Der Lautsprecher schaltet sich automatisch

nach 15 Minuten aus wenn kein Bluetooth®, WiFi , Netzanschluss oder

WiFi動作周波数:2412-2462Mhz

WiFi定格出力:802.11b: <20dBm, 802.11g: <15dBm, 802.11n: SISO <15dBm MIMO <18dBm Bluetooth動作周波数:2402~2480MHz

Bluetooth通信範囲/RF出力:最大約10m(見通し距離)、RF出力 <4dBm 対応Bluetooth®プロファイル: A2DP (ワイヤレス ステレオ Bluetooth®) 、AVRCP (Bluetooth® リモート コントロール)、HFP (ハンズフリー プロ

対応オーディオ コーデック:SBC リチウムイオン バッテリー: 14.8V 2200mAH (32.56Wh)

λ 71·18V - 2Δ スピーカー出力:8W×2、15W×1

バッテリー ヤーブ モード: 15分以 FBluetoothまたはWiFi接続、雷源接 続がない、またはオーディオケーブルが接続されていない場合、自動的に 雷源をオフにします。

動作温度範囲:0°C~45°C Power Adapter Information - Model No: FJ-SW1802000N Input: 100-240VAC 50/60Hz Output: 18VDC 2A メモ: コンプライアンスマークは本製品下部に表示してあります。 ワイヤレス機能はお使いのデバイスのBluetoothまたはWiFiに依存しま

す。壁や構造物がある場合はワイヤレスでの使用範囲に影響が出る場





to third party licenses found here: developer.spotify.com. esdk-third-party-licenses trademark of Spotify AB.

nazon. Alexa and all related

nazon.com, Inc. or its affliates.

oos are trademarks of

WiHeartRADIO iHeartRadio is a registered trademark of iHeartMedia, Inc.

All other trademarks are the property of their respective owners and @ 2018 Creative Labs Pte Ltd. All rights reserved. Creative and the Creative long the terms and conditions of the end user license agreement.

Napster® and the Napster logo registered in the United States The Spotify Software is subject お客様へ商品をお渡しする際に販売日を明記した貴店印をご捺印下さい


Please put your dealer chop on this space for the customer.



www.creative.com/register

are hereby recognized as such. All specifications are subject to change are trademarks or registered trademarks of Creative Technology Ltd in the United without notice. Actual product may differ slightly from images shown. States and/or other countries. App Store is a service mark of Apple Inc. Android Use of this product is subject to a limited warranty. The software and Google Play are trademarks of Google Inc. The Bluetoothis word mark and included in this packaging may not be used separately from the logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of hardware. Before using the software, you must agree to be bound by such marks by Creative Labs is under license. Wi-Fi is a registered mark of the Wi-Fi Alliance

www.creative.com/sunnor










Model No.: MF8285 PN 03MF828500000 Rev A

Overview




- Power 2 Battery / Charging Indicator
- Microphone
- Bluetooth


- 6 LED Lightshow
- Amazon Alexa™ action ** 8 Microphone Mute/Unmute
- 9 Volume down/I+
- 10 Play/ Pause/ Answer call/ Reject call


* when applicable ** Press to speak to Alexa if required

Sleep Timer

SoundSpa Mode







Power & Battery indicator





for Wi-F1 setup.

The App also enables music playback from popular streaming services or from your own music library, Multi-Room/Multi-Speaker playback, and

schermo per impostare il WIFI. L'applicazione consente anche la riproduzione musicale dai siti di streamino

più popolari o dalle raccolte musicali personali, in modalità multi-stanza/a

het instellen van Wi-Fi.
Met de app kunt u ook muziek afspelen van populaire streamingservices
of van uw eigen muziekbibliotheek, afspelen in meerdere kamers met

a configuração WiFi. A Aplicação também permite a reprodução de música a partir de serviços populares de streaming, ou a partir da sua própria biblioteca de música, ou

streamingtjenester eller fra dit eget musikbibliotek, trådløst opsætning til

Med appen kan du spela upp musik från populära strömningstjänster eller från ditt eget musikbibliotek, i flera rum och över flera högtalare

lecture multi-pièces / multi-enceintes, et bien plus encore.

et instellen van Wi-Fi.

meerdere luidsprekers en nog zo veel meer. Transfira, instale e execute a Aplicação. Siga as instruções no ecrá para

a reprodução multiroom/multialtifalantes e muito mais.

Appen giver også mulighed for at afspille musik fra populære

Scaricare, installare e lanciare l'applicazione. Seguire le istruzioni sullo schermo per impostare il WiFi.



Download, installeer en start de app. Volg de instructies op het scherm voor

Pobierz, zainstaluj I uruchom aplikację. Postępuj zgodnie z instrukcjami



DE Download, installiere und starte die App. Folgen Sie den Bildsphirmingstruktionen zu Wilden App.

Multi-Room/Multi-altavoz y mucho más.

Room/Multi-Lautsprecher Wiedergabe und vieles mehr

Lataa, asenna ja käynnistä sovellus. Määritä Wi-Fi näytön ohjeita

noudattamalla. Sovellus mahdollistaa myös musiikin toistamisen suosituista

suoratoistopalveluista tai omasta musiikkikirjastostasi, toiston useassa huoneessa / usealla kaiuttimella ja paljon muuta.

wyświetlonymi na ekranie, aby skonfigurować ustawienia Wi-Fi. Aplikacja umożliwia odtwarzanie muzyki z popularnych serwisów, własnej kolekcji, w kilku miejscach i z kilku głośników jednocześnie

niestnostiach/z viacerých reproduktorov a mnoho ďalších funkcií.

nastavte siet WI-FI. Aplikácia umožňuje prehrávanie hudby z obľúbených streamovacích služieb alebo z vašej vlastnej hudobnej knižnice, prehrávanie vo viacerých

streamovacích služeb nebo z vaší vlastní hudební knihovny, přehrávání ve více místnostech/přehrávání více reproduktorů a mnohem více.

Загружайте, устанавливайте и запускайте приложение. Следуйте инструкциям на экране для настройки Wi-Fi.

アプリストアよりアプリをダウンロード/インストールし、起動してWiFiセットアップ方法を参照して下さい。

なな少照している。 には音楽再生機能のほか、対応音楽ストリーミングサービスまたは自身 ミライブラリーからのストリーミング再生、マルチルーム/丸内スピーカー

инструкциям на экране для настролки инт. Приложение также включает воспроизведение музыки с популярного потокового сервиса или с Вашей собственной музыкальной библиотеки, многокомнатное воспроизведение/

оспроизведение нескольких динамиков и многое другое.

の音楽ライブラリーからのスト! 再生などの機能が含まれます。

SK Stiahnite si, nainštaluje a spustte aplikáciu. Podľa pokynov na obrazovke

CZ Stáhněte, nainstalujte a spusťte aplikaci. Nastavte síť WiFi podle zobrazených pokynů. Tato aplikace rovněž umožňuje přehrávat hudbu z oblíbených

Bildschirminstruktionen zur WIFI- Einrichtung Die App ermöglicht die Musikwiedergabe von beliebten Streaming Anbietern oder auch die Kreation einer eigenen Musiksammlung, Multi-

Searching for speaker...

Wi-Fi Setup Wizasd



turn to the app to continu

CONTINUE



Creative Nov

Siri / Google Now

Security Recommens



CONTINUE





Mv WIFi Network










Spotify (1)


Listen out loud with Spotify Connect


- 1. Connect your Creative Nova to your wifi network
- 2. Open up the Spotify app on your phone, tablet or laptop using the same wifi network
- 3. Play a song and select Devices Available.
- 4. Select your Creative Nova and start listening











Additional Safety and Regulatory information for Creative Nova

Regulatory Information

The following sections contain notices for various countries:

CAUTION: This product is intended for use with FCC/CE certified computer equipment. Please check the equipment operating/installation manual and/or with the equipment manufacturer to verify/confirm if your equipment is suitable prior to the installation or use of the product.

Federal Communication Commission (FCC) Interference Statement Notice for USA FCC Part 15:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: To comply with the limits of the Class B digital device, pursuant to Part 15 of the FCC Rules, this device must be installed with computer equipment certified to comply with Class B limits.

All cables used to connect to the computer and peripherals must be shielded and grounded. Operation with non-certified computers or non-shielded cables may result in interference to radio or television reception.

MODIFICATION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device.

Federal Communication Commission (FCC) Radiation Exposure StatementThis equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

SUPPLIER'S DECLARATION OF CONFORMITY

According CFR Title 47 §2.1077

Manufacturer's Name: Creative Labs, Inc.

Manufacturer's Address: 1901 McCarthy Boulevard

Milpitas, CA. 95035 Tel: (408)428-6600

declares under its sole responsibility that the product

Trade Name: Creative
Model Numbers: MF8285

Product Name: Creative Nova

has been tested according to the FCC / CISPR22 requirement for Class B devices and found compliant with the following standards:

EMI/EMC: ANSI C63.4 & C63.10, FCC Part 15 Subpart B& C

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including Interference that may cause undesirable operation.

Supplementary Information:

Thinh Bui Compliance Manager Creative Labs, Inc. 5th July, 2018

充電式電池リサイクルについてのご注意



Li-ion

クリエイティブの一部製品にはリチウムイオン充電池が使用されています。

リチウムイオン充電池はリサイクル可能な資源です。

- ・クリエイティブ製品に内蔵されている充電池をリサイクルするには、充電池の取り外しはお客様ご自身では行わないで下さい。リサイクルの方法などのお問い合わせは、クリエイティブメディア株式会社のカスタマーサービスセンター http://jp.creative.com/support/contact/(日本語のみ)にご相談下さい。
- ・取り外しが可能なクリエイティブ製品の充電池をリサイクルするには -



注意事项

安全の為、電力を完全に使い切ってから充電池を取り外して下さい。

- ・安全の為、充電池の金属端子部分にはセロハンテープなどの絶縁テープを貼って下さい。
- ・安全策を講じた使用済み充電池は、充電式電池のリサイクル協力店へお持ち下さい。

充電式電池の回収/リサイクルおよびリサイクル協力店については、中間責任法人JBRCのホームページ http://www.jbrc.com/ を 参照して下さい。

Notice for Singapore

Complies with IMDA Standards DA107311