

User's Manual

WatchAir OpenArms

EPUS-100B

EPICT, Inc





I'll go "Settings" to set up

0

 \triangleleft


WatchAir-WatchAir_F145EB

WatchAir-WatchAir_F145F0


If W.A is setup on Home network, choose the first one.

If not click "I'll go "Settings" to set up"


Select W.A in AP mode




Type in your password




Back to previous page, then select your W.A(Currently in AP mode)



Select your home network that you are going to connect to W.A. And put in your password.




Screen showing connection switched to home network






Channel Scan




Channel information & Downloading image




Main Screen, "Available Now"

Select "Available Now" and click play button



Playing screen



FCC Statements

 NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.